

Device handbook

LINAX PQ5000-RACK

Operating instructions (2025-05)



GMC INSTRUMENTS

Camille Bauer Metrawatt AG
Aargauerstrasse 7
CH-5610 Wohlen / Switzerland
Phone: +41 56 618 21 11
Telefax: +41 56 618 35 35
E-Mail: info@cbmag.com
<https://www.camillebauer.com>

 CAMILLE BAUER
GMC-INSTRUMENTS GROUP

Legal information

Warning notices

In this document warning notices are used, which you have to observe to ensure personal safety and to prevent damage to property. Depending on the degree of danger the following symbols are used:



If the warning notice is not followed death or severe personal injury **will** result.



If the warning notice is not followed damage to property or severe personal injury **may** result.



If the warning notice is not followed the device **may** be damaged or **may** not fulfill the expected functionality.



If the cyber security policies are not followed data **may** be disclosed to unauthorized users, manipulated or restricted in its availability by cyber security threats.

Qualified personnel

The product described in this document may be handled by personnel only, which is qualified for the respective task. Qualified personnel have the training and experience to identify risks and potential hazards when working with the product. Qualified personnel are also able to understand and follow the given safety and warning notices.

Intended use

The product described in this document may be used only for the application specified. The maximum electrical supply data and ambient conditions specified in the technical data section must be adhered. For the perfect and safe operation of the device proper transport and storage as well as professional assembly, installation, handling and maintenance are required.

Disclaimer of liability

The content of this document has been reviewed to ensure correctness. Nevertheless, it may contain errors or inconsistencies and we cannot guarantee completeness and correctness. This is especially true for different language versions of this document. This document is regularly reviewed and updated. Necessary corrections will be included in subsequent version and are available via our webpage <https://www.camillebauer.com>.

Feedback

If you detect errors in this document or if there is necessary information missing, please inform us via e-mail to: customer-support@camillebauer.com

Contents

1. Introduction	5
1.1 Purpose of this document	5
1.2 Scope of supply	5
1.3 Further documents	5
2. Safety notes	6
2.1 Safety notes	6
2.2 Cyber Security notes	6
3. Device overview	7
3.1 Brief description	7
3.2 Device overview	8
3.2 Available measurement data	9
4. Mechanical mounting	10
5. Electrical connections	11
5.1 General safety notes	11
5.2 Possible cross sections and tightening torques	12
5.3 Power supply	12
5.4 Inputs	12
5.5 Digital inputs	20
5.6 Digital output	20
5.7 Analog outputs	20
5.8 Modbus interface RS485	21
5.9 Uninterruptible power supply (UPS)	21
5.10 GPS time synchronization	22
5.11 IRIG-B time synchronization	23
6. Commissioning	24
6.1 Cyber Security policies	24
6.2 Parametrization of the device functionality	25
6.3 Installation check	25
6.4 Ethernet installation	27
6.4.1 Settings	27
6.4.2 Connection of the standard interface	30
6.4.3 Connection of the IEC61850 interface	30
6.4.4 MAC addresses	30
6.5 Communication tests	30
6.6 3G/4G Router	31
6.7 IEC 61850 interface	31
6.8 Simulation of analog / digital outputs	31
6.9 Security system	32
6.9.1 RBAC management	32
6.9.2 User log in / out via website	35
6.9.3 User log in / out via local display	36
6.9.4 Whitelisting clients	37
6.9.5 Secure communication using https	37
6.9.6 Audit log (SYSLOG)	40
7. Operating the device	41
7.1 Operating elements	41
7.2 Selecting the information to display	41
7.3 Measurement displays and used symbols	42
7.4 Resetting measurement data	43
7.5 Configuration	44
7.5.1 Local configuration at the device	44
7.5.2 Configuration via web browser	46

7.6	PQ monitoring	48
7.6.1	PQ events	48
7.6.2	PQ statistic	50
7.6.3	Provision of PQ data	51
7.7	Alarming	52
7.7.1	Limit values on base quantities	52
7.7.2	Monitoring functions	53
7.7.3	Summary alarm	54
7.8	Data recordings	55
7.8.1	Periodic data	55
7.8.2	Events	58
7.8.3	PQ events	59
7.8.4	PQ statistic	62
7.9	Measurement information in file format	66
7.9.1	Predefined tasks	66
7.9.2	Creating periodic file data	68
7.9.3	Accessing file information via webpage	69
7.9.4	Download of PQIS files	70
7.9.5	Periodical sending to a SFTP Server	71
7.9.6	Evaluation of the PQDIF files	72
7.10	Display timeouts	72
8.	Service, maintenance and disposal	73
8.1	Calibration and new adjustment	73
8.2	Cleaning	73
8.3	Battery	73
8.4	Cyber Security Decommissioning	73
8.5	Disposal	73
9.	Technical data	74
10.	Dimensional drawings	80
Annex		81
A	Description of measured quantities	81
A1	Basic measurements	81
A2	Harmonic analysis	85
A3	System imbalance	86
A4	Mean values and trend	87
A5	Meters	88
B	Display matrices	89
B0	Used abbreviations for the measurements	89
B1	Display matrices for single phase system	95
B2	Display matrices for split-phase (two-phase) systems	96
B3	Display matrices for 3-wire system, balanced load	97
B4	Display matrices for 3-wire systems, unbalanced load	98
B5	Display matrices for 3-wire systems, unbalanced load, Aron	99
B6	Display matrices for 4-wire systems, unbalanced load	100
C	Logic functions	101
D	FCC statement	102
INDEX		103

1. Introduction

1.1 Purpose of this document

This document describes the universal measurement device for heavy-current quantities LINAX PQ5000. It is intended to be used by:

- Installation personnel and commissioning engineers
- Service and maintenance personnel
- Planners

Scope

This handbook is valid for all hardware variants of the PQ5000 rack version. Some of the functions described in this document are available only, if the necessary optional components are included in the device.

Required knowledge

A general knowledge in the field of electrical engineering is required. For assembly and installation of the device knowledge of applicable national safety regulations and installation standard is required.

1.2 Scope of supply

- Measurement device
- Quick installation and set-up guide
- Battery pack (optional, for devices with UPS only)

1.3 Further documents

This document is accessible via device website (menu **Service | Device information | Download manual**). Further documents are available via our homepage <https://www.camillebauer.com>.

2. Safety notes

2.1 Safety notes



Device may only be disposed in a professional manner!

The installation and commissioning should only be carried out by trained personnel.

Check the following points before commissioning:

- that the maximum values for all the connections are not exceeded, see "Technical data" section,
- that the connection wires are not damaged, and that they are not live during wiring,
- that the power flow direction and the phase rotation are correct.

The instrument must be taken out of service if safe operation is no longer possible (e.g. visible damage). In this case, all the connections must be switched off. The instrument must be returned to the factory or to an authorized service dealer.

It is forbidden to open the housing and to make modifications to the instrument. The instrument is not equipped with an integrated circuit breaker. During installation check that a labeled switch is installed and that it can easily be reached by the operators.

Unauthorized repair or alteration of the unit invalidates the warranty.

2.2 Cyber Security notes



This device can record data (measurement data, events, logging of operating procedures, etc.). This data can represent an asset that is worthy of protection and must be protected against disclosure and modification, and its availability must be guaranteed. In order to achieve the greatest possible security with regard to cyber security threats, the following must be observed:

Security-relevant settings must be made during commissioning. See the policies in [chapter 6.1 Cyber Security policies](#)

The device software must be kept up to date during operation. Software updates are published on the manufacturer's website.

When decommissioning the device, security-relevant measures must be performed. See [chapter 8.4 Cyber security decommissioning](#)

3. Device overview

3.1 Brief description

The devices of the LINAX PQ series are comprehensive instruments for the universal measurement and monitoring in power systems. They provide a wide range of functions, which may be extended using optional components. The nameplate on the device gives further details about the present version. A connection to the process environment may be established by means of communication interfaces, via digital I/O's, analog outputs or relays. The parameterization of the device is possible directly at the device or via web browser.

The LINAX PQ5000 is an independently certified measurement devices of class A according to IEC 61000-4-30 Ed. 3. It provides reliable and comparable information for regulatory authorities, negotiations with energy suppliers or internal quality control.

Continuous monitoring analyses breakdowns immediately and eliminates their causes in a sustainable manner. In addition, long-term acquisition permits the early recognition of changes in order to improve supply security and thus system availability.

The flexible approach without any software excels both in autarchy and flexible software integration options. It is based on standardized interfaces, generates compliance reports directly via the device website and excels with a comprehensive cyber security concept.

3.2 Device overview



	PQ5000R-2...	PQ5000R-3...
Voltage inputs	5	2 x 5
Input channels current	4 (5 A or 3 V)	2 x 4 (5 A or 3 V)
Function class acc. IEC 61000-4-30	Class A	Class A
Device type acc. IEC 62586-1	PQI-A FI1	PQI-A FI1
PQ COMPLIANCE MONITORING		
Power frequency	▪	▪
Voltage / current variations	▪	▪
Unbalance voltage / current	▪	▪
THDS of voltages	▪	▪
Harmonics voltage / current	▪	▪
Flicker Pst / Plt	▪	▪
Mains signalling voltages	▪	▪
Interharmonics voltage / current	▪	▪
PQ EVENT RECORDING		
Voltage dip	▪	▪
Voltage interruption	▪	▪
Voltage swell	▪	▪
Rapid voltage changes (RVC)	▪	▪
Homopolar voltage (unbalance)	▪	▪
Current swell	▪	▪
Frequency anomaly	▪	▪
Ripple control sequences	▪	▪
State change of digital inputs	▪	▪
MEASUREMENT UNCERTAINTY		
Voltage, current	±0,1%	±0,1%
Active, reactive, apparent power	±0,2%	±0,2%
Active energy (IEC 62053-22)	Class 0.2S	Class 0.2S
COMMUNICATION		
Ethernet: Modbus/TCP, Webserver, NTP	(Standard)	(Standard)
IEC 61850	(Option)	—
RS485: Modbus/RTU	(Option)	(Option)
Extension modules (optional)	4 analog outputs, 12 digital inputs, 1 relay	2 x 4 analog outputs, 2 x 12 digital inputs, 2 x 1 relay
POWER SUPPLY		
	100-230V AC/DC	100-230V AC/DC
Consumption	≤40 VA	≤60 VA
DESIGN		
Colour display	TFT 3,5" (320x240px)	2 x TFT 3,5" (320x240px)
Dimensions	482,6 x 132,6 x 270,1 mm	482,6 x 132,6 x 270,1 mm
Montage	Installation in 19" rack	Installation in 19" rack

3.2 Available measurement data

MEASURED VALUE GROUP	APPLICATION
INSTANTANEOUS VALUES • U, I, IMS, P, Q, S, PF, LF, QF ... • Angle between voltage phasors • Min/max of instantaneous values with time stamp	» Transparent monitoring of present system state » Fault detection, connection check, sense of rotation check » Determination of grid variable variance with time reference
EXTENDED REACTIVE POWER ANALYSIS • Total reactive power, fundamental frequency, harmonics • $\cos\phi$, $\tan\phi$ of fundamental frequency with min values in all quadrants	» Reactive power compensation » Verification of specified power factor
HARMONICS ANALYSIS (ACCORDING TO IEC 61000-4-7) • Total harmonics content THD U/I and TDD I • Individual harmonics / interharmonics U/I	» Evaluation of the thermic load of equipment » Analysis of system perturbation and consumer structure
IMBALANCE ANALYSIS • Symmetrical components (positive, negative, zero sequence system) • Imbalance (derived from symmetrical components) • Deviation from U/I mean value	» Equipment overload protection » Failure/earth fault detection
ENERGY BALANCE ANALYSIS • Meter for acquisition/supply of active/reactive energy, high/low-rate tariff, meter with selectable base variable • Power mean values active/reactive power, demand and supply, freely definable mean values (e.g. phase power, voltage, current and much more) • Mean value trends	» Preparation of (internal) energy billing » Determination of energy consumption versus time (load profile) for energy management or energy efficiency verification » Energy consumption trend analysis for load management
OPERATING HOURS • 3 operating hour counters with programmable running condition • Operating hours of the device	» Monitoring of service and maintenance intervals

The device provides measurements in the following subcategories:

- Instantaneous values:** Present TRMS values and associated min/max values
- Energy:** Power mean-values with trend and history as well as energy meters. Mean-value progressions (load profiles) and periodic meter readings are also available.
- Harmonics:** Total harmonic distortion THD/TDD, individual harmonics and their maximum values, phase angle of the harmonics
- Phasor diagram:** Overview of all current and voltage phasors and phase sequence check
- Waveform** of current and voltage inputs
- Events:** State list of monitored alarms, chronological lists of PQ events and self-defined alarms / events as well as operator events.
- PQ statistic:** Data of the statistical power quality analysis with the possibility to create reports (PQ-Easy Report).

4. Mechanical mounting



Please ensure that the [operating temperature limits](#) are not exceeded when determining the place of mounting (place of measurement).



By installing, the device becomes part of an electrical power installation that must be designed, operated and maintained in accordance with country-specific regulations so that the installation is safe and provides prevention against fire and explosion as far as possible.



It is the task of this installation to ensure that dangerous connections of the device cannot be touched during operation and that the spread of flames, heat and smoke from the interior is prevented. This may be done by providing an enclosure (e.g. case, cabinet) or using a room accessible to qualified personnel only and compliant with local fire safety standards.

5. Electrical connections




Ensure under all circumstances that the leads are free of potential when connecting them!

5.1 General safety notes




Please observe that the data on the type plate must be adhered to!

The national provisions have to be observed in the installation and material selection of electric lines, e.g. in Germany VDE 0100 "Erection of power installations with nominal voltages up to 1000 V"!



Backplane, single rack, with I/O extension, antenna connectors for 3G/4G router and IEC61850 interface



Backplane, double rack, without I/O extension and antenna connectors for 3G/4G router

Symbol	Meaning
	Device may only be disposed of in a professional manner!
	Double insulation, device of protection class 2
	CE conformity mark. The device fulfills the requirements of the applicable EU directives.
	Caution! General hazard point. Read the operating instructions.
	Warning, hazard of electrical shock.
CAT III	Measurement category CAT III
	Earth connector

5.2 Possible cross sections and tightening torques

Inputs L1, L2, L3, PE(L4), N(COM), I1, I2, I3, IN	
Single wire	• 1 x 0.2 ÷ 4.0mm² or 2 x 0.2 ÷ 2.5mm² • 1 x 24 AWG ÷ 11 AWG or 2 x 24 AWG ÷ 14 AWG
Multiwire with end splices	• 1 x 0.2 ÷ 4.0mm² or 2 x 0.2 ÷ 2.5mm² • 1 x 24 AWG ÷ 11 AWG or 2 x 24 AWG ÷ 14 AWG
Tightening torque	• 0.5 ÷ 0.6 Nm • 4.42 ÷ 5.31 lbf in
Aux Power, I/O's, Modbus	
Single wire	• 1 x 0.2 ÷ 2.5mm² or 2 x 0.2 ÷ 1.0mm² • 1 x 24 AWG...14 AWG or 2 x 23 AWG...17 AWG
Multiwire with end splices	• 1 x 0.25 ÷ 2.5mm² or 2 x 0.2 ÷ 1.5mm² • 1 x 23 AWG ÷ 14 AWG or 2 x 20 AWG ÷ 16 AWG
Tightening torque	• 0.5 ÷ 0.6 Nm • 4.42 ÷ 5.31 lbf in

5.3 Power supply



Connect the earth terminal to protection earth before connecting the supply voltage.



A marked and easily accessible current limiting switch in accordance with IEC 60947-2 has to be arranged in the vicinity of the device for turning off the power supply. Fusing should be 10 Amps or less and must be rated for the available voltage and fault current.

5.4 Inputs



All voltage measurement inputs must originate at circuit breakers or fuses rated 5 Amps or less. This does not apply to the neutral connector. You have to provide a method for manually removing power from the device, such as a clearly labeled circuit breaker or a fused disconnect switch in accordance with IEC 60947-2 or IEC 60947-3.

When using **voltage transformers** you have to ensure that their secondary connections never will be short-circuited.



No fuse may be connected upstream of the **current measurement inputs!**

When using **current-to-current transformers** (e.g. x/5 A) their secondary connectors must be short-circuited during installation and before removing the device. Never open the secondary circuit under load.




Devices with 3V 50/60Hz current inputs

- The current sensors including the conductor isolation must guarantee in total a reinforced or double insulation between the mains circuit connected on the primary side and the measuring inputs of the device.
- The connections ↓ of the current inputs are internally connected. If the 3V current sensors has to be earthed the common connection should be used for that.

Further hints

- The connection of the inputs depends on the configured system (connection type).
- In the connection diagrams on the next pages conventional current-to-current CTs (x/5 A) are used. If the device is equipped with 3V current inputs, the connection of the CTs has to be performed in the same way but using current-to-voltage sensors.
- In the connection diagrams on the next pages conventional voltage transformers are used. If a voltage transformer with **extra windings** for measuring the homopolar voltage is applied, connections should be as shown below.




 400 V LN / 693 V LL 50/60Hz - 600 V / CAT III



In order for the homopolar voltage U_{4C} to be measured, the item „Measure homopolar voltage“ must be set to „Yes“ in the settings of the measurement. This item is only available for 3-wire system types.

Single-phase AC mains



With current transformers


If current I_N does not need to be measured, the corresponding transformer can be omitted.

If voltage U_{NE} does not need to be measured, connection of PE can be omitted.

Direct current measurement

If only currents up to 7.5 A need to be measured no current transformers are required, but restrictions apply:


Warning: Maximum permissible rated voltage 300V to ground!



With current and voltage transformer

If current I_N or voltage U_{NE} does not need to be measured, the corresponding transformers can be omitted.


Three wire system, balanced load, current measurement via L1



With current transformer

If only currents up to 7.5 A need to be measured no current transformer is required, but restrictions apply:

Maximum permissible rated voltage 300V to ground (520V ph-ph)!



With current and voltage transformers


In case of current measurement via L2 or L3 connect the device according to the following table:

Terminals	↑ I1	I1 ↓	L1	L2	L3
Current meas. via L2	I2(S1)	I2(S2)	L2	L3	L1
Current meas. via L3	I3(S1)	I3(S2)	L3	L1	L2




By rotating the voltage connections the measurements U_{12} , U_{23} and U_{31} will be assigned interchanged!

Three wire system, unbalanced load, Aron connection




If only currents up to 7.5 A need to be measured no current transformers are required, but restrictions apply:



With current and 3 single-pole isolated voltage transformers

Four wire system, unbalanced load



With current transformers

If voltage U_{NE} does not need to be measured, connection of PE can be omitted.


If current I_N does not need to be measured, the corresponding transformer can be omitted.

Direct current measurement

If only currents up to 7.5 A need to be measured no current transformers are required, but restrictions apply:




Maximum permissible rated voltage
300V to ground (520V ph-ph)!



With current and voltage transformer

If current I_N does not need to be measured, the corresponding transformer can be omitted.

Split-phase ("two phase system"), unbalanced load



With current transformers

If voltage U_{NE} does not need to be measured, connection of PE can be omitted.


If current I_N does not need to be measured, the corresponding transformer can be omitted.

Direct current measurement

If only currents up to 7.5 A need to be measured no current transformers are required, but restrictions apply:



Maximum permissible rated voltage
300V to ground (600V ph-ph)!



With current and voltage transformer

In systems without a primary neutral conductor a voltage transformer with a secondary center tap can also be used.

5.5 Digital inputs


Usage of the (optional) digital inputs

- ▶ Triggering power quality recordings
- ▶ Trigger and release signal for monitoring functions
- ▶ Operating feedback of loads for operating time counters
- ▶ Registration of external state transitions

Passive inputs (external power supply with $24 \div 130\text{V DC}$ required)



The power supply shall not exceed 130 V DC !




5.6 Digital output


The (optional) relay output can be used with a voltage up to 250V AC/DC.

Usage as digital output

- ▶ Status of internal system warnings/alarms
- ▶ Pending over/under voltage/current event



5.7 Analog outputs




Connection to an analog input card of a PLC or a control system

The device is an isolated measurement device. The module outputs are galvanically connected, but the modules isolated from each other. To reduce the influence of disturbances shielded a twisted-pair cables should be used. The shield should be connected to earth on both opposite ends. If there are potential differences between the ends of the cable the shield should be earthed on one side only to prevent from equalizing currents.

Under all circumstances consider as well appropriate remarks in the instruction manual of the system to connect.

5.8 Modbus interface RS485

Via the optional Modbus interface measurement data may be provided for a superior system. However, the Modbus interface cannot be used for device parameterization.



1) One ground connection only.
This is possibly made within the master (PC).

Rt: Termination resistors: 120 Ω each
for long cables (> approx. 10 m)

Rs: Bus supply resistors,
390 Ω each

The signal wires (A, B) have to be twisted. GND (X) can be connected via a wire or via the cable shield. In disturbed environments shielded cables must be used. Supply resistors (Rs) have to be present in bus master (PC) interface. Stubs should be avoided when connecting the devices. A pure line network is ideal. You may connect up to 32 Modbus devices to the bus.

Modbus RTU enabled	no
Baud rate	115.2kBd
Parity	none parity
Stop bits	2
Device address	1

A proper operation requires that all devices connected to the bus have equal communication settings (baud rate, transmission format) and unique device addresses. Use the appropriate menu in the settings of communication.

If a Modbus/RTU interface is present but not required, communication may be disabled for security reasons.

The bus system is operated half duplex and may be extended to a maximum length of 1200 m without repeater.

5.9 Uninterruptible power supply (UPS)

The [battery pack](#) for the optional uninterruptible power supply is supplied separately. Please note that compared to the storage temperature range of the base unit the [storage temperature range](#) of the battery pack is restricted.

Ensure that devices with uninterruptible power supply are used in an environment in accordance with the [specification](#). The battery pack may not be recharged if the device is used outside this operating temperature range.


Due to aging the capacity of the battery decreases. To ensure a successful operation of the device during power interruptions the battery needs to be replaced every 3 up to 5 years.



Potential for Fire or Burning. Do not disassemble, crush, heat or burn the removed battery pack.

Replace battery pack with a [battery pack of the same type](#) only. Use of another battery may present a risk of fire or explosion.

5.10 GPS time synchronization



The device may be equipped with a connector for connecting a GPS receiver as a very accurate time synchronization source for the measurement device. The GPS receiver is used as outdoor antenna to process data from multiple GPS satellites simultaneously.

GPS receiver

Only use the receiver **Garmin GPS 16x-LVS** (article no. 181'131), offered as an accessory. This device is preconfigured by us and provides the required time information (sentences) without further configuration effort.

- Protection: IPx7 (waterproof)
- Operating temperature: -30...80°C
- Storage temperature: -40...80°C
- 1Hz pulse accuracy: 1µs
- Connector: RJ45



Choosing a mounting location


For a correct operation the GPS receiver requires data from at least 3 satellites at the same time. Therefore, position the receiver so that the clearest possible view of the sky and horizon in all direction is obtained. This can be on the roof of a building, at best without reception being restricted by other buildings or obstacles. Avoid mounting the receiver next to large areas of conductive material, as this may cause poor signal reception. It should be also not closer than 1 meter away from any other antenna.



If lightning protection is required, this must be provided by the user.

Mounting the GPS receiver

- The GPS receiver **Garmin GPS 16x-LVS** can be flush mounted by means of 3 M4 screws.
- 120° distribution over a circle of $\varnothing 71.6\text{mm}$
- Thread length max. 8mm. Using longer screws may damage the GPS receiver.



Connecting the GPS receiver



Never connect the RJ45 socket of the connecting cable directly to a network device such as a router or switch. These devices could be damaged.

The GPS receiver is plugged directly into the GPS connector. The connection cable has a length of 5 m. It may be extended using an RJ45 coupling and an Ethernet cable. The connection cable should not be laid in parallel to live conductors. Twisting or sharp kinking of the cable should be avoided.

Commissioning

- In the settings menu change time synchronization to „NTP server / GPS“
- Check the time synchronization status

> Service > Device information > Device state

Min/max values reset	Device version
Meter contents set/reset	Device license
Operating hours	Device state

Device information

Factory reset

Firmware update

Communication Tests

Device reboot

```
Interfaces -----
1) eth0
MAC:          00:12:34:1A:00:05
State:        Up
Link:         Yes
Speed:        100Mb/s
IP address:   192.168.62.142   [static]
Broadcast addr.: 192.168.63.255 [static]
Subnet mask:  255.255.248.0   [static]
Gateway addr.: 192.168.56.4   [static]

Name servers -----
DNS server 1: 192.168.56.55   [static]

Time sources -----
Source 1:      pool.ntp.org
Source 2:      Local clock
Source 3:      GPS

Time Synchronisation -----
synchronised to GPS at stratum 1
time correct to within 1 ms
polling server every 16 s

GPS Status -----
Number of satellites: 04
GPS quality: Differential fix
```

- The time synchronization can be restarted by switching the time synchronization off and on again.
- Time synchronization via GPS and NTP server may work in parallel. If both synchronization sources are available, the system uses the more accurate time source, which is normally GPS.



When connecting a GPS receiver for the first time or when it has been out of operation for a long time, it may take up to 1 hour for finding enough satellites for GPS receiver operation and thus for a reliable time synchronization.

5.11 IRIG-B time synchronization



The device may be equipped with a BNC connector for connecting the signal of an IRIG-B time server. The input supports IRIG-B004, unmodulated on TTL level.

6. Commissioning



Before commissioning you have to check if the connection data of the device match the data of the plant (see nameplate).

If so, you can start to put the device into operation by switching on the power supply and the measurement inputs.

6.1 Cyber Security policies



Activation of firewall

To protect data (sub billing, energy efficiency data, power monitoring data, grid power quality data, syslog data, timestamps) from unauthorized access, the IP-based whitelist shall be activated immediately during the first commissioning of the device.



Configuration interface

To protect the device configuration from unauthorized manipulation, the role-based access control system shall be activated and configured to define the rights of the individual roles.



Passwords

To protect the device configuration from unauthorized manipulation, the users defined in the role-based access control system shall use strong passwords. The access credentials must be safely stored (e.g. do not affix any stickers with access data to the device).



UI access to measurement data

To protect the measured and/or recorded data from unauthorized disclosure, the role-based access control system shall be activated and configured to define the access rights of the individual roles.



Modbus RTU interface

To protect data (sub billing, power monitoring data, grid power quality data) from unauthorized access, the Modbus RTU interface shall be deactivated if the interface is not used.



Modbus TCP interface

To protect data (sub billing, power monitoring data, grid power quality data) from unauthorized access, the Modbus TCP interface shall be deactivated if the interface is not used.



IEC 61850 interface

To protect the data (sub billing, power monitoring data, grid power quality data) from unauthorized access, do not connect the IEC 61850 interface if it is not used.



Scheduled export

To protect data from unauthorized access, the export interface of the device shall be deactivated if the interface is not used.



NTP interface

The NTP protocol does not offer any protection mechanisms against manipulation of data, e.g. by a “man in the middle” scenario. Therefore, if NTP synchronization is not used in the application, the time synchronization shall be disabled to protect the device against manipulation of time and timestamping information.



Syslog interface

The syslog protocol does not offer any protection mechanisms against manipulation of data, e.g. by a “man in the middle” scenario. Therefore, to protect the syslog data from unauthorized access, the syslog interface of the device shall be deactivated if the interface is not used.



External I/O data

External I/O data that is collected or emitted by the device is not subject by the device's protection mechanisms against disclosure, manipulation or loss of availability. It is the responsibility of the product user to take appropriate protective measures (e.g. physical access restriction).

6.2 Parametrization of the device functionality

A full parameterization of all functions of the device is possible directly at the device or via web browser. This assumes that user has the required access rights.

For security reasons, the security features “Users and Permissions” (RBAC) and “Web security” (HTTPS) are activated in the factory settings. So, before the device webpage can be displayed using https, you have to [install a root certificate](#), which is provided via our homepage. Once the certificate is downloaded to the local computer the certificate can be installed manually. Just double-click on the file, and install the certificate as a trusted root certification authority.


See: [Configuration \(7.5\)](#)

6.3 Installation check

The correct connection of the current and voltage inputs can be checked in two ways.

- a) **Sense of rotation check:** Using the sequence of the current and voltage phasors the sense of rotation is determined and compared to the configured one. The phase rotation indicator is arranged in the menu “Phasor diagram”.

Test requirement: Magnitude of all connected voltages at least 5% of nominal, magnitude of all connected currents at least 0.2% of nominal.



Possible results



Correct sense of rotation



Wrong sense of rotation








Missing phase or magnitude too small

- b) **Phasor verification:** The phasor diagram shows a technical visualization of the current and voltage phasors, using a counter-clockwise rotation, independent of the real sense of rotation.



The diagram is always built basing on the voltage of the reference channel (direction 3 o'clock)

 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.60</td><td>230.64</td><td>230.54</td><td>V</td></tr><tr><td>0.00</td><td>-119.97</td><td>120.03</td><td>*</td></tr><tr><td>85.97</td><td>86.03</td><td>85.86</td><td>A</td></tr><tr><td>-22.9</td><td>-21.7</td><td>-20.0</td><td>*</td></tr><tr><td>0.921</td><td>0.929</td><td>0.940</td><td>PF</td></tr></table>	L1	L2	L3		230.60	230.64	230.54	V	0.00	-119.97	120.03	*	85.97	86.03	85.86	A	-22.9	-21.7	-20.0	*	0.921	0.929	0.940	PF	Correct installation (expectation) - Voltage sequence in clock-wise order L1 → L2 → L3 ($0^\circ \rightarrow -120^\circ \rightarrow 120^\circ$) - Current sequence in clock-wise order L1 → L2 → L3 - Similar angle between voltage and current phasors in all phases (approx. -20°)
L1	L2	L3																								
230.60	230.64	230.54	V																							
0.00	-119.97	120.03	*																							
85.97	86.03	85.86	A																							
-22.9	-21.7	-20.0	*																							
0.921	0.929	0.940	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.58</td><td>230.63</td><td>230.53</td><td>V</td></tr><tr><td>0.00</td><td>-119.97</td><td>120.03</td><td>*</td></tr><tr><td>85.96</td><td>86.04</td><td>85.87</td><td>A</td></tr><tr><td>-22.9</td><td>158.4</td><td>-20.0</td><td>*</td></tr><tr><td>0.921</td><td>-0.930</td><td>0.940</td><td>PF</td></tr></table>	L1	L2	L3		230.58	230.63	230.53	V	0.00	-119.97	120.03	*	85.96	86.04	85.87	A	-22.9	158.4	-20.0	*	0.921	-0.930	0.940	PF	What's wrong? - Voltage sequence: L1 → L2 → L3 - Current sequence: L1 → L3 → L2; Current L2 is out of the expected sequence - Angle U-I: Angle between U_{L2} and I_{L2} is approx. 180° wrong Required correction Reversing the polarity of current I_2
L1	L2	L3																								
230.58	230.63	230.53	V																							
0.00	-119.97	120.03	*																							
85.96	86.04	85.87	A																							
-22.9	158.4	-20.0	*																							
0.921	-0.930	0.940	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.59</td><td>230.49</td><td>230.70</td><td>V</td></tr><tr><td>0.00</td><td>120.04</td><td>-119.99</td><td>*</td></tr><tr><td>85.97</td><td>86.02</td><td>85.86</td><td>A</td></tr><tr><td>-22.9</td><td>98.3</td><td>-140.0</td><td>*</td></tr><tr><td>0.921</td><td>-0.145</td><td>-0.766</td><td>PF</td></tr></table>	L1	L2	L3		230.59	230.49	230.70	V	0.00	120.04	-119.99	*	85.97	86.02	85.86	A	-22.9	98.3	-140.0	*	0.921	-0.145	-0.766	PF	What's wrong? - Voltage sequence: L1 → L3 → L2; L3 and L2 seems to be interchanged - Current sequence: L1 → L2 → L3 - Angle U-I: Angles between U_{L2} / I_{L2} and U_{L3} / I_{L3} do not correspond to the expectations Required correction Exchanging the connections of the voltages L2 and L3
L1	L2	L3																								
230.59	230.49	230.70	V																							
0.00	120.04	-119.99	*																							
85.97	86.02	85.86	A																							
-22.9	98.3	-140.0	*																							
0.921	-0.145	-0.766	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.58</td><td>230.49</td><td>230.68</td><td>V</td></tr><tr><td>0.00</td><td>120.04</td><td>-119.99</td><td>*</td></tr><tr><td>85.97</td><td>86.04</td><td>85.86</td><td>A</td></tr><tr><td>-22.9</td><td>-81.6</td><td>-140.0</td><td>*</td></tr><tr><td>0.921</td><td>0.145</td><td>-0.766</td><td>PF</td></tr></table>	L1	L2	L3		230.58	230.49	230.68	V	0.00	120.04	-119.99	*	85.97	86.04	85.86	A	-22.9	-81.6	-140.0	*	0.921	0.145	-0.766	PF	What's wrong? - Voltage sequence: L1 → L3 → L2; L3 and L2 seems to be exchanged - Current sequence: L1 → L3 → L2; Current L2 is out of the expected sequence - Angle U-I: Angles between U_{L2} / I_{L2} and U_{L3} / I_{L3} do not correspond to the expectations Required correction Exchanging the connections of the voltages L2 and L3 and reversing the polarity of the current input I_2
L1	L2	L3																								
230.58	230.49	230.68	V																							
0.00	120.04	-119.99	*																							
85.97	86.04	85.86	A																							
-22.9	-81.6	-140.0	*																							
0.921	0.145	-0.766	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.45</td><td>230.48</td><td>230.58</td><td>V</td></tr><tr><td>0.00</td><td>-120.02</td><td>119.98</td><td>*</td></tr><tr><td>85.96</td><td>86.00</td><td>85.86</td><td>A</td></tr><tr><td>-143.0</td><td>-141.6</td><td>-140.0</td><td>*</td></tr><tr><td>-0.798</td><td>-0.784</td><td>-0.766</td><td>PF</td></tr></table>	L1	L2	L3		230.45	230.48	230.58	V	0.00	-120.02	119.98	*	85.96	86.00	85.86	A	-143.0	-141.6	-140.0	*	-0.798	-0.784	-0.766	PF	What's wrong? - Voltage sequence: L1 → L2 → L3 - Current sequence: L3 → L1 → L2 - Angle U-I: The U-I angles do not correspond to the expectation, but are similar Required correction Cyclical exchange of the voltage connections: $L1 \rightarrow L3$, $L2 \rightarrow L1$, $L3 \rightarrow L2$. As an alternative the sequence of all currents may be changed as well (more effort required).
L1	L2	L3																								
230.45	230.48	230.58	V																							
0.00	-120.02	119.98	*																							
85.96	86.00	85.86	A																							
-143.0	-141.6	-140.0	*																							
-0.798	-0.784	-0.766	PF																							

6.4 Ethernet installation

6.4.1 Settings

Before devices can be connected to an existing Ethernet network, you have to ensure that they will not disturb the normal network service. The rule is:



None of the devices to connect is allowed to have the same IPv4/6 address than another device already installed.

The device supports both IPv4 and IPv6 communication. IPv4 communication is activated by default; IPv6 can be activated additionally via configuration.

IPv4 communication

Depending on the device version, there may be multiple involved network devices with different default IPv4 addresses.

Interface	Application	Default IPv4	Settings via menu
Standard 1	Configuration Device 1	192.168.1.101	Settings Communication Ethernet
Standard 2	Configuration Device 2 (double rack only)	192.168.1.102	Settings Communication Ethernet
IEC 61850	IEC61850 communication	192.168.1.111	Settings IEC61850 Ethernet

IPv6 communication

Depending on the device version, there may be multiple involved network devices with different default IPv6 addresses, once the IPv6 communication is activated.

Interface	Application	Default IPv6	Settings via menu
Standard 1	Configuration Device 1	fd2d:bb44:97f1:3976::1	Settings Communication Ethernet
Standard 2	Configuration Device 2 (double rack only)	fd2d:bb44:97f1:3976::2	Settings Communication Ethernet
IEC 61850	IEC61850 communication	fd2d:bb44:97f1:3976::B	Settings IEC61850 Ethernet

Network settings (Communication | Ethernet)

The following settings have to be arranged with the network administrator:

• IPv4/6: IP address	Must be unique , i.e. may be assigned in the network only once
• IPv4: Subnet mask	Defines how many devices are directly addressable in the IPv4 network. This setting is equal for all the devices. Examples
• IPv4/6: Gateway address	Is used to resolve addresses during communication between different networks. It should contain a valid address within the directly addressable network
• IPv4/6: DNS-Server x	Is used to resolve a domain name into an address, if e.g. a name (pool.ntp.org) is used for the NTP server. Further information
• IPv6: Prefix length	Is comparable to the subnet mask in IPv4 networks; it is the number of the leftmost bits of the site prefix which need to be identical for direct communication.
• Hostname	Individual designation for each device. Via the hostname the device can be uniquely identified in the network. Therefore for each device a unique name should be assigned.
• NTP-Server x	NTP servers are used as base for time synchronization

IPv4: Mode	Static ▼
IPv4: IP address	192.168.62.25
Subnet mask	255.255.248.0
IPv4: Gateway address	192.168.56.5
IPv4: DNS server 1	192.168.56.55
IPv4: DNS server 2	192.168.56.155
IPv6: Mode	Static ▼
IPv6: IP address	fd2d:bb44:97f1:3976::3
IPv6: Prefix length	64
IPv6: Gateway address	fd2d:bb44:97f1:3976::5:1
IPv6: DNS server 1	
IPv6: DNS server 2	
Host name	PQ5000Exxxxx
Clock synchronization	NTP server / GPS ▼
NTP server 1	pool.ntp.org
NTP server 2	

Network settings of Standard Ethernet interface

IP address	192.168.62.103
Subnet mask	255.255.248.0
Gateway address	192.168.56.5
DNS server 1	192.168.56.55
DNS server 2	192.168.56.155
Host name	PQ5000-IEC61850-RR
Clock synchronization	NTP server ▼
NTP server 1	pool.ntp.org
NTP server 2	

Network settings of IEC61850 interface

IPv4: Subnet mask

For a direct communication between device and PC both devices need to be in the same network when the subnet mask is applied:

Example 1	decimal	binary
IP address	192.168. 1.101	11000000 10101000 00000001 01100101
Subnet mask	255.255.255.224	11111111 11111111 11111111 11100000
	variable range	xxxxxx
First address	192.168. 1. 96	11000000 10101000 00000001 01100000
Last address	192.168. 1.127	11000000 10101000 00000001 01111111

► The device 192.168.1.101 can access directly the devices 192.168.1.96 ... 192.168.1.127


Example 2	decimal	binary
IP address	192.168. 57. 64	11000000 10101000 00111001 01000000
Subnet mask	255.255.252. 0	11111111 11111111 11111100 00000000
	variable range	xx xxxxxxxx
First address	192.168. 56. 0	11000000 10101000 00111000 00000000
Last address	192.168. 59.255	11000000 10101000 00111011 11111111

► The device 192.168.57.64 can access directly the devices 192.168.56.0 ... 192.168.59.255

IPv4: Mode >> DHCP

If a DHCP server is available, alternatively to the static mode „**DHCP**“ or „**DHCP, addresses only**“ can be selected. The device then gets all necessary information from the DHCP server. The difference between the two modes is that for “DHCP” also the DNS server address is obtained.

The settings obtained from the DHCP server can be retrieved locally via the service menu.



Depending on the settings of the DHCP server the provided IPv4 address can change on each reboot of the device. Thus, it's recommended to use the DHCP mode during commissioning only.

Time synchronization via NTP protocol

For the *time synchronization* of devices via Ethernet *NTP* (Network Time Protocol) is the standard. Corresponding time servers are used in computer networks, but are also available for free via Internet. Using NTP it's possible to hold all devices on a common time base.

Two different NTP servers may be defined. If the first server is not available the second server is used for trying to synchronize the time.

If a public NTP server is used, e.g. “pool.ntp.org”, a name resolution is required. This normally happens via a **DNS server**. So, the IP address of the DNS server must be set in the communication settings of the Ethernet interface to make a communication with the NTP server, and thus time synchronization, possible. Your network administrator can provide you the necessary information.

The time synchronization of the Standard interface can be performed via a [GPS receiver](#) or an [IRIG-B time server](#) as well.

TCP ports

The TCP communication is done via so-called ports. The number of the used port allows determining the type of communication. As a standard Modbus/TCP communication is performed via TCP port 502, NTP uses port 123. However, the port for the Modbus/TCP communication may be modified. You may provide a unique port to each of the devices, e.g. 503, 504, 505 etc., for an easier analysis of the communication traffic. Independent of these setting a communication via port 502 is always supported. The device allows at least 5 connections to different clients at the same time.

Firewall

Due to security reasons nowadays each network is protected by means of a firewall. When configuring the firewall you have to decide which communication is desired and which have to be blocked. The TCP port 502 for the Modbus/TCP communication normally is considered to be unsafe and is often disabled. This may lead to a situation where no communication between networks (e.g. via Internet) is possible.

6.4.2 Connection of the standard interface

The standard Ethernet interface is available via both a RJ45 connector on the front and on the back of the device.

- Interface: RJ45 socket, Ethernet 100BaseTX
- Mode: 10/100 MBit/s, full / half duplex, Auto-negotiation
- Protocols: http, https, Modbus/TCP, NTP

6.4.3 Connection of the IEC61850 interface

The two ports (RJ45) of the IEC61850 interface are available via back of the device. Both ports are equivalent and internally connected via a switch.

- Interface: RJ45 sockets, Ethernet 100BaseTX
- Mode: 10/100 MBit/s, full / half duplex, auto-negotiation
- Protocols: IEC61850, NTP

6.4.4 MAC addresses

For uniquely identifying Ethernet connections in a network, a unique MAC address is assigned to each connection. Compared to the IP address, which may be modified by the user at any time, the MAC address is static. The corresponding MAC addresses are given on the nameplate and may be displayed also via Service | Device information | Device state or IEC61850 status respectively.

6.5 Communication tests

Via the service menu on the device website you may check if the selected network structure is valid. The device must be able to reach the DNS server via gateway. The DNS server then allows resolving the URL of the NTP server to an IP address. The Standard Ethernet interface serves as interface for the communication tests.

- Ping: Connection test to any network device (initial: gateway address)
- DNS: Test, if the name resolution via DNS works (initial: URL of NTP server)
- NTP: Test, if the selected NTP-Server is in fact a time server (stratum x)
- SFTP: Test, if access to SFTP server works. A test file will be copied to the base directory of the server.

IPv4: Ping	192.168.56.5	Test
IPv6: Ping	fd2d:bb44:97f1:3976::5:1	Test
DNS	192.168.56.55 192.168.56.55	Test
NTP	pool.ntp.org	Test
SFTP server	tenserv.camillebauer.intra 22	
	data	
	sftpuser ****	Test

Testing NTP 'pool.ntp.org'

```
=====
server 176.10.99.200, stratum 2, offset -0.000689, delay 0.03264
server 162.159.200.123, stratum 3, offset 0.000510, delay 0.03139
server 84.16.67.12, stratum 1, offset -0.000664, delay 0.03560
server 5.148.175.134, stratum 2, offset -0.000103, delay 0.03174
23 Apr 14:29:06 ntpdate[5257]: adjust time server 84.16.67.12 offset -0.000664 sec
```

NTP server test

6.6 3G/4G Router

The optional 3G/4G router provides access to device data via the mobile communication network.

- Type: RUT240, LTE CAT4 Industrial Cellular Router
- Manufacturer: Teltonika
- Instructions available via: https://wiki.teltonika.lt/view/RUT240_Manual
- Default IP address for configuration: 192.168.1.1

SIM card

The router is delivered without SIM card. To insert a SIM card, you have to open the top cover of the rack housing by removing the 6 fixing screws first.



Ensure that all leads already connected to the device are free of potential before opening the cover!

The router is mounted on the left side wall (seen from the back).

1. Push the SIM holder button with the SIM needle
2. Pull out the SIM holder
3. Insert your SIM card into the SIM holder
4. Slide the SIM holder back into the router



6.7 IEC 61850 interface

The features of the optional IEC61850 interface are described in a separate document:


>> IEC61850 interface SINEAX AMx000/DM5000, LINAX PQx000, CENTRAX CUx000

This document is available via: <https://www.camillebauer.com/>

6.8 Simulation of analog / digital outputs

To check if subsequent circuits will work properly with output values provided by the device, using the service menu **Simulation** analog or digital outputs may be simulated. This is done by either entering analog output values or selecting a discrete state for the digital output.

Simulation is possible via webpage and as well via the local display.



Simulation of analog outputs via device webpage

6.9 Security system

There are several security mechanism implemented in the device which can be activated to provide a comprehensive access protection to all device data.

- The **role-based access control (RBAC)** system allows restricting the access to measured data, configuration settings and service functions to the rights granted to the present user. For access via website or local display this is done by reducing the available menus and / or providing only read access rights to specific services. For accessing data via external applications an API (Application Programming Interface) key is required, which needs to be implemented as a special user.
- **HTTPS** provides encrypted communication using TLS (Transport Layer Security)
- Via **client whitelist** access to the device can be restricted to specific clients with definable IP addresses
- **Communication blocking:** Communication services, such as Modbus/RTU, Modbus/TCP or SYSLOG are blocked by default and must be actively enabled via configuration. This way unauthorized access may be prevented and possible intruding points eliminated.
- **Audit log:** The device stores all security related messages in a separate list accessible via the service menu. The content of this list can also be transferred to a central log-server using the **SYSLOG** protocol for security auditing.

If the device is equipped with a display, restrictions defined in the security system also take effect when operating the device via the local display. It is also possible to restrict users to local access only.

6.9.1 RBAC management

Each access to device data via website, local display or external software applications can be comprehensively protected using the role-based access control (RBAC) system. This way, access to measured value information, the change of configuration parameters or the resetting / deletion of measurement data can be individually adapted to the role of the active user.

Note: All settings of the security system are stored in the device in encrypted form only; login credentials are never transmitted in plain text.

A maximum of 8 users is supported

- **3 pre-defined standard users**
 - *admin*: A user with administrator rights (Default setting password: „CBM_1234“)
 - *localgui*: The standard user for the local display. Its permissions determine what can be displayed or changed via the built-in display without a user having to log in.
 - *anonymous*: The standard user for access via device website. Its permissions determine what can be displayed or changed via the website without a user having to log in.
- **Up to 5 definable users or API keys**

Users or API keys may be created by each user with write access to the settings of the security system. In any case, each user with a web login can change the password of its own account.


Application programming interface (API) keys are used to allow applications to access device data via REST interface (communication via http/https protocol). Such keys are timely unlimited and have either read-only permissions, all permissions or all permissions except security.

The pre-defined administrator or any other user with full access rights to the settings of the security system can:

 - Change its own credentials (user name and/or password)
 - Change the credentials (user name and/or password) of any other user
 - Freely define the permissions of the standard users *localgui* and *anonymous*; both users are standard users without login credentials
 - Create new users up to a maximum of 5
 - Restrict users to local operation only (no login via website)


Adding users / API keys

In addition to the 3 predefined users a maximum of 5 users or API keys may be created. To do so, use “Add user / API key” and select the type of user to be created.



A dialog box titled "Add user/ API key" with a close button (X) in the top right corner. It contains three buttons: "Create user", "Create API key", and "Cancel".

Users: During password definition the requirements for a secure password are checked and the result is displayed. Each new user can be created based on the permission template of an already existing user, but all of these permissions may be changed later.



A form titled "Create user" with a close button (X) in the top right corner. It contains the following fields and controls:

- User name:
- Password: (with a red bar below it)
- Re-enter password:
- Permission template: (with a dropdown arrow)
- Buttons: "Save" and "Back"

On the right side, a list of password requirements is shown with green checkmarks:

- password length: 8 - 32
- different character types: 3/4
- uppercase [A-Z]
- lowercase [a-z]
- numbers [0-9]
- special characters

When defining / changing passwords the following restrictions must be considered:




- Password length 8 up to 32 characters
- At least three different types of characters must be used (uppercase, lowercase, numbers, special characters)



CAUTION: If login credentials (user name and / or password) of users with write access to the security system are changed, this information must be kept safe. For security reasons resetting the RBAC system can only be done at the factory, no backdoor is implemented.

API key: Along with the key name you have to define the permissions to be granted to the application using the key via REST interface. The resulting access rights cannot be changed afterwards.




A form titled "Create API key" with a close button (X) in the top right corner. It contains the following fields and controls:

- Key name:
- Permission template: (with a dropdown arrow)
- Buttons: "Save" and "Back"

Below the "Permission template" field, a list of permission options is shown:

- Read-only permissions
- All permissions except security
- All permissions

Once the API key is created it can be displayed using  “Show API key”



When the application wants to communicate via REST interface with the device, it has to provide the API key and the session token via the cookie field in the request header, e.g.:

Cookie:

```
AccessToken=eyJhbGciOiJIUzI1NiIsInR5cCI6IkpXVCJ9.eyJhdWQiOiI0MjlmZiIsImhhdCI6MTU3OFE4ODY3ODcwc3VlIjoiW0FQSV1BY2Nlc3Nub2t1bilsInR4bGl6IiMyOSJ9.HTbWTu7h57ctuLwFPxiOy3SGmmj5At1la0Njk-ID4JA
sessionToken={5d1ca47c-8d38-4a08-85d5-fefbd941fa20}
```

Further information is provided in the document “http interface SINEAX PQx000”

Assignment of user rights

The assignment of the user rights granted for operation is done via the menu Settings | Security system | Users and permissions:


Users and Permissions		enabled						
		Add user/ API key						
		admin	localgui	anonymous	operator1	operator2	operator3	[API]AccessToken
Local account (no weblogin)		☐	☒	☐	☐	☐	☐	☐
 Instantaneous values								
 Energy								
 Harmonics								
 Phasor diagram								
 Waveform								
 Events								
 PQ statistic								
 Service								
Reset values								
Reset/Update device								
Audit Log								
Use IO simulation								
 Settings								
Basic device settings								
Measurement								
Communication								
Security system								

Overview of the access rights of each possible user

-  Measurements or settings can be displayed
-  Measurements or settings cannot be displayed
-  Settings can be changed
-  Settings cannot be changed
-  Field not selectable
-  Change a user's login credentials

6.9.2 User log in / out via website

a) If “anonymous” has no granted permissions

Via website	Remarks
	1) Enter user name and password 2) Press <ENTER> or select “Login” If successful, depending on the permissions of the user logged in, the appropriate website is displayed

b) If “anonymous” has granted permissions



Via website	Remarks
	1) Click on the symbol  2) Enter user name and password. On first login use the default settings admin / CBM_1234. 3) Press <ENTER> or select “Login” If successful, depending on the permissions of the user logged in, the appropriate website is displayed

c) If another user is already logged in


Via website	Remarks
	Log out the current user by selecting “Logout” 1) Click on the symbol  2) Enter user name and password 3) Press <ENTER> or select “Login” If successful, depending on the permissions of the user logged in, the appropriate website is displayed

6.9.3 User log in / out via local display



a) If “localgui” has no granted permissions

Locally	Remarks
	No information is displayed on the screen. Press <ESC> to enter the login screen.
	1) Press <OK> to enter the user name 2) Proceed to password using ▼ 3) Press <OK> to enter the password 4) Proceed to Login and press <OK> If successful, depending on the permissions of the user logged in, the appropriate menu is displayed.


b) If localgui has granted permissions

Locally	Remarks
	Repeatedly press <ESC> until the login screen is displayed. 1) Press <OK> to enter the user name 2) Proceed to password using ▼ 3) Press <OK> to enter the password 4) Proceed to Login and press <OK> If successful, depending on the permissions of the user logged in, the appropriate menu is displayed

c) If another user is already logged in

Locally	Remarks
	Repeatedly press <ESC> until the login screen is displayed. Log out the current user by selecting “Logout” Depending on the permissions of localgui either a menu or the lock symbol is displayed
	Repeatedly press <ESC> until the login screen is displayed. 1) Press <OK> to enter the user name 2) Proceed to password using ▼ 3) Press <OK> to enter the password 4) Proceed to Login and press <OK> If successful, depending on the permissions of the user logged in, the appropriate menu is displayed.

6.9.4 Whitelisting clients



It is possible to define a list of IPv4 and/or IPv6 addresses of up to 10 clients allowed to have access to the device. All other clients will be blocked. Enable the whitelist via the *Settings* of the *Security system* in the item *Whitelist*.




If a DHCP server is used in the system, clients may get different IP addresses on each startup, losing this way access to the device.

If a device is no longer accessible you can reset its IP address (LAN), deactivating the whitelist at the same time.

6.9.5 Secure communication using https


HTTPS protocol provides encrypted communication using TLS (Transport Layer Security). Such as bidirectional encryption of communications between a client and server protects against eavesdropping and tampering of the communication, by creating a secure channel over an insecure network.

Before HTTPS communication can be used, a root certificate needs to be installed. The user can either use a Camille Bauer certificate (default setting) or its own customer certificate. This may be changed when defining the Settings of the Security system.



Camille Bauer certificate

The certificate can directly be downloaded from the device via **Certificates and keys**.



Name	Issuer	Not valid before	Not valid after
Camille Bauer SINEAX LINAX CENTRAX Root CA	Camille Bauer SINEAX LINAX CENTRAX Root CA	21.11.2024, 10:42:53	14.11.2054, 10:42:53

Details

Name: Camille Bauer SINEAX LINAX CENTRAX Root CA
Issuer: Camille Bauer SINEAX LINAX CENTRAX Root CA
Not valid before: 2024-11-21T09:42:53.000Z
Not valid after: 2054-11-14T09:42:53.000Z
Serial number: 18B5CEFD64D1386816617FE1F86B793CB318A210

Download


Ok

Alternatively, the certificate can also be obtained from the Camille Bauer website:

- <https://www.camillebauer.com/pq5000r-en>.


The certificate must be installed before starting the browser.

Once the certificate is downloaded to the local computer the certificate can be installed manually. Just double-click on the file. **Install certificate**, then select **Place all certificates in the following store**, **Browse** and select **Trusted Root Certification Authorities**. **Finish** the Import Wizard.




The imported certificate is valid for all devices of the PQ, AM, DM and CU series.


Agree to install the certificate if the below security warning appears:



Upload the customer server certificate and the private key via *Certificates and keys* under *Certificates for TLS*.



The uploaded certificate can then be selected when activating the HTTPS communication via *Settings* of the *Security System* in the menu *Web Security*.




You may use https communication also by ignoring any browser warning and establishing an **unsecure** connection to the device. However, for security reasons you should not work like that in the intended network environment.

6.9.6 Audit log (SYSLOG)

Security related events, such as ...

- a computer establishing a connection to the device
- a user logged in /out
- a failed login attempt
- each changing of the device configuration
- the view of the security log by a user
- etc.

are logged in a security log accessible via the service menu.



Time	PID	Priority	IP address	User name	Message
17.01.2020, 09:35:59	cb-gui[2126]	Notice	192.168.57.65:54375	admin	User reviewed latest security event log (allow)
17.01.2020, 09:35:54	cb-gui[2126]	Notice	192.168.57.65:54375	admin	User logged in successfully
17.01.2020, 08:33:30	sshd[2436]	Info	192.168.58.58:11348	root	Accepted password ssh2
17.01.2020, 08:31:18	sshd[2420]	Info	192.168.58.58:11318	root	Accepted password ssh2
17.01.2020, 08:31:17	sshd[2416]	Info	192.168.58.58:11315	root	Accepted password ssh2
17.01.2020, 08:24:56	cb-gui[2126]	Info	192.168.57.65:53539	admin	User logged out successfully
17.01.2020, 08:04:45	cb-gui[2126]	Notice	192.168.57.65:53387	admin	User reviewed latest security event log (allow)
17.01.2020, 08:02:59	cb-pq3000[2120]	Notice			The device was power off on Fri Jan 17 07:57:31 2020
17.01.2020, 08:02:59	cb-pq3000[2120]	Notice			The device was power on Fri Jan 17 07:57:31 2020
17.01.2020, 08:02:59	cb-pq3000[2120]	Notice			Firmware update was on Fri Jan 17 08:01:07 2020


Example of a security log: The severity of each message is shown in a color code, which may also serve as filter criteria.

Each entry into this list may, if activated, also be transferred to a central log-server using the **SYSLOG** protocol for security auditing. This transfer may be performed based on UDP, TCP or TLS. The settings of the Syslog server are available via Settings | Communication | Syslog server:

Syslog protocol	TCP
Host	tenserv.camillebauer.com
Port	514

7. Operating the device

7.1 Operating elements



The operation of the device is performed by means of 6 keys:

- 4 keys for **navigation** (◀, ▲, ▼, ▶) and for the selection of values
- OK for **selection** or confirmation
- ESC for **menu display**, terminate or cancel

The **function** of the operating keys changes in some measurement displays, during parameterization and in service functions.

7.2 Selecting the information to display



Information selection is performed via menu. Menu items may contain further sub-menus.

Displaying the menu

Press **ESC**. Each time the key is pressed a change to a higher menu level is performed, if present.

Displaying information



The menu item chosen using ▲, ▼ can be selected using **OK**. Repeat the procedure in possible submenus until the required information is displayed.

Return to measurement display

After 2 min. without interaction the menu is automatically closed and the last active measurement display is shown.

7.3 Measurement displays and used symbols


For displaying measurement information the device uses both numerical and numerical-graphical measurement displays.

Examples	Measurement information
	4 measured quantities
	Graphical measurement display Further examples

Incoming / outgoing / inductive / capacitive

The device provides information for all four quadrants. Quadrants are normally identified using the roman numbers I, II, III and IV, as shown in the adjacent graphic. Depending on whether the system is viewed from the producer or consumer side, the interpretation of the quadrants is changing: The energy built from the active power in the quadrants I+IV can either been seen as delivered or consumed active energy.

By avoiding terms like incoming / outgoing energy and inductive or capacitive load when displaying data, an independent interpretation of the 4-quadrant information becomes possible. Instead the quadrant numbers I, II, III or IV, a combination of them or an appropriate graphical representation is used. You can select your own point of view by selecting the reference arrow system (load or generator) in the settings of the measurement.




Used symbols


For defining a measurement uniquely, a short description (e.g. U_{1N}) and a unit (e.g. V) are often not sufficient. Some measurements need further information, which is given by one of the following symbols or a combination of these symbols:

	Mean-value	ΣHT	Meter (high tariff)
	Mean-value trend	ΣLT	Meter (low tariff)
	Bimetal function (current)	$\blacktriangle$	Maximum value
	Energy quadrants I+IV	$\blacktriangledown$	Minimum value
	Energy quadrants II+III	TRMS	True root-mean-square value
	Energy quadrants I+II	RMS	Root-mean square value (e.g. fundamental or harmonic content only)
	Energy quadrants III+IV	(H1)	Fundamental component only
I, II, III, IV	Quadrants	$\emptyset$	Average (of RMS values)


Examples



Meters with tariff and quadrant information



User mean values: Last values



User mean values: Trend

7.4 Resetting measurement data

- **Minimum and maximum values** may be reset during operation. The reset may be performed in groups using the service menu.

Group	Values to be reset
1	Min/max values of voltages, currents and frequency
2	Min/max values of Power quantities (P,Q,Q(H1),D,S); min. load factors
3	Min/max values of power mean-values, bimetal slave pointers and free selectable mean-values
4	Maximum values of harmonic analysis: THD U/I, TDD I, individual harmonics U/I
5	All imbalance maximum values of voltage and current

- **Meter contents** may be individually set or reset during operation using the service menu
- **Recorded logger data** can be individually reset via the service menu "Logger values reset". This makes sense whenever the configuration of the quantities to record has been changed.

7.5 Configuration

7.5.1 Local configuration at the device

With the exception of the security system a full parameterization of the device can be performed via the menu “Settings”.

Modifications will not take effect before the user accepts the query “Store configuration changes” when leaving the settings menu. Changings in the “Country and clock” menu have immediate effect (e.g. a different operating language is used), but nevertheless must be stored.

- **Country and clock:** display language, date format, time zone, clock synchronization, time/date
- **Display:** Refresh rate, brightness, screen saver
- **Communication:** Settings of the communication interfaces [Ethernet](#) and [Modbus/RTU](#). In addition, a [SFTP server](#) may be defined, to push user definable data files to.
- **Measurement:** System type, sense of rotation, nominal values of $U / I / f$, sampling, [reference arrow system](#) etc.

Hints

- *U / I transformer: The primary to secondary ratio is used only for converting the measured secondary to primary values, so e.g. 100 / 5 is equivalent to 20 / 1. The values do not have any influence on the display format of the measurements.*
- *Nominal voltage: Is used as the 100% reference for monitoring power quality events and corresponds to the declared input voltage U_{din} in accordance with IEC 61000-4-30*
- *Nominal current: Rated current the system is designed for*
- *Max demand load current: Reference for scaling the harmonic content [TDD](#) of the currents*
- *Max short circuit current: Is used is used for calculating the limits for current harmonics and TDD when testing IEEE 519 compliance*
- *Maximum primary values U/I: These values are used only for fixing the display format of the measurements. This way the resolution of the displayed values can be optimized, because there is no dependency to installed transformers.*
- *Synchronous sampling: yes=sampling is adjusted to the measured system frequency to have a constant number of samplings per cycle; no=constant sampling based on the selected system frequency*
- *Reference channel: The measurement of the system frequency is done via the selected voltage or current input*
- *Voltage neutral-earth / neutral current: These quantities may be measured or calculated. Of course, if “measured” is selected the appropriate terminals must be connected.*
- **Power quality:** Definition of parameters for monitoring the PQ events voltage dip, voltage interruption, voltage swell, rapid voltage changes and mains signalling voltage. User-specific limits for the evaluation of the PQ statistic can also be set.
- **Mean-values | standard quantities:** Interval time and synchronization source for the predefined power mean values
- **Mean-values | user defined quantities:** Up to 12 quantities (10 pre-defined, 2 selectable) for determining their mean-values and selection of their common interval and synchronization source
- **Bimetal current:** Selection of the response time for determining [bimetal currents](#)
- **Meters | Standard meters:** Tariff switching ON/OFF, [meter resolution](#)
- **Meters | User defined meters:** Base quantities ($P_x, Q_x, Q(H1)_x, S_x, I_x$), Tariff switching ON/OFF, [meter resolution](#)
- **Meters | Meter logger:** Selection of the reading interval
- **Limit values:** Selection of up to 12 quantities to monitor, [limit values](#) for ON/OFF, event text ¹⁾
- **Digital inputs:** Debounce time (minimum pulse width) and polarity of the optional [digital inputs](#)
- **Monitoring functions:** Definition of up to 8 [monitoring functions](#) with up to three inputs each, delay times for ON / OFF and event text ¹⁾
- **Summary alarm:** Selection of the monitoring functions to be used for triggering the [summary alarm](#) and selection of a possible source for resetting

- **Operating hours:** Selection of the running condition for up to 3 operating hour counters
- **Digital output:** Definition of the state source for the optional [digital output](#)
- **Analog outputs:** Type of output, source, transfer characteristic, upper/lower range limit
- **Security system:** Definition of the [security system](#) (RBAC, https, whitelist)
- **Device tag:** Definition of different texts ¹⁾ mainly used for report generation, such as device tag, document title, device location and others.
- **Data export scheduler:** Via [website](#) you can setup tasks to be performed regularly. Each time such a task is running, it creates a data file to be transferred to a SFTP server and/or to be stored locally on the device. Via local configuration tasks can be enabled or disabled only.

¹⁾ In user-defined event and description texts all Unicode characters (UTF8) are allowed with the exception of the following:

- ASCII control characters (0x00 - 0x1F)
- The quotation mark " (0x22)
- The character & (0x26)
- The apostrophe ' (0x27)
- The asterisk * (0x2A)
- The slash / (0x2F)
- The colon : (0x3A)
- The «less than» character < (0x3C)
- The «bigger than» character > (0x3E)
- The question mark ? (0x3F)
- The backslash \ (0x5C)
- The vertical line | (0x7C)

At the device itself only «normal» characters of the ASCII character set can be input. Entering language specific character or texts is possible via the website of the device only.

7.5.2 Configuration via web browser


	It's recommended to use either Google Chrome or Firefox as browser.
	Internet Explorer works with limitations only (partly missing texts, firmware update not possible)

As soon as the [root certificate](#) is installed you can start the browser and display the device website using:

- IPv4 communication: https://IPv4_addr, e.g. <https://192.168.1.101>
- IPv6 communication: [https://\[IPv6_addr\]](https://[IPv6_addr]), e.g. [https://\[fd2d:bb44:97f1:3976::1\]](https://[fd2d:bb44:97f1:3976::1])

This request works only if device and PC are in the same network segment. Depending on the device version, there may be multiple network devices with different [default IP addresses](#).

Device website using Google Chrome




 192.168.1.101/webgui/index.html#	The locker symbol shows that a secure connection is established
	There are three information here: • The SD-card is present and stores data • A network connection is established • No user with credentials has logged in so far. Information granted to the default user 'anonymous' is displayed.



Via WEB-GUI you can make the same settings as via the [local GUI](#) using the Settings menu. In addition, it is possible to setup the [security system](#) and the [Data export scheduler](#) and to enter user-defined event or description texts in UTF8 format.

In addition, it is possible to setup the and to setup the. Possibly modifications needs to be saved in the device, before all parameters have been set. In such a case the following message appears:




If this request is not confirmed, unsaved modifications of the present device configuration may get lost.

Loading / saving configuration files

The user can save the present device configuration on a storage media and reload it from there. The storage or load procedure varies depending on the used browser.



The settings of the security system are not part of the configuration file. There is no possibility to transfer security settings from one device to another.

	Loading a configuration file from a storage media The configuration data of the selected file will be directly loaded into the device. The values in the WEB-GUI will be updated accordingly. Normally devices differ in the settings of network and Modbus parameters and device name. Thus when loading the file you can choose, whether the appropriate settings of the device should be retained or overwritten by the values in the file to be uploaded. 
	Storing the current parameter settings of the WEB-GUI into the device
	Saving the device configuration to a storage media Attention: Modifications in the WEB-GUI, which haven't been stored in the device, will not be written to the storage media.

7.6 PQ monitoring

Power quality monitoring provides both a statistical evaluation, allowing an assessment of compliance with standards (e.g. EN 50160) or supply contracts, as well as records of events in the grid (e.g. power voltage dip). This facilitates the analysis of causes and effects. Conformity reports may also be created directly via the website of the device.

7.6.1 PQ events

The device monitors all voltage events in accordance with IEC 61000-4-30. The default values of the trigger thresholds correspond to the common values of the EN 50160 for a public low-voltage distribution system, but can be changed by the user to individual needs.

In addition to the requirements of IEC 61000-4-30 the device can monitor current swells, voltage unbalance and frequency anomalies.

Monitored events	Threshold	Hysteresis	Reference value
Voltage dip	90%	2%	Nominal voltage
Voltage interruption	10%	2%	
Voltage swell	110%	2%	
Rapid voltage change	6%	50% ¹⁾	
Homopolar voltage	50%	2%	
Current swell	120%	2%	Nominal current
Frequency anomaly	lower: 99% upper: 101%	0.5%	Nominal frequency
Digital input events ²⁾	Any state change		

¹⁾ Related to the respective threshold

²⁾ For device versions with digital inputs, the states of these inputs during the event are displayed along with the values of voltages and currents. State changes of digital inputs can also trigger an event recording



The device does not verify the user-defined event parameters. If these values are not plausible, events may be not recognized correctly or misclassified. In particular, the trigger threshold for RVC events should not be greater than half of the difference of the threshold values of voltage swell and voltage dip.

Recordings

If any of the above events occurs, the device records both the half-cycle RMS values and the samples of all voltage and current channels. The event recording times can be configured using the menu *Settings* | *Power quality* | *Event recording*:

RMS(1/2): Pretrigger recording	s	1.000
RMS(1/2): Event recording (max.)	s	180.000
Samples: Pretrigger recording	s	1.000
Samples: Event recording	s	4.000

Possible recording times

≤1.0s

≤180.0s

≤1.0s

≤5.0s

Note: The event recording time “RMS(1/2): After triggering” is a maximum recording time. It is reduced to the real event duration + 1s, if the event duration is shorter than the configured time.

Recorded PQ events can be [visualized](#) either via the local display or the webpage of the device.

Mains signalling voltage

The device monitors mains signalling voltages, which are transmitted in the supply system for load control purposes, and records them as events. Typically these are ripple control signals. The user can define the frequency of the signalling voltage, the threshold and hysteresis (related to the nominal voltage) as well as the recording duration in multiples of the measurement interval of 10/12 cycles. The recording duration must not exceed 120s. The ripple control frequency is typically below 3 kHz and can be requested from the local energy provider.

Reference channel		U1 ▼
Ripple control frequency	Hz	375
Trigger threshold	%	2
Trigger hysteresis	%	1
Rec. duration (10/12 cycles)	#	50

7.6.2 PQ statistic

Power quality (PQ) is assessed by a comparison between the PQ parameters measured by the device and the limits of a contract agreed upon. The assessment period is usually at least one week to take into account possible variations between weekdays and weekends.

Via its website the device can perform an assessment of the measured PQ parameters in accordance with the following standards:

- EN 50160 (2010), low voltage, interconnected systems
- EN 50160 (2010), low voltage, island systems
- EN 50160 (2010), medium voltage, interconnected systems
- EN 50160 (2010), medium voltage, island systems
- EN 50160 (2010), high voltage, interconnected systems
- EN 50160 (2010), high voltage, island systems
- IEC 61000-2-2 (2002), public low voltage systems
- IEC 61000-2-4 (2002), industrial and non-public systems up to 35 kV, class 1
- IEC 61000-2-4 (2002), industrial and non-public systems up to 35 kV, class 2
- IEC 61000-2-4 (2002), industrial and non-public systems up to 35 kV, class 3
- IEC 61000-2-12 (2003), public medium voltage systems
- GB/T
- IEEE 519
- User specific limit sets

The assessment of the PQ statistic is shown in the chapter [Data recording | PQ statistic](#), including the creation of conformity reports.

Recorded PQ parameter groups

Measurement	Averaging time	Applied limits
Power frequency	10 s	<i>The applied limits and time conditions of the preset standards can be seen via the device website.</i> <i>They can be displayed via the following menu:</i> <i>Settings</i> <i> Power Quality</i> <i> Custom threshold limits</i> <i> (Standard)</i>  <i>Within the same menu user data sets with specific limits and evaluation criteria can be defined</i>  <i>User specific data sets can also be deleted again.</i>
Voltage magnitude	10 min.	
Flicker P _{st}	10 min.	
Flicker P _{lt}	2 h	
Mains signalling voltage	3 s	
Supply voltage unbalance	10 min.	
THDS of voltages	10 min.	
Voltage harmonics	10 min.	
Voltage interharmonics	10 min.	
Current magnitude	10 min.	
Current unbalance	10 min.	
Current harmonics	10 min.	
Current interharmonics	10 min.	

7.6.3 Provision of PQ data

The device can create PQ related data, such as PQ events or PQ statistic, using the standard format PQDIF (**P**ower **Q**uality **D**ata **I**nterchange **F**ormat). The automatic or event-driven generation of such files can be defined via the [Data export scheduler](#) in the Settings menu. By default, daily PQDIF will be created periodically after midnight for the past day and provided in a hierarchical time structure (year, month, day) for [download](#).

PQDIF files may also be generated manually via web interface. This may be done either for the present day (including data since midnight) or contiguous, selectable time ranges of up to 7 days. The file(s) is added in the time structure of the end day. Days with existing files are marked with a red dot.

> Service > Local data storage > Generate PQDIF

Simulation

Min/max values reset

Meter contents set/reset

Logger values reset

Operating hours

Device information

Local data storage

Factory reset

Audit Log

Firmware update

Communication Tests

Device reboot

Generate PQDIF

Download data

< March 2021

Mo	Tu	We	Th	Fr	Sa	Su
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	1	2	3	4
5	6	7	8	9	10	11

Generate PQDIF

Start PQ data generation

> Found 10 events on Wed Mar 24 2021

> Event 'Voltage dip' at 2021-03-24T13:45:23.549+01:00

> Event 'Voltage dip' at 2021-03-24T13:48:16.953+01:00

> Event 'Voltage dip' at 2021-03-24T13:48:53.748+01:00

> Event 'Voltage dip' at 2021-03-24T13:50:05.536+01:00

> Event 'Voltage dip' at 2021-03-24T13:51:05.008+01:00

> Event 'Voltage dip' at 2021-03-24T13:51:44.569+01:00

> Event 'Voltage dip' at 2021-03-24T13:54:33.099+01:00

> Event 'Voltage dip' at 2021-03-24T14:01:54.240+01:00


> Event 'Voltage dip' at 2021-03-24T14:07:14.922+01:00

> Event 'Voltage dip' at 2021-03-24T14:08:48.014+01:00

> PQ data stored in file 'PQ1000-1216324003_20210324.pqd'

> PQ data generation done

If for the selected time range PQDIF files are already stored in the device the below warning will be displayed.



7.7 Alarming

The device supports an alarming concept independent of power quality events. Depending on the user requirements, simple or more advanced monitoring tasks may be realized. The most important objects are limit values on base quantities, monitoring functions and the summary alarm.

7.7.1 Limit values on base quantities

Limit value 1 2016-06-20 17:52


Monitored quantity	Voltage U1N
Limit for ON	200
Limit for OFF	205
Event text	Low voltage U1N
List entry	Alarms

Using limit values either the exceeding of a given value (upper limit) or the fall below a given value (lower limit) is monitored.

Limits values are defined by means of two parameters: Limit for ON / OFF. The hysteresis corresponds to the difference between these two values.


Both state transitions OFF→ON and ON→OFF can be recorded as event or alarm in the appropriate lists.

Upper limit: $\text{Limit for ON} \geq \text{Limit for OFF}$



- ▶ The limit value becomes active (1) as soon as the limit for ON state is exceeded. It remains active until the associated measured quantity falls below the limit for OFF state again.
- ▶ The limit value is inactive (0) if either the limit for ON is not yet reached or if, following the activation of the limit value, the associated measured quantity falls below the limit for OFF state again.

Lower limit: $\text{Limit for ON} < \text{Limit for OFF}$



- ▶ The limit value becomes active (1) as soon as the associated measured quantity falls below the limit for ON state. It remains active until the associated measured quantity exceeds the limit for OFF state again.
- ▶ The limit value is inactive (0) if either the associated measured quantity is higher than the limit for ON state or if, following the activation of the limit value, it exceeds the limit for OFF state again.



If the limit for ON state and the limit for OFF state are configured to the same value, the limit value will be treated as an upper limit value without hysteresis.

Limit value states can:

- ... be used as logic input for a monitoring function
- ... be recorded as event or alarm in the appropriate lists on each state transition


7.7.2 Monitoring functions

By means of monitoring functions the user can define an extended condition monitoring, e.g. for triggering an over-current alarm, if one of the phase currents exceeds a certain limit value.

The states of all monitoring functions

...will be shown in the alarm list ("Events" via main menu)

...build the [summary alarm](#) state



Logic inputs

Up to three states of limit values, logic inputs or other monitoring functions. Unused inputs will automatically be initialized in a way that they do not influence the output.

Logic function

For the logical combination of the inputs the function AND, NAND, OR, NOR, DIRECT and INVERT are available. These logical functions are described in [Appendix C](#).

Delay time on

The time a condition must be present until it is forwarded

Delay time off

Time to be waited until a condition, which is no longer present, will be released again

Description

This text will be used for visualization in the alarm list

List entry


- *Alarm / event*: Each state transition will be recorded in the appropriate list
- *none*: No recording of state transitions

Possible follow-up actions

- Visualization of the present state in the alarms overview
- Combining the states of all monitoring functions to create a [summary alarm](#)
- Recording of state transitions as alarm or event in the appropriate lists

7.7.3 Summary alarm

The summary alarm combines the states of all [monitoring functions](#) MFx to a superior alarm-state of the overall unit. For each monitoring function you may select if it is used for building the summary alarm state. If at least one of the used functions is in the alarm state, the summary alarm is also in the alarm state.




Alarm display ((🔔))

The symbol arranged in the status bar signals if there are active alarms or not.

Acknowledgment: By acknowledging the summary alarm, the user confirms that he has recognized that an alarm state is present. The acknowledgment is done automatically as soon as the user selects the alarm list to be displayed locally or via web browser or if the alarm state no longer exists. By acknowledging only the flashing of the alarm symbol stops, the symbol itself remains statically displayed until none of the monitoring functions is in the alarm state.

Alarm state display (via menu Events | Alarms)



This display serves to identify the source of the summary alarm.

7.8 Data recordings

The device stores long-term recordings of measurement progressions, events and PQ statistics. Some of these recordings provide predefined contents; some is based on user-defined contents.

In addition, file-based information may be periodically created using the [data export scheduler](#). This data may be saved internally and / or send securely to a SFTP server.

In general, recordings are done in endless mode. The oldest data will be deleted, as soon as the associated memory is used for more than 80%.

Group	Data type	Request	
Periodic data	- Mean-values versus time, predefined (5) and user-specific (12) quantities - Periodic meter readings, predefined (4) and user-specific (12) quantities	 Energy	- Mean value logger - Meter logger
Events	In form of a logbook with time information: - Event list: Every state transition of monitoring functions or limit values, classified as event - Alarm list: Every state transition of monitoring functions or limit values, classified as alarm	 Events	Event and alarm list
PQ events	The occurrence of PQ events will be registered in the PQ event list. By selecting the entries for voltage events: - the course of the RMS values of all U/I - the wave shape of all U/I during the disturbance will be displayed	 Events	PQ events and Mains Signalling
Security events	Security log (SYSLOG)	 Service	Log of the security system
PQ statistic	For a selectable weekly interval, the evaluation of the PQ statistic is displayed, depending on the selected standard. In addition, daily trends of the monitored PQ variables can be displayed. By means of PQ-Easy Report, conformity reports can be created directly via website.		

7.8.1 Periodic data

Configuration of the periodic data recording

Via the settings menu the user can individually configure:


- The averaging interval of the standard mean-values P(I+IV), P(II+III), Q(I+II), Q (III+IV), S
- The averaging interval of up to 12 user-defined mean-values
- The reading interval of standard meters P(I+IV), P(II+III), Q(I+II), Q (III+IV)
- The reading interval of up to 12 user-defined meters

The recording of all mean-values and meters is started automatically on device start. The recording of the mean-values is done when the appropriate averaging interval expires.

Displaying the chronology of the mean values

The chronology of the mean values is available via the menu **Energy** and is divided in two groups:

- Pre-defined power mean values
- User-defined mean values




Selection of the mean values group



The selection of the mean-value quantity to display can be performed via choosing the corresponding register. Three different kind of displays are supported:

- Daily profile: Hourly mean-values will be shown, independently of the real averaging time
- Weekly profile
- Table: Listing of all acquired mean-values in the sequence of the real averaging interval

The graphical representation allows comparing directly the values of the previous day or week.



By selecting the bars you may read the associated values:

- Mean-value
- Min. RMS value within the interval
- Max. RMS value within the interval



Weekly display



Weekly display: Reading

#	time	mean	min(interval)	max(interval)
1	14.06.2016, 14:33:00.000	79.89 kW	65.75 kW	109.42 kW
2	14.06.2016, 14:32:00.000	93.65 kW	74.95 kW	125.97 kW
3	14.06.2016, 14:31:00.000	86.42 kW	74.48 kW	104.69 kW
4	14.06.2016, 14:30:00.000	80.17 kW	67.36 kW	106.59 kW
5	14.06.2016, 14:29:00.000	88.62 kW	75.01 kW	111.77 kW
6	14.06.2016, 14:28:00.000	80.96 kW	69.96 kW	116.12 kW
7	14.06.2016, 14:27:00.000	81.96 kW	68.81 kW	108.47 kW
8	14.06.2016, 14:26:00.000	80.98 kW	69.09 kW	102.54 kW
9	14.06.2016, 14:25:00.000	88.52 kW	68.12 kW	123.43 kW


Mean values in table format

Displaying the chronology of meter contents

The chronology of meters is available via the menu **Energy** and is divided in two groups:

- Pre-defined meters
- User-defined meters

From the difference of two successive meter readings the energy consumption for the dedicated time range can be determined.



Selection of the meter logger group

> Std. meter log.

Log. $\Sigma P(I+IV)$ Log. $\Sigma P(II+III)$ Log. $\Sigma Q(I+II)$ Log. $\Sigma Q(III+IV)$

«Previous 1 2 3 4 5 Next» Results per page 25

#	time	$\Sigma P(I+IV), \Sigma IT$	$\Sigma P(II+III), \Sigma IT$	
1	15.06.2016, 14:00:00.000	0 kWh	33276.80 kWh	
2	15.06.2016, 13:00:00.000	0 kWh	33203.10 kWh	
3	15.06.2016, 12:00:00.000	0 kWh	33137.40 kWh	
4	15.06.2016, 11:00:00.000	0 kWh	33069.10 kWh	
5	15.06.2016, 10:00:00.000	0 kWh	32996 kWh	
6	15.06.2016, 09:00:00.000	0 kWh	32919.70 kWh	
7	15.06.2016, 08:00:00.000	0 kWh	32849.90 kWh	
8	15.06.2016, 07:00:00.000	0 kWh	32784 kWh	
9	15.06.2016, 06:00:00.000	0 kWh	32735.30 kWh	
10	15.06.2016, 05:00:00.000	0 kWh	32719.10 kWh	
11	15.06.2016, 04:00:00.000	0 kWh	32687.10 kWh	


Meter content readings in table form

Displaying data locally

The selection works in the same way as with the WEB-GUI. There are the following differences:

- The individual measured quantities are arranged in a display matrix and can be selected via navigation.
- The number of displayable meter readings is limited to 25
- The time range of the mean values is limited to the present day or the present week. There is no possibility for navigation.

Manual data export as CSV file



Via  in the display of the mean values or meter logger the time range of the data to export can be selected. A CSV (Comma separated value) file will be generated. This can be imported as a text file to Excel, with comma as a separator.

The same file contains data for all quantities of the respective group.

7.8.2 Events


Configuration of events

- For all [monitoring functions](#) and [limit values](#) for which state transitions need to be recorded, the parameter “list entry” must be set to either events or alarms.
- Threshold values for PQ events can be adapted via the menu Settings | Power Quality

Displaying of event entries

Event lists are a kind of logbook. The occurrence of monitored events is recorded in the appropriate list with the time of its occurrence. There are the following lists:

- Alarm and event list
- PQ events ([see 7.8.4](#))
- [Security log](#) (via service menu)



> Event and alarm list

Event list Alarm list

Results per page

#	time	text	state
1	25.11.2019, 18:30:36,097	U1N high	└─
2	25.11.2019, 18:16:27,154	U1N high	└─
3	25.11.2019, 18:16:03,609	U1N high	└─
4	25.11.2019, 17:46:56,066	U1N high	└─
5	21.11.2019, 14:15:16,453	U1N high	└─
6	21.11.2019, 14:15:09,055	U1N high	└─
7	21.11.2019, 14:07:40,319	U1N high	└─

Example of an event list

Displaying data locally

The selection works in principle in the same way as with the WEB-GUI. There is the following difference:

- The number of displayable events is limited to 25

7.8.3 PQ events


Configuration of the events to record

[See 7.6](#)

Display of PQ event recordings (locally)

Recorded events are available in the form of a logbook, mains signalling events are stored in a separated list. Each detected event is entered into the PQ event list with the time of its occurrence, the remaining voltage and the duration of the event. By selecting a list entry, the graphical display of the measured values during this event is entered. The following presentations are available:

- Half cycle RMS curves of all voltages, all currents, all voltages and currents
- Wave shapes of all voltages, all currents, all voltages and currents
- State changes of digital inputs (for device versions with optional digital inputs only)



Display matrix on the local display

Restriction of the quantities to display on the local display

The user can adapt the displayed information to its needs. Once the graphic is displayed, the setting window for the selection of the quantities to be displayed is entered by pressing <OK>.

Voltage display

U1N	☒
U2N	☒
U3N	☒
UNE	☐

Current display

I1	☒
I2	☒
I3	☒
IN	☐


Mixed display

U1N	☒
U2N	☒
U3N	☒
UNE	☒
U12	☒
U23	☒
U31	☒

Display of PQ events (WEB-GUI)


As with the local GUI, recorded events are available in the form of a logbook. Events may be filtered by event type and event date.

By selecting a list entry, the graphical display of the measured values during this event is entered.




time	Duration [s]	Event type	Trigger channel	Details
20.06.2021 09:50:42,952	250.356	Voltage dip	U2, U3	Residual voltage: 120.007 V Depth: 109.993 V
16.07.2021 09:28:38,590	1.600	Voltage interruption	U1, U2, U3	Residual voltage: 0.0351962 V Depth: 229.965 V
16.07.2021 09:28:38,570	1.640	Voltage dip	U1, U2, U3	Residual voltage: 0.0351962 V Depth: 229.965 V
16.07.2021 09:24:11,238	237.822	Voltage dip	U1	Residual voltage: 159.69 V Depth: 70.3095 V
14.07.2021				Residual voltage: 99.8595 V

List of PQ events



Graphical display of a PQ event


By selecting a time range via left mouse key, the graphical event display may be zoomed.




Zoomed PQ event

7.8.4 PQ statistic

From the PQ statistic it is very easy to see whether the limits of the [monitored criteria](#) are respected or not. Each criterion is represented by a bar, which itself may be composed of multiple color components:




Example for monitoring voltage variations:




- Limit to be respected is marked with a red line (95% of the time range)
- U1N: Requirement fulfilled, because green bar > 95%
- U2N: Requirement not fulfilled, because green bar < 95%
- U3N: Requirement fulfilled, because green bar > 95%

Display of PQ statistic (WEB-GUI)

Selection via the menu PQ statistic





The PQ statistic is shown for a time range of one week. The end of the time range can be selected. The time range always starts and ends at 00:00h. In the overview you can directly select the standard to be used for assessment.



Display of PQ statistic (locally)

Selection via Main menu | PQ statistic




The PQ statistic is always displayed for the past seven days. Another time range cannot be selected.

The standard to be used for the assessment of the statistic can be changed by selecting the entry "Standard".

Display of PQ statistic details

For the recorded PQ quantities details can be displayed on a daily basis. On the local display this feature is limited to the past day.

...	Frequency	Daily statistic U	Harmonics U	Interharmonics U	Daily statistic I	Harmonics I	Interharmonics I
	Distribution	Voltage	Harmonics U1x	Interharmonics U1x	Current	Harmonics I1	Interharmonics I1
	Daily statistic	Flicker Pst	Harmonics U2x	Interharmonics U2x	Imbalance I	Harmonics I2	Interharmonics I2
		Flicker Plt	Harmonics U3x	Interharmonics U3x	TDD I	Harmonics I3	Interharmonics I3
		Imbalance U					
		THD U					





Statistical distribution of 10-s frequency values




Course of 10-min voltage values

Creating a conformity report via the device website – PQ-Easy Report


Via  a conformity report in PDF format can be created.

1. Select assessment period: At least 1 week
2. Select standard for which conformity needs to be proven
3. Select content of report (3 levels)
4. Enter a comment, which needs to be shown on the first page of the report
5. Start report generation...



During report generation a progress bar is shown at the upper side of the screen. The duration of the report generation depends on the selected content, the assessment period and the number of recorded PQ events.




The generated report can be downloaded.

Depending on the browser and its settings, you can either choose where to save the file or the report will be saved in the default download directory.

Example of a conformity report


a) Overview



b) Details



c) Events




7.9 Measurement information in file format

Using the data export scheduler tasks can be managed to provide measurement information in file form. Files can be generated periodically or event-driven and stored locally in the device and/or sent to an SFTP server.

The creation, management and customization of tasks for providing files is done via the settings menu using the item *Data export | Data export scheduler*.

7.9.1 Predefined tasks

The data export scheduler contains three predefined tasks for providing measurement data in PQDIF or CSV file format. For better readability all tasks are activated in the below image, in the factory settings the task “Periodic PQIS” is deactivated.




The screenshot shows a table with five columns: active, Name, Creation, File format, and Action. There are three rows of tasks. Each row has a green checkmark in the 'active' column. The tasks are 'Periodic PQDIF', 'PQ Events', and 'Periodic PQIS'. The 'Creation' column shows 'daily (last 24 hours)' for the first and third tasks, and 'immediately' for the second. The 'File format' column shows '[PQDIF] All values in three files' for the first and third tasks, and '[PQDIF] events' for the second. The 'Action' column shows '• store on local Storage' for the first and third tasks, and '• push to SFTP server' for the second. An 'Add task' button is in the top right corner.

active	Name	Creation	File format	Action
☒	Periodic PQDIF	daily (last 24 hours)	[PQDIF] All values in three files	• store on local Storage
☒	PQ Events	immediately	[PQDIF] events	• push to SFTP server
☒	Periodic PQIS	daily (last 24 hours)	[PQIS] All values in separate files	• store on local Storage

These tasks may be activated, deactivated and changed, but not deleted. Local storage and push to SFTP server are possible actions to be defined. If a task needs to be modified, this can easily be done by selecting the appropriate line.

Periodic PQDIF

This task is executed periodically shortly after midnight and saves the file (s) in a hierarchical time structure (year, month, day). The task can be adjusted by selecting the entry. You can choose whether the information should be contained in one file or in up to three files (statistics, histograms, events). The time period can be either one day or seven days, and generation can be daily or weekly. The factory setting is the daily generation of up to 3 files, each for the previous day.



The screenshot shows the 'Edit task' dialog for 'Periodic PQDIF'. It has fields for Name, File, Creation, and Action. The 'File' field has two dropdowns: 'PQDIF' and 'Everything in one file'. The 'Creation' field has a dropdown menu open showing options: 'daily (last 7 days)', 'daily (last 24 hours)', 'daily (last 7 days)' (highlighted), and 'weekly (last 7 days)'. The 'Action' field has a dropdown menu showing 'store on local Storage'. There is a '+' button at the bottom left and 'Ok' and 'Cancel' buttons at the bottom.

Edit task

Name
Periodic PQDIF

File
PQDIF Everything in one file

Creation
daily (last 7 days)
daily (last 24 hours)
daily (last 7 days)
weekly (last 7 days)


Action
store on local Storage

+

Ok Cancel

PQ Events

If this task is activated, a PQDIF file with event data is created as soon as a PQ event has ended. Typically, this file is then sent to an SFTP server.



The screenshot shows a dialog box titled "Edit task" with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Name:** A text field containing "PQ Events".
- File format:** Two dropdown menus. The first is set to "PQDIF" and the second is set to "events".
- Creation:** A dropdown menu set to "immediately".
- active:** A checkbox that is checked, indicated by a green checkmark icon.
- Action:** A dropdown menu set to "push to SFTP server".
- subfolder:** A text field containing "MOB-HC_62.46/PQDIF/Events".
- Transmission window:** A dropdown menu set to "none".
- Bottom section:** A horizontal line separates this section from the others. It contains a dropdown menu set to "store temporarily on local Stor".
- Buttons:** "Ok" and "Cancel" buttons are located at the bottom right of the dialog.

Periodic PQIS


If this task is activated, the device periodically creates, at the end of each day, CSV files with all information about the power quality, possibly occurred events during the day and the determined load profiles per Current Module. These files can be [downloaded](#) compressed in a ZIP file for a selectable time period. They are structured and formatted in a way that they can be read directly into the PQIS® software and evaluated there. The following files are generated:

- 10 minutes mean-values for PQ assessment
- 2 hours flicker values for PQ assessment
- Mean-values (configurable interval) of power quantities
- PQ event list
- Data for each PQ event:
 - Half-cycle values of voltages and currents
 - Waveform (samples) of voltages and currents
- Signalling voltage event list
- Half-cycle voltages for all signalling voltage events

7.9.2 Creating periodic file data

In addition to the predefined tasks new tasks can be setup for creating data files with a specific content at regular intervals. These files may then be stored locally and / or pushed to a SFTP server.

By selecting “Add task” new schedules can be set-up. An example is shown below:




The new task “24h_PowerMeans” will generate daily CSV files containing standard mean-values for the past 24 hours.

The files will be both stored locally and pushed to the subfolder PowerMeans of a SFTP server. The [settings](#) of the SFTP server to be used can be defined via Communication | SFTP in the Settings menu.

The transmission window selected here causes a random transmission of the file to the SFTP server within one hour since creation.

The task list then shows four active tasks. Predefined tasks are marked gray to highlight that they can be deactivated but not removed. On the other hand, at any time the newly created task “24h_PowerMeans” can be fully modified, deactivated or deleted.



active	Name	Creation	File format	Action
☒	Periodic PQDIF	daily (last 24 hours)	[PQDIF] All values in three files	• store on local Storage
☒	PQ Events	immediately	[PQDIF] events	• push to SFTP server
☒	Periodic PQIS	daily (last 24 hours)	[PQIS] All values in separate files	• store on local Storage
☒	24_h_PowerMeans	daily (last 24 hours)	[CSV] mean values	• store on local Storage • push to SFTP server

Via the settings of the local display only the activation / deactivation of the tasks is supported.

CSV settings

CSV files are intended for transmitting statistics of mean values. You may adjust the below parameters to adapt the file format and the content of the created files to your requirements.

Separator	Semicolon
Decimal separator	Dot
Time format	Local time +AB
include min/max values	Yes
Scaled to...	Nominal values
Digits after decimal point	3


- The **Separator** separates the individual entries on a text line for later display in table form.
- The **Decimal separator** defines how numbers or measured values are written to the file. The decimal separator must correspond to the country-specific number format of the operating system so that the CSV file can be opened directly in Excel without an import process. Common separators are periods (123.45) or commas (123,45).
- **Time format** defines the time format to be written. With the “local time + AB” time format, the double entries between 2 and 3 AM are supplemented with the letters A and B when switching back from daylight saving time.
- **Include min/max values** defines whether mean values with / without minimum and maximum values are written to the CSV file.
- **Scaled to** specifies whether the numerical value is based on the basic unit (e.g. 1087.65W) or on the units specified according to the nominal values (e.g. 1.0876kW), which are also used in the web interface.
- **Digits after decimal point** defines the number of digits after the decimal separator with which the numbers are written to the file.

7.9.3 Accessing file information via webpage


You can access files stored in the device using the service menu **Local data storage | Download data**. Depending on the tasks defined in the data export scheduler the available file structure may be different:

- **csv**: container for all CSV files to be locally stored
- **pqdif**: container for all PQDIF files to be locally stored

The structure is displayed in a new tab.




All files are stored in a hierarchical time structure (year, month, day). By selecting the desired date and double-clicking on the appropriate file, it can easily be downloaded.



7.9.4 Download of PQIS files


The files stored in the device can be downloaded and then transferred to the PQIS software.



By selecting a measurement campaign, all information for the entire measurement period can be downloaded to the local computer as a compressed ZIP file. The start and end times are automatically set, but can be changed. If desired, data files for mains signaling voltage events may be omitted, as they do not represent a power quality issue.

7.9.5 Periodical sending to a SFTP Server


If in the data export scheduler the sending to an SFTP server was selected as action, the appropriate files will be sent periodically to the SFTP server defined in the settings of the communication.



The image shows a configuration window for an SFTP server. It contains several fields and dropdown menus:

- Host:** tenserv.camillebauer.intra
- Port:** 22
- Username:** sftpuser
- Password:**
- Base directory:** data
- Only connect to trusted host:** No (dropdown menu)
- Legacy host key algorithms:** None (dropdown menu with a list: None, SSH-RSA, SSH-DSS, SSH-RSA, SSH-DSS)


For improving security, you may select that the device connects to trusted hosts only. When activating this setting the host must be present and sends a public key back to the device. If you accept this key the associated host will be added to the list of trusted servers.



In the presently used OpenSSH version **legacy algorithms** are not enabled by default, as these older algorithms have been found to be weak. But they can be enabled, if the used SFTP server does only support these algorithms. In the [Communication tests](#) in the service menu various settings can be tested to find the one supported by the SFTP server.

7.9.6 Evaluation of the PQDIF files

For the analysis of the data of the PQDIF files a free tool with limited functionality, such as the PQDiffactor from Electrotek Concepts (<http://www.pqview.com/pqdiffactor/>; registration required), or any other software (e.g. Dranview-7) supporting the PQDIF format can be used.



Representation of a voltage dip using PQDiffactor

7.10 Display timeouts

Devices with display are designed for displaying measurements. So, any other procedure will be terminated after a certain time without user interaction and the last active measurement image will be shown again.

Menu timeout

A menu timeout takes effect after 2 min. without changing the present menu selection. It doesn't matter if the currently displayed menu is the main menu or a sub-menu: The menu is closed and the last active measurement image is displayed again.

Configuration timeout

After 5 min. without interaction in a parameter selection or during entering a value in the settings menu, the active configuration step is closed and the associated parameter remains unchanged. The next step depends on what you have done before:

- If the user did not change configuration parameters before the aborted step, the main menu will be displayed and the device starts to monitor a possible menu timeout.
- If the user changed configuration parameters before the aborted step, the query "Store configuration changes?" is shown. If the user does not answer this query within 2 min. this dialogue is closed: The changed configuration will be stored and activated and then the last active measurement image is displayed again.

8. Service, maintenance and disposal

8.1 Calibration and new adjustment

Each device is adjusted and checked before delivery. The condition as supplied to the customer is measured and stored in electronic form.

The uncertainty of measurement devices may be altered during normal operation if, for example, the specified ambient conditions are not met. If desired, in our factory a calibration can be performed, including a new adjustment if necessary, to assure the accuracy of the device.

8.2 Cleaning

The display and the operating keys should be cleaned in regular intervals. Use a dry or slightly moist cloth for this.



Damage due to detergents

Detergents may not only affect the clearness of the display but also can damage the device. Therefore, do not use detergents.

8.3 Battery

The device contains a battery for buffering the internal clock. It cannot be changed by the user. The replacement can be done at the factory only.

If the UPS option is implemented, the associated battery pack needs to be exchanged regularly. For more information see [chapter 5.9](#).

8.4 Cyber Security Decommissioning



Logger data on internal Memory

To protect the data (sub billing, power monitoring data, grid power quality data, syslog data, time stamps) from unauthorized access, the data must be erased before the device is decommissioned.

This can be done via the corresponding menu item in the Service menu.

8.5 Disposal

The product must be disposed in compliance with local regulations. This particularly applies to the built-in battery.

9. Technical data

Inputs

Current	(hardware versions: 3 V or 5 A)
• 3V 50/60 Hz	max. 6.0 V (sinusoidal)
• 5A 50/60 Hz	
Nominal current:	adjustable 1...5 A; max. 7.5 A (sinusoidal)
Measurement cat.:	300V CAT III
Consumption:	$\leq I^2 \times 0.01 \Omega$ per phase
Overload capacity:	10 A continuous; 100 A, 5 x 1 s, interval 300 s
Nominal voltage:	57.7...400 V _{LN} (UL: 347V _{LN}), 100...693 V _{LL} (UL: 600V _{LL});
Measurement max.:	520 V _{LN} , 900 V _{LL} (sinusoidal)
Measurement category:	600V CAT III
Consumption:	$\leq U^2 / 1.54 M\Omega$ per phase
Impedance:	1.54 M Ω per phase
Overload capacity:	continuous: 520 V _{LN} , 900 V _{LL} 10 x 1 s, interval 10s: 800 V _{LN} , 1386 V _{LL}
Systems:	Single phase Split phase (2-phase system) 3-wire, balanced load 3-wire, unbalanced load 3-wire, unbalanced load, Aron connection 4-wire, unbalanced load
Nominal frequency:	42... <u>50</u> ...58Hz or 50.5... <u>60</u> ...69.5Hz, configurable
Sampling rate:	18 kHz
Internal data memory:	32 GB

Measurement uncertainty

Reference conditions: Acc. IEC/EN 60688, ambient 15...30°C,
sinusoidal input signals (form factor 1.1107), no fixed frequency for sampling,
measurement time 200ms (10 cycles at 50Hz, 12 cycles at 60Hz)

Voltage, current:	$\pm 0.1\%$ ^{1) 2)}
Neutral current:	$\pm 0.2\%$ ¹⁾ (if calculated)
Power:	$\pm 0.2\%$ ^{1) 2)}
Power factor:	$\pm 0.2^\circ$
Frequency:	± 0.01 Hz
Imbalance U, I:	$\pm 0.5\%$
Harmonics:	$\pm 0.5\%$
THD U, I:	$\pm 0.5\%$
Active energy ³⁾ :	Class 0.2S
Reactive energy ⁴⁾ :	Class 0.5S

Measurement with fixed system frequency:

General:	$\pm$ Basic uncertainty x (F _{config} - F _{actual}) [Hz] x 10
Imbalance U:	$\pm 2\%$ up to ± 0.5 Hz
Harmonics:	$\pm 2\%$ up to ± 0.5 Hz
THD, TDD:	$\pm 3.0\%$ up to ± 0.5 Hz

¹⁾ Related to the nominal value of the basic quantity

²⁾ Additional uncertainty if neutral wire not connected (3-wire connections)

- Voltage, power: 0.1% of measured value; load factor: 0.1°
- Energy: Voltage influence x 2, angle influence x 2

3) Acc. **IEC 62053-22: 2003** for

Accuracy Requirements	Subclause
<i>Meter constant</i>	8.4
<i>Starting current test</i>	8.3.3
<i>Limits of error due to variation of the current</i>	8.1
Limits of error due to influence quantities	Subclause
<i>5th harmonic of voltage and current</i>	8.2.1
<i>Interharmonics in the current circuit – burst fired waveform test</i>	8.2.1
<i>Odd harmonics in the current circuit</i>	8.2.1
<i>Reversed phase sequence</i>	8.2.1

4) Acc. **IEC 62053-24: 2014** for

Accuracy Requirements	Subclause
<i>Meter constant</i>	8.5
<i>Starting current test</i>	8.4
<i>Limits of error due to variation of the current</i>	8.2
Limits of error due to influence quantities	Subclause
<i>5th harmonic of voltage and current</i>	8.3
<i>Interharmonics in the current circuit – burst fired waveform test</i>	8.3
<i>Odd harmonics in the current circuit</i>	8.3
<i>Reversed phase sequence</i>	8.3

Power Quality

Type of device: (IEC 62586-1) **PQI-A F11: Power Quality Instrument – Class A; Fixed installation;**
Indoor environment with uncontrolled temperature variations (1)

Measurement cycle: 200 ms (50Hz: 10 cycles; 60Hz: 12 cycles)

Flagging concept: Multiphase approach in accordance with IEC 61000-4-30

Certification: According to IEC62586-2 (standard for verifying compliance with IEC 61000-4-30)

Certification body: Federal Institute of Metrology METAS, an independent and accredited laboratory

Conformity assessment against IEC 62586-2:2017

Clause	PQ parameter	Compliance 120 V- 60 Hz	Compliance 230 V – 50 Hz
6.1	Power frequency	Yes	Yes
6.2	Magnitude of the supply voltage	Yes	Yes
6.3	Flicker	Yes (class F1)	Yes (class F1)
6.4	Supply voltage interruptions, dips and swells	Yes	Yes
6.5	Supply voltage unbalance	Yes	Yes
6.6	Voltage harmonics	Yes	Yes
6.7	Voltage interharmonics	Yes	Yes
6.8	Mains signalling voltage of the supply voltage	Yes	Yes
6.9	Measurement of underdeviation / overdeviation parameters	Yes	Yes
6.10	Flagging	Yes	Yes
6.11	Clock uncertainty testing	Yes	Yes
6.12	Variations due to external influence quantities	Yes	Yes
6.13	Rapid voltage changes (RVC)	Yes	Yes
6.14	Magnitude of current	Yes	Yes
6.15	Harmonic current	Yes	Yes
6.16	Interharmonic currents	Yes	Yes
6.17	Current imbalance	Yes	Yes

Zero suppression, range limitations

The measurement of specific quantities is related to a pre-condition which must be fulfilled, that the corresponding value can be determined and sent via interface or displayed. If this condition is not fulfilled, a default value is used for the measurement.

Quantity	Condition	Default
Voltage	$U_x < 1\% U_{xnom}$	0.00
Current	$I_x < 0,1\% I_{xnom}$	0.00
PF	$S_x < 1\% S_{xnom}$	1.00
QF, LF, $\tan\phi$	$S_x < 1\% S_{xnom}$	0.00
Frequency	voltage and/or current input too low ¹⁾	Nominal frequency
Voltage unbalance	$U_x < 5\% U_{xnom}$	0.00
Current unbalance	mean value of phase currents $< 5\% I_{xnom}$	0.00
Phase angle U	at least one voltage $U_x < 5\% U_{xnom}$	120°
Harmonics U, THD-U	fundamental $< 5\% U_{xnom}$	0.00

¹⁾ Specific levels depend on the device configuration

Power supply

Nominal voltage: 100...230V AC 50/60Hz / DC $\pm 15\%$
Overvoltage category: OVC III
Consumption: Single rack: max. 40VA (depends on the device hardware used)
Double rack: max. 60VA (depends on the device hardware used)

I/O interface

Analog outputs

Linearization: Linear, kinked
Range: ± 20 mA (24 mA max.), bipolar
Uncertainty: $\pm 0.2\%$ of 20 mA
Burden: $\leq 500 \Omega$ (max. 10 V / 20 mA)
Burden influence: $\leq 0.2\%$
Residual ripple: $\leq 0.4\%$
Response time: 220...420 ms

Passive digital inputs

Nominal voltage:	24 ÷ 130 V DC (130 V max.)	110 ÷ 220 V DC (-15/+20%)
Input current:	< 5 mA	< 1 mA
Logisch ZERO:	-3 up to +5 V DC	0 up to 12 V DC
Logisch ONE:	11 up to 130 V DC	50 up to 264 V DC

Digital output

Relay
Load capacity: 250 V AC, 2 A, 500 VA
30 V DC, 2 A, 60 W

Interface

Ethernet

via RJ45 sockets
Protocol: Modbus/TCP, NTP, http, https, IPv4, IPv6
Physics: Ethernet 100BaseTX
Mode: 10/100 Mbit/s, full/half duplex, auto-negotiation

IEC61850

via RJ45 sockets, 2 equivalent ports
Protocol: IEC61850, NTP
Physics: Ethernet 100BaseTX
Mode: 10/100 Mbit/s, full/half duplex, auto-negotiation

Modbus/RTU via plug-in terminal (A, B, C/X)
Protocol: Modbus/RTU
Physics: RS-485, max. 1200m (4000 ft)
Baud rate: 9'600, 19'200, 38'400, 57'600, 115'200 Baud
Number of participants: ≤ 32

Internal clock (RTC)

Uncertainty: ± 2 minutes / month (15 up to 30°C)
Synchronization: none, via Ethernet ([NTP protocol](#)), [GPS](#) or [IRIG-B](#)
Running reserve: > 10 years

Uninterruptible power supply (UPS)

Type: VARTA Easy Pack EZPackL, UL listed MH16707
Nominal voltage: 3.7V
Capacity: 1150 mAh min., 4.5 Wh
Operating duration: 5 times 3 minutes
Life time: 3 up to 5 years, depending on operating and ambient conditions

Ambient conditions, general information

Operating temperature: • Device without UPS: –10 up to 15 up to 30 up to + 55°C
• Device with UPS: 0 up to 15 up to 30 up to + 35°C
(if used outside this operating temperature range, it is not ensured that the UPS battery pack is recharged).
Storage temperature: Base device: -25 up to + 70°C;
Battery pack UPS: -20...60°C (<1 month); -20°...45°C (< 3 months);
-20...30°C (< 1 year)
Temperature influence: 0.5 x measurement uncertainty per 10 K
Long term drift: 0.5 x measurement uncertainty per year
Usage group: II (acc. EN 60 688)
Relative humidity: < 95% no condensation
Altitude: ≤ 2000 m max.
Device to be used indoor only!

Mechanical attributes

Housing material: Polycarbonate (Makrolon)
Flammability class: V-0 acc. UL94, non-dripping, free of halogen
Weight: 4.2 kg (single rack), 5.0 kg (double rack)
Dimensions: [Dimensional drawings](#)

Vibration withstand (test according to DIN EN 60 068-2-6)

Acceleration: Device with display: ± 0.25 g (operating); 1.20 g (storage)
Frequency range: 10 ... 150 ... 10 Hz, rate of frequency sweep: 1 octave/minute
Number of cycles: 10 in each of the 3 axes

Safety

Protection class:	II (protective insulation, voltage inputs via protective impedance)
Pollution degree:	2
Protection:	Front: IP40; Housing: IP30; IP20 (if version without router) Terminals: IP20
Rated voltage (versus earth):	Power supply: 100...230V AC / DC I/O's: 130 / 220 V DC

• Device with 5A 50/60Hz current inputs

The current inputs are galvanically isolated from each other

Test voltages: Test time 60 s, acc. IEC/EN 61010-1 (2011)

- power supply versus inputs U ¹⁾: 3600V AC
- power supply versus inputs I: 3000V AC
- power supply versus bus, I/O's: 3000V AC
- inputs U versus inputs I: 1800V AC
- inputs U versus bus, I/O's ¹⁾: 3600V AC
- inputs I versus bus, I/O's: 3000V AC
- inputs I versus inputs I: 1500V AC

¹⁾ During type test only, with all protective impedances removed

• Device with 3V 50/60Hz current inputs

The connections ↓ of the current inputs are internally connected

Test voltages: Test time 60 s, acc. IEC/EN 61010-1 (2011)

- power supply versus inputs U ¹⁾: 3600V AC
- power supply versus inputs I: 3000V AC
- power supply versus bus, I/O's: 3000V AC
- inputs U versus inputs I, bus, I/O's ¹⁾: 3600V AC

¹⁾ During type test only, with all protective impedances removed



The device uses the principle of protective impedance for the voltage inputs to ensure protection against electric shock. All circuits of the device are tested during final inspection.

Prior to performing high voltage or isolation tests involving the voltage inputs, all output connections of the device, especially analog and digital outputs as well as Modbus and Ethernet interface, must be removed. A possible high-voltage test between input and output circuits must be limited to 500V DC, otherwise electronic components can be damaged.

Applied regulations, standards and directives

IEC/EN 61010-1	Safety regulations for electrical measuring, control and laboratory equipment
IEC/EN 61000-4-30 Ed.3	Power quality measurement methods
IEC/EN 61000-4-7	General guide on harmonics and interharmonics measurements
IEC/EN 61000-4-15	Flickermeter - Functional and design specifications
IEEE 1159.3	Recommended Practice for the Transfer of Power Quality Data
IEC 62586-1 Ed.2	Power quality measurement in power supply systems – Power quality instruments (PQI)
IEC 62586-2 Ed.2	Power quality measurement in power supply systems – Functional tests and uncertainty requirements
IEC TS 63383	Cybersecurity aspects of devices used for power metering and monitoring, power quality monitoring, data collection and analysis
EN50160	Voltage characteristics of electricity supplied by public distribution systems
IEC/EN 60688	Electrical measuring transducers for converting AC electrical variables into analog or digital signals
DIN 40 110	AC quantities
IEC/EN 60068-2-1/ -2/-3/-6/-27:	Ambient tests -1 Cold, -2 Dry heat, -3 Damp heat, -6 Vibration, -27 Shock
IEC/EN 60297-3-100	Mechanical structures for electronic equipment - Dimensions of mechanical structures of the 482,6 mm (19 in) series - Part 3-100: Basic dimensions of front panels, subracks, chassis, racks and cabinets.
IEC/EN 60529	Protection type by enclosures
IEC/EN 61000-6-4	Electromagnetic compatibility (EMC): Emission standard for industrial environments
IEC/EN 61000-6-5	Electromagnetic compatibility (EMC): Immunity for equipment used in power station and substation environment
IEC 62053-22: 2003	Static meters for AC active energy (classes 0,1S, 0,2S and 0,5S)
IEC 62053-24: 2014	Static meters for reactive energy at fundamental frequency (classes 0,5S, 1S, 1, 2 and 3)
UL94	Tests for flammability of plastic materials for parts in devices and appliances
2011/65/EU (RoHS)	EU directive on the restriction of the use of certain hazardous substances

Warning


This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

This device complies with part 15 of the FCC:

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class A digital apparatus complies with Canadian ICES-0003.

10. Dimensional drawings



All dimensions in [mm]

Annex

A Description of measured quantities

Used abbreviations

1L	Single phase system
2L	Split phase; system with 2 phases and center tap
3Lb	3-wire system with balanced load
3Lu	3-wire system with unbalanced load
3Lu.A	3-wire system with unbalanced load, Aron connection (only 2 currents connected)
4Lu	4-wire system with unbalanced load

A1 Basic measurements

The basic measured quantities are calculated each 200ms by determining an average over 10 cycles at 50Hz or 12 cycles at 60Hz. If a measurement is available depends on the selected system.

Depending on the measured quantity also minimum and maximum values are determined and non-volatile stored with timestamp. These values may be reset by the user via display or website; see [resetting of measurements](#).

Measurement	present	max	min	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Voltage U	•	•	•	✓	✓				
Voltage U_{1N}	•	•	•		✓				✓
Voltage U_{2N}	•	•	•		✓				✓
Voltage U_{3N}	•	•	•						✓
Voltage U_{12}	•	•	•			✓	✓	✓	✓
Voltage U_{23}	•	•	•			✓	✓	✓	✓
Voltage U_{31}	•	•	•			✓	✓	✓	✓
Voltage U_{NE} / U_{4C} ¹⁾	•	•		✓	✓	✓	✓	✓	✓
Current I	•	•		✓		✓			
Current I1	•	•			✓		✓	✓	✓
Current I2	•	•			✓		✓	✓	✓
Current I3	•	•					✓	✓	✓
Neutral current I_N	•	•		✓	✓				✓
Earth current I_{PE} (calculated)	•	•							✓
Active power P	•	•		✓	✓	✓	✓	✓	✓
Active power P1	•	•			✓				✓
Active power P2	•	•			✓				✓
Active power P3	•	•							✓
Fundamental active power P(H1)	•	•		✓	✓	✓	✓	✓	✓
Fundamental active power P1(H1)	•	•			✓				✓
Fundamental active power P2(H1)	•	•			✓				✓
Fundamental active power P3(H1)	•	•							✓
Total reactive power Q	•	•		✓	✓	✓	✓	✓	✓
Total reactive power Q1	•	•			✓				✓
Total reactive power Q2	•	•			✓				✓
Total reactive power Q3	•	•							✓
Distortion reactive power D	•	•		✓	✓	✓	✓	✓	✓
Distortion reactive power D1	•	•			✓				✓
Distortion reactive power D2	•	•			✓				✓
Distortion reactive power D3	•	•							✓
Fundamental reactive power Q(H1)	•	•		✓	✓	✓	✓	✓	✓
Fundamental reactive power Q1(H1)	•	•			✓				✓
Fundamental reactive power Q2(H1)	•	•			✓				✓
Fundamental reactive power Q3(H1)	•	•							✓

¹⁾ U_{4C} for 3-wire systems only if measurement of homopolar voltage has been activated; U_{NE} otherwise


Measurement	present	max	min	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Apparent power S	•	•		√	√	√	√	√	√
Apparent power S1	•	•			√				√
Apparent power S2	•	•			√				√
Apparent power S3	•	•							√
Fundamental apparent power S(H1)	•	•		√	√	√	√	√	√
Fundamental apparent power S1(H1)	•	•			√				√
Fundamental apparent power S2(H1)	•	•			√				√
Fundamental apparent power S3(H1)	•	•							√
Frequency F	•	•	•	√	√	√	√	√	√
Power factor PF	•			√	√	√	√	√	√
Power factor PF1	•				√				√
Power factor PF2	•				√				√
Power factor PF3	•								√
PF quadrant I			•	√	√	√	√	√	√
PF quadrant II			•	√	√	√	√	√	√
PF quadrant III			•	√	√	√	√	√	√
PF quadrant IV			•	√	√	√	√	√	√
Reactive power factor QF	•			√	√	√	√	√	√
Reactive power factor QF1	•				√				√
Reactive power factor QF2	•				√				√
Reactive power factor QF3	•								√
Load factor LF	•			√	√	√	√	√	√
Load factor LF1	•				√				√
Load factor LF2	•				√				√
Load factor LF3	•								√
cosφ (H1)	•			√	√	√	√	√	√
cosφ L1 (H1)	•				√				√
cosφ L2 (H1)	•				√				√
cosφ L3 (H1)	•								√
cosφ (H1) quadrant I			•	√	√	√	√	√	√
cosφ (H1) quadrant II			•	√	√	√	√	√	√
cosφ (H1) quadrant III			•	√	√	√	√	√	√
cosφ (H1) quadrant IV			•	√	√	√	√	√	√
tanφ (H1)	•			√	√	√	√	√	√
tanφ L1 (H1)	•				√				√
tanφ L2 (H1)	•				√				√
tanφ L3 (H1)	•								√
$U_{mean}=(U1N+U2N)/2$	•				√				
$U_{mean}=(U1N+U2N+U3N)/3$	•								√
$U_{mean}=(U12+U23+U31)/3$	•					√	√	√	
$I_{mean}=(I1+I2)/2$	•				√				
$I_{mean}=(I1+I2+I3)/3$	•						√		√
IMS, Average current with sign of P	•			√	√	√	√	√	√
Phase angle between U1 and U2	•					√	√	√	√
Phase angle between U2 and U3	•					√	√	√	√
Phase angle between U3 and U1	•					√	√	√	√
Angle between U and I	•			√		√	√	√	
Angle between U1 and I1	•				√				√
Angle between U2 and I2	•				√				√
Angle between U3 and I3	•								√
Maximum ΔU <> Um	•	•			√	√	√	√	√
Maximum ΔI <> Im	•	•			√		√		√

• Available via communication interface only

Reactive power

Most of the loads consume a combination of ohmic and inductive current from the power system. Reactive power arises by means of the inductive load. But the number of non-linear loads, such as RPM regulated drives, rectifiers, thyristor controlled systems or fluorescent lamps, is increasing. They cause non-sinusoidal AC currents, which may be represented as a sum of harmonics. Thus the reactive power to transmit increases and leads to higher transmission losses and higher energy costs. This part of the reactive power is called distortion reactive power.

Normally reactive power is unwanted, because there is no usable active component in it. Because the transmission of reactive power over long distances is uneconomic, it makes sense to install compensation systems close to the consumers. So transmission capacities may be used better and losses and voltage drops by means of harmonic currents can be avoided.



P:	Active power
S:	Apparent power including harmonic components
S1:	Fundamental apparent power
Q:	Total reactive power
Q(H1):	Fundamental reactive power
D:	Distortion reactive power

The reactive power may be divided in a fundamental and a distortion component. Only the fundamental reactive power may be compensated directly by means of the classical capacitive method. The distortion components have to be combated using inductors or active harmonic conditioners.

The **load factor PF** is the relation between active power P and apparent power S, including all possibly existing harmonic parts. This factor is often called $\cos\varphi$, which is only partly correct. The PF corresponds to the **$\cos\varphi$** only, if there is no harmonic content present in the system. So the **$\cos\varphi$** represents the relation between the active power P and the fundamental apparent power S(H1).


The **$\tan\varphi$** is often used as a target quantity for the capacitive reactive power compensation. It corresponds to the relation of the fundamental reactive power Q(H1) and the active power P.

Power factors

The **power factor PF** gives the relation between active and apparent power. If there are no harmonics present in the system, it corresponds to the $\cos\varphi$ or displacement power factor. The PF has a range of -1...0...+1, where the sign gives the direction of energy flow.

The **load factor LF** is a quantity derived from the PF, which allows making a statement about the load type. Only this way it's possible to measure a range like 0.5 capacitive ... 1 ... 0.5 inductive in a non-ambiguous way.

The **reactive power factor QF** gives the relation between reactive and apparent power.




Example from the perspective of an energy consumer

Zero displacement voltage U_{NE}

Starting from the generating system with star point E (which is normally earthed), the star point (N) on load side is shifted in case of unbalanced load. The zero displacement voltage between E and N may be determined by a vector addition of the voltage vectors of the three phases:

$$\underline{U}_{NE} = - (\underline{U}_{1N} + \underline{U}_{2N} + \underline{U}_{3N}) / 3$$

A displacement voltage may also occur due to harmonics of order 3, 9, 15, 21 etc., because the dedicated currents add in the neutral wire.



A2 Harmonic analysis

The harmonic analysis is performed according IEC 61000-4-7 over 10 cycles at 50Hz or 12 cycles at 60Hz. If a measured quantity is available depends on the selected system.

Measurement	prese	max	1L	2L	3Lb	3Lu	3Lu.A	4Lu
THD Voltage U1N/U	•	•	√	√				√
THD Voltage U2N	•	•		√				√
THD Voltage U3N	•	•						√
THD Voltage U12	•	•			√	√	√	
THD Voltage U23	•	•			√	√	√	
THD Voltage U31	•	•			√	√	√	
THD Current I1/I	•	•	√	√	√	√	√	√
THD Current I2	•	•		√		√	√	√
THD Current I3	•	•				√	√	√
TDD Current I1/I	•	•	√	√	√	√	√	√
TDD Current I2	•	•		√		√	√	√
TDD Current I3	•	•				√	√	√
Harmonic contents 2 nd ...50 th U1N/U	•	•	√	√				√
Harmonic contents 2 nd ...50 th U2N	•	•		√				√
Harmonic contents 2 nd ...50 th U3N	•	•						√
Harmonic contents 2 nd ...50 th U12	•	•			√	√	√	
Harmonic contents 2 nd ...50 th U23	•	•			√	√	√	
Harmonic contents 2 nd ...50 th U31	•	•			√	√	√	
Harmonic contents 2 nd ...50 th I1/I	•	•	√	√	√	√	√	√
Harmonic contents 2 nd ...50 th I2	•	•		√		√	√	√
Harmonic contents 2 nd ...50 th I3	•	•				√	√	√

• Available via communication interface only

Harmonic contents are available up to the 89th (50Hz) or 75th (60Hz) on the Modbus interface

Harmonics

Harmonics are multiples of the fundamental or system frequency. They arise if non-linear loads, such as RPM regulated drives, rectifiers, thyristor controlled systems or fluorescent lamps are present in the power system. Thus undesired side effects occur, such as additional thermal stress to operational resources or electrical mains, which lead to an advanced aging or even damage. Also the reliability of sensitive loads can be affected and unexplainable disturbances may occur. In industrial networks the image of the harmonics gives good information about the kind of loads connected. See also:

► [Increase of reactive power due to harmonic currents](#)

TDD (Total Demand Distortion)

The complete harmonic content of the currents is calculated additionally as Total Demand Distortion, briefly TDD. This value is scaled to the rated current or rated power. Only this way it's possible to estimate the influence of the current harmonics on the connected equipment correctly.

Maximum values

The maximum values of the harmonic analysis arise from the monitoring of THD and TDD. The maximum values of individual harmonics are not monitored separately, but are stored if a maximum value of THD or TDD is detected. The image of the maximum harmonics therefore always corresponds to the dedicated THD or TDD.



The accuracy of the harmonic analysis strongly depends on the quality of the current and voltage transformers possibly used. In the harmonics range transformers normally change both, the amplitude and the phase of the signals to measure. It's valid: The higher the frequency of the harmonic, the higher its damping or phase shift.

A3 System imbalance

Measured quantity	prese	max	1L	2L	3Lb	3Lu	3Lu.A	4Lu
UR1: Positive sequence [V]	•				√	√	√	√
UR2: Negative sequence [V]	•				√	√	√	√
U0: Zero sequence [V]	•							√
U: Imbalance UR2/UR1	•	•			√	√	√	√
U: Imbalance U0/UR1	•	•						√
IR1: Positive sequence [A]	•					√		√
IR2: Negative sequence [A]	•					√		√
I0: Zero sequence [A]	•							√
I: Imbalance IR2/IR1	•	•				√		√
I: Imbalance I0/IR1	•	•						√

• Available via communication interface only

Imbalance in three-phase systems may occur due to single-phase loads, but also due to failures, such as e.g. the blowing of a fuse, an earth fault, a phase failure or an isolation defect. Also harmonics of the 3rd, 9th, 15th, 21st etc. order, which add in the neutral wire, may lead to imbalance. Operating resources dimensioned to rated values, such as three-phase generators, transformers or motors on load side, may be excessively stressed by imbalance. So a shorter life cycle, a damage or failure due to thermal stress can result. Therefore monitoring imbalance helps to reduce the costs for maintenance and extends the undisturbed operating time of the used resources.

Imbalance or unbalanced load relays use different measurement principles. One of them is the approach of the symmetrical components, the other one calculates the maximum deviation from the mean-value of the three phase values. The results of these methods are not equal and don't have the same intention. Both of these principles are implemented in the device.

Symmetrical components (acc. Fortescue)

The imbalance calculation method by means of the symmetrical components is ambitious and intensive to calculate. The results may be used for disturbance analysis and for protection purposes in three-phase systems. The real existing system is divided in symmetrical system parts: A positive sequence, a negative sequence and (for systems with neutral conductor) a zero sequence system. The approach is easiest to understand for rotating machines. The positive sequence represents a positive rotating field, the negative sequence a negative (braking) rotating field with opposite sense of direction. Therefore the negative sequence prevents that the machine can generate the full turning moment. For e.g. generators the maximum permissible current imbalance is typically limited to a value of 8...12%.

Maximum deviation from the mean value

The calculation of the maximum deviation from the mean value of the phase currents or phase voltages gives the information if a grid or substation is imbalanced loaded. The results are independent of rated values and the present load situation. So a more symmetrical system can be aspired, e.g. by changing loads from one phase to another.


Also failure detection is possible. The capacitors used in compensation systems are wear parts, which fail quite often and then have to be replaced. When using three phase power capacitors all phases will be compensated equally which leads to almost identical currents flowing through the capacitors, if the system load is comparable. By monitoring the current imbalance it's then possible to estimate if a capacitor failure is present.

The maximum deviations are calculated in the same steps as the instantaneous values and therefore are arranged there ([see A1](#)).

A4 Mean values and trend

Measured quantity		Present	Trend	max	min	History
Active power I+IV	10s...60min. ¹⁾	•	•	•	•	5
Active power II+III	10s...60min. ¹⁾	•	•	•	•	5
Reactive power I+II	10s...60min. ¹⁾	•	•	•	•	5
Reactive power III+IV	10s...60min. ¹⁾	•	•	•	•	5
Apparent power	10s...60min. ¹⁾	•	•	•	•	5
Mean value quantity 1	10s...60min. ²⁾	•	•	•	•	1
....						
Mean value quantity 12	10s...60min. ²⁾	•	•	•	•	1

¹⁾ Interval time t1 ²⁾ Interval time t2



Calculating the mean-values

The mean value calculation is performed via integration of the measured instantaneous values over a configurable averaging interval. The interval time may be selected in the range from 10 seconds up to one hour. Possible interim values are set the way that a multiple of it is equal to a minute or an hour. Mean values of power quantities (interval time t1) and free quantities (interval time t2) may have different averaging intervals.

Synchronization

For the synchronization of the averaging intervals the internal clock is used. To be able to compare the mean values of power quantities on generating and demand side it is therefore required to synchronize the clock either via NTP, GPS or IRIG-B.

Trend

The estimated final value (trend) of mean values is determined by weighted addition of measurements of the past and the present interval. It serves for early detection of a possible exceeding of a given maximum value. This can then be avoided, e.g. by switching off an active load.

History

For mean values of system powers the last 5 interval values may be displayed on the device or read via interface. For configurable quantities the value of the last interval is provided via communication interface.

Bimetal current


This measured quantity serves for measuring the long-term effect of the current, e.g. for monitoring the warming of a current-carrying line. To do so, an exponential function is used, similar to the charging curve of a capacitor. The response time of the bimetal function can be freely selected, but normally it corresponds to the interval for determining the power mean-values.

Measured quantity	Present	max	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Bimetal current IB, 1...60min. ³⁾	•	•	√		√			
Bimetal current IB1, 1...60min. ³⁾	•	•		√		√	√	√
Bimetal current IB2, 1...60min. ³⁾	•	•		√		√	√	√
Bimetal current IB3, 1...60min. ³⁾	•	•				√	√	√

³⁾ Interval time t3

A5 Meters

Measured quantity	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Active energy I+IV, high tariff	•	•	•	•	•	•
Active energy II+III, high tariff	•	•	•	•	•	•
Reactive energy I+II, high tariff	•	•	•	•	•	•
Reactive energy III+IV, high tariff	•	•	•	•	•	•
Active energy I+IV, low tariff	•	•	•	•	•	•
Active energy II+III, low tariff	•	•	•	•	•	•
Reactive energy I+II, low tariff	•	•	•	•	•	•
Reactive energy III+IV, low tariff	•	•	•	•	•	•
User configured meter 1	Only basic quantities can be selected which are supported in the present system.					
User configured meter 2						
User configured meter 3						
User configured meter 4						
User configured meter 5						
User configured meter 6						
User configured meter 7						
User configured meter 8						
User configured meter 9						
User configured meter 10						
User configured meter 11						
User configured meter 12						



Standard meters

The meters for active and reactive energy of the system are always active.

User configured meters

To each of these meters the user can freely assign a basic quantity.

Programmable meter resolution



For all meters the resolution (displayed unit) can be selected almost freely. This way, applications with short measurement times, e.g. energy consumption of a working day or shift, can be realized. The smaller the basic unit is selected, the faster the meter overflow is reached.

B Display matrices

B0 Used abbreviations for the measurements

Instantaneous values

Name	Measurement identification		Unit	Description
U	U	TRMS	V	Voltage system
U1N	U 1N	TRMS	V	Voltage between phase L1 and neutral
U2N	U 2N	TRMS	V	Voltage between phase L2 and neutral
U3N	U 3N	TRMS	V	Voltage between phase L3 and neutral
U12	U 12	TRMS	V	Voltage between phases L1 and L2
U23	U 23	TRMS	V	Voltage between phases L2 and L3
U31	U 31	TRMS	V	Voltage between phases L3 and L1
UNE	U NE	TRMS	V	Zero displacement voltage 4-wire systems
U4C	U NE	TRMS	V	Homopolar voltage between U4 and COM
I	I	TRMS	A	Current system
I1	I 1	TRMS	A	Current phase L1
I2	I 2	TRMS	A	Current phase L2
I3	I 3	TRMS	A	Current phase L3
IN	I N	TRMS	A	Neutral current
IPE	I PE	TRMS		Earth current
P	P	TRMS	W	Active power system ($P=P1+P2+P3$)
P1	P 1	TRMS	W	Active power phase L1
P2	P 2	TRMS	W	Active power phase L2
P3	P 3	TRMS	W	Active power phase L3
Q	Q	TRMS	var	Reactive power system ($Q=Q1+Q2+Q3$)
Q1	Q 1	TRMS	var	Reactive power phase L1
Q2	Q 2	TRMS	var	Reactive power phase L2
Q3	Q 3	TRMS	var	Reactive power phase L3
S	S	TRMS	VA	Apparent power system
S1	S 1	TRMS	VA	Apparent power phase L1
S2	S 2	TRMS	VA	Apparent power phase L2
S3	S 3	TRMS	VA	Apparent power phase L3
F	F	TRMS	Hz	System frequency
PF	PF	TRMS		Active power factor P/S
PF1	PF 1	TRMS		Active power factor P1/S1
PF2	PF 2	TRMS		Active power factor P2/S2
PF3	PF 3	TRMS		Active power factor P3/S3
QF	QF	TRMS		Reactive power factor Q / S
QF1	QF 1	TRMS		Reactive power factor Q1 / S1
QF2	QF 2	TRMS		Reactive power factor Q2 / S2
QF3	QF 3	TRMS		Reactive power factor Q3 / S3
LF	LF	TRMS		Load factor system
LF1	LF 1	TRMS		Load factor phase L1
LF2	LF 2	TRMS		Load factor phase L2
LF3	LF 3	TRMS		Load factor phase L3
UR1	U pos	SEQ	V	Positive sequence voltage
UR2	U neg	SEQ	V	Negative sequence voltage
U0	U zero	SEQ	V	Zero sequence voltage
IR1	I pos	SEQ	A	Positive sequence current
IR2	I neg	SEQ	A	Negative sequence current
I0	I zero	SEQ	A	Zero sequence current
UR2R1	U neg/pos	UNB	%	Unbalance factor voltage UR2/UR1
IR2R1	I neg/pos	UNB	%	Unbalance factor current IR2/IR1
U0R1	U zero/pos	UNB	%	Unbalance factor voltage U0/UR1
I0R1	I zero/pos	UNB	%	Unbalance factor current I0/IR1

Name	Measurement identification	Unit	Description
IMS	I $\emptyset$  TRMS	A	Average current with sign of P
Pst1N	Pst 1N 10min		Short term flicker U1N, Averaging time 10min.
Pst2N	Pst 2N 10min		Short term flicker U2N, Averaging time 10min.
Pst3N	Pst 3N 10min		Short term flicker U3N, Averaging time 10min.
Pst12	Pst 12 10min		Short term flicker U12, Averaging time 10min.
Pst23	Pst 23 10min		Short term flicker U23, Averaging time 10min.
Pst31	Pst 31 10min		Short term flicker U31, Averaging time 10min.
UD	U $\leq$ 1N TRMS	V	Underdeviation system voltage
UD1N	U $\leq$ 1N TRMS	V	Underdeviation voltage U1N
UD2N	U $\leq$ 2N TRMS	V	Underdeviation voltage U2N
UD3N	U $\leq$ 3N TRMS	V	Underdeviation voltage U3N
UD12	U $\leq$ 12 TRMS	V	Underdeviation voltage U12
UD23	U $\leq$ 23 TRMS	V	Underdeviation voltage U23
UD31	U $\leq$ 31 TRMS	V	Underdeviation voltage U31
OD	U $\geq$ 1N TRMS	V	Overdeviation system voltage
OD1N	U $\geq$ 1N TRMS	V	Overdeviation voltage U1N
OD2N	U $\geq$ 2N TRMS	V	Overdeviation voltage U2N
OD3N	U $\geq$ 3N TRMS	V	Overdeviation voltage U3N
OD12	U $\geq$ 12 TRMS	V	Overdeviation voltage U12
OD23	U $\geq$ 23 TRMS	V	Overdeviation voltage U23
OD31	U $\geq$ 31 TRMS	V	Overdeviation voltage U31

Minimum and maximum of instantaneous values

Name	Measurement identification			Unit	Description
U_MM	U		TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U
U1N_MM	U	1N	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U1N
U2N_MM	U	2N	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U2N
U3N_MM	U	3N	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U3N
U12_MM	U	12	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U12
U23_MM	U	23	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U23
U31_MM	U	31	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U31
UNE_MAX	U	NE	TRMS $\blacktriangle TS$	V	Maximum value of UNE
U4C_MAX	U	4C	TRMS $\blacktriangle TS$	V	Maximum value of U4C
I_MAX	I		TRMS $\blacktriangle TS$	A	Maximum value of I
I1_MAX	I	1	TRMS $\blacktriangle TS$	A	Maximum value of I1
I2_MAX	I	2	TRMS $\blacktriangle TS$	A	Maximum value of I2
I3_MAX	I	3	TRMS $\blacktriangle TS$	A	Maximum value of I3
IN_MAX	I	N	TRMS $\blacktriangle TS$	A	Maximum value of IN
IPE_MAX	I	PE	TRMS $\blacktriangle TS$	A	Maximum value of IPE
P_MAX	P		TRMS $\blacktriangle TS$	W	Maximum value of P
P1_MAX	P	1	TRMS $\blacktriangle TS$	W	Maximum value of P1
P2_MAX	P	2	TRMS $\blacktriangle TS$	W	Maximum value of P2
P3_MAX	P	3	TRMS $\blacktriangle TS$	W	Maximum value of P3
Q_MAX	Q		TRMS $\blacktriangle TS$	var	Maximum value of Q
Q1_MAX	Q	1	TRMS $\blacktriangle TS$	var	Maximum value of Q1
Q2_MAX	Q	2	TRMS $\blacktriangle TS$	var	Maximum value of Q2
Q3_MAX	Q	3	TRMS $\blacktriangle TS$	var	Maximum value of Q3
S_MAX	S		TRMS $\blacktriangle TS$	VA	Maximum value of S
S1_MAX	S	1	TRMS $\blacktriangle TS$	VA	Maximum value of S1
S2_MAX	S	2	TRMS $\blacktriangle TS$	VA	Maximum value of S2
S3_MAX	S	3	TRMS $\blacktriangle TS$	VA	Maximum value of S3
F_MM	F		TRMS $\blacktriangle TS$	Hz	Minimum and maximum value of F
UR21_MAX	U	neg/pos	UNB $\blacktriangle TS$	%	Maximum value of UR2/UR1
IR21_MAX	I	neg/pos	UNB $\blacktriangle TS$	%	Maximum value of IR2/IR1
THD_U_MAX	U		THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U
THD_U1N_MAX	U	1N	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U1N
THD_U2N_MAX	U	2N	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U2N
THD_U3N_MAX	U	3N	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U3N
THD_U12_MAX	U	12	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U12
THD_U23_MAX	U	23	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U23
THD_U31_MAX	U	31	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U31
TDD_I_MAX	I		TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I
TDD_I1_MAX	I	1	TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I1
TDD_I2_MAX	I	2	TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I2
TDD_I3_MAX	I	3	TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I3

TS: Timestamp of occurrence, e.g. 2014/09/17 11:12:03

Mean-values, trend and bimetal current

Name	Measurement identification				Unit	Description
M1	(m)	(p)	(q)	 (t2)	(mu)	Mean-value 1
M2	(m)	(p)	(q)	 (t2)	(mu)	Mean-value 2
....	(m)	(p)	(q)	 (t2)	(mu)	
M11	(m)	(p)	(q)	 (t2)	(mu)	Mean-value 11
M12	(m)	(p)	(q)	 (t2)	(mu)	Mean-value 12
TR_M1	(m)	(p)	(q)	 (t2)	(mu)	Trend mean-value 1
TR_M2	(m)	(p)	(q)	 (t2)	(mu)	Trend mean-value 2
....	(m)	(p)	(q)	 (t2)	(mu)	
TR_M11	(m)	(p)	(q)	 (t2)	(mu)	Trend mean-value 11
TR_M12	(m)	(p)	(q)	 (t2)	(mu)	Trend mean-value 12
IB	IB			 (t3)	A	Bimetal current, system
IB1	IB	1		 (t3)	A	Bimetal current, phase L1
IB2	IB	2		 (t3)	A	Bimetal current, phase L2
IB3	IB	3		 (t3)	A	Bimetal current, phase L3

Minimum and maximum of mean-values and bimetal-current

Name	Measurement identification				Unit	Description
M1_MM	(m)	(p)	(q)	 (t2) ▲ TS ▼ TS	..	Min/Max mean-value 1
M2_MM	(m)	(p)	(q)	 (t2) ▲ TS ▼ TS	..	Min/Max mean-value 2
....	(m)	(p)	(q)	 (t2) ▲ TS ▼ TS	..	
M11_MM	(m)	(p)	(q)	 (t2) ▲ TS ▼ TS	..	Min/Max mean-value 11
M12_MM	(m)	(p)	(q)	 (t2) ▲ TS ▼ TS	..	Min/Max mean-value 12
IB_MAX	IB			 (t3) ▲ TS	A	Maximum bimetal current, system
IB1_MAX	IB	1		 (t3) ▲ TS	A	Maximum Bimetal current, phase L1
IB2_MAX	IB	2		 (t3) ▲ TS	A	Maximum Bimetal current, phase L2
IB3_MAX	IB	3		 (t3) ▲ TS	A	Maximum Bimetal current, phase L3

Meters

Name	Measurement identification				Unit	Description
ΣP_I_IV_HT	P			ΣHT	Wh	Meter P I+IV, high tariff
ΣP_II_III_HT	P			ΣHT	Wh	Meter P II+III, high tariff
ΣQ_I_II_HT	Q			ΣHT	varh	Meter Q I+II, high tariff
ΣQ_III_IV_HT	Q			ΣHT	varh	Meter Q III+IV, high tariff
ΣP_I_IV_LT	P			ΣLT	Wh	Meter P I+IV, low tariff
ΣP_II_III_LT	P			ΣLT	Wh	Meter P II+III, low tariff
ΣQ_I_II_LT	Q			ΣLT	varh	Meter Q I+II, low tariff
ΣQ_III_IV_LT	Q			ΣLT	varh	Meter Q III+IV, low tariff
ΣMETER1	(m)	(p)	(qg)	Σ(T)	(mu)	User meter 1, tariff HT or LT
ΣMETER2	(m)	(p)	(qg)	Σ(T)	(mu)	User meter 2, tariff HT or LT
.....	(m)	(p)	(qg)	Σ(T)	(mu)	
ΣMETER11	(m)	(p)	(qg)	Σ(T)	(mu)	User meter 11, tariff HT or LT
ΣMETER12	(m)	(p)	(qg)	Σ(T)	(mu)	User meter 12, tariff HT or LT

(m): Short description of basic quantity, e.g. „P“

(p): Phase reference of the selected quantity, e.g. „1“





(q): Quadrant information, e.g. „I+IV“


(qg): Graphical quadrant information, e.g. 

(T): Associated tariff, e.g. „HT“ or „LT“

(mu): Unit of basic quantity

Graphical measurement displays

Name	Presentation	Description
Px_TRIANGLE		Graphic of the power triangle consisting of: • Active, reactive and apparent power P_x, Q_x, S_x • Distortion reactive power D_x • Fundamental reactive power $Q_x(H1)$ • $\cos(\varphi)$ of fundamental • Active power factor PF_x
PF_MIN		Graphic: Minimum active power factor PF in all 4 quadrants
Cφ_MIN	(as PF_MIN)	Graphic: Minimum $\cos(\varphi)$ in all 4 quadrants
MT_P_I_IV		Graphic mean-value P (I+IV) Trend, last 5 interval values, minimum and maximum
MT_P_II_III	(as MT_P_I_IV)	Graphic mean-value P (II+III) Trend, last 5 interval values, minimum and maximum
MT_Q_I_II	(as MT_P_I_IV)	Graphic mean-value Q (I+II) Trend, last 5 interval values, minimum and maximum
MT_Q_III_IV	(as MT_P_I_IV)	Graphic mean-value Q (III+IV) Trend, last 5 interval values, minimum and maximum
MT_S	(as MT_P_I_IV)	Graphic mean-value S: Trend, last 5 interval values, minimum and maximum
HO_IX		Graphic: Odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all currents
HO_UX	(as HO_IX)	Graphic: Odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all voltages
HE_IX	(as HO_IX)	Graphic: Even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all currents
HE_UX	(as HO_IX)	Graphic: Even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all voltages
HO_UX_MAX	(as HO_IX)	Graphic: Maximum values odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all voltages
HO_IX_MAX	(as HO_IX)	Graphic: Maximum values odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all currents
Name	Presentation	Description

HE_UX_MAX	(as HO_IX)	Graphic: Maximum values even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all voltages
HE_IX_MAX	(as HO_IX)	Graphic: Maximum values even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all currents
PHASOR		Graphic: All current and voltage phasors with present load situation

B1 Display matrices for single phase system

Display menu	Corresponding matrix				
 Instantaneous values	U UNE F	U_MM UNE_MAX F_MM	Pst1N	UD OD	
	I IN IMS	I_MAX IN_MAX			
	P Q S PF	P_MAX Q_MAX S_MAX			
	P_TRIANGLE				
	PF_MIN	Cφ_MIN			
 Energy Meter contents Standard meters	ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT				
 Energy Meter contents User meters	ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS				
 Energy Mean-values Power mean-values + trend	MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S
 Energy Mean-values User mean-values + trend	M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM		
	M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM		
	M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM		
 Energy Bimetal current	IB IB_MAX				

B2 Display matrices for split-phase (two-phase) systems

Display menu	Corresponding matrix																									
 Instantaneous values	<table><tr><td>U1N U2N U UNE</td><td>U1N_MM U2N_MM U_MM UNE_MAX</td><td>Pst1N Pst2N</td><td>UD12 UD1N UD2N</td><td>OD12 OD1N OD2N</td></tr><tr><td>I1 I2 IN IPE</td><td>I1_MAX I2_MAX IN_MAX IPE_MAX</td><td></td><td></td><td></td></tr><tr><td>P Q S PF</td><td>P1 P2 Q1 Q2</td><td>P_MAX Q_MAX S_MAX F_MM</td><td>P1_MAX P2_MAX Q1_MAX Q2_MAX</td><td></td></tr><tr><td>P_TRIANGLE</td><td>P1_TRIANGLE</td><td>P2_TRIANGLE</td><td></td><td></td></tr><tr><td>PF_MIN</td><td>Cφ_MIN</td><td></td><td></td><td></td></tr></table>	U1N U2N U UNE	U1N_MM U2N_MM U_MM UNE_MAX	Pst1N Pst2N	UD12 UD1N UD2N	OD12 OD1N OD2N	I1 I2 IN IPE	I1_MAX I2_MAX IN_MAX IPE_MAX				P Q S PF	P1 P2 Q1 Q2	P_MAX Q_MAX S_MAX F_MM	P1_MAX P2_MAX Q1_MAX Q2_MAX		P_TRIANGLE	P1_TRIANGLE	P2_TRIANGLE			PF_MIN	Cφ_MIN			
U1N U2N U UNE	U1N_MM U2N_MM U_MM UNE_MAX	Pst1N Pst2N	UD12 UD1N UD2N	OD12 OD1N OD2N																						
I1 I2 IN IPE	I1_MAX I2_MAX IN_MAX IPE_MAX																									
P Q S PF	P1 P2 Q1 Q2	P_MAX Q_MAX S_MAX F_MM	P1_MAX P2_MAX Q1_MAX Q2_MAX																							
P_TRIANGLE	P1_TRIANGLE	P2_TRIANGLE																								
PF_MIN	Cφ_MIN																									
 Energy Meter contents Standard meters	<table><tr><td>ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT</td></tr></table>	ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																								
ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																										
 Energy Meter contents User meters	<table><tr><td>ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS</td></tr></table>	ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																								
ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																										
 Energy Mean-values Power mean-values + trend	<table><tr><td>MT_P_I_IV</td><td>MT_P_II_III</td><td>MT_Q_I_II</td><td>MT_Q_III_IV</td><td>MT_S</td></tr></table>	MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																				
MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																						
 Energy Mean-values User mean-values + trend	<table><tr><td>M1 M2 M3 M4</td><td>TR_M1 TR_M2 TR_M3 TR_M4</td><td>M1_MM M2_MM M3_MM M4_MM</td></tr><tr><td>M5 M6 M7 M8</td><td>TR_M5 TR_M6 TR_M7 TR_M8</td><td>M5_MM M6_MM M7_MM M8_MM</td></tr><tr><td>M9 M10 M11 M12</td><td>TR_M9 TR_M10 TR_M11 TR_M12</td><td>M9_MM M10_MM M11_MM M12_MM</td></tr></table>	M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM	M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM	M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM																
M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM																								
M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM																								
M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM																								
 Energy Bimetal current	<table><tr><td>IB1 IB2 IB1_MAX IB2_MAX</td></tr></table>	IB1 IB2 IB1_MAX IB2_MAX																								
IB1 IB2 IB1_MAX IB2_MAX																										

B3 Display matrices for 3-wire system, balanced load

Display menu	Corresponding matrix																																			
 Instantaneous values	<table><tr><td>U12 U23 U31 F</td><td>U4C U4C_MAX ¹⁾</td><td>U12_MM U23_MM U31_MM F_MM</td><td>UR1 UR2 UR2R1 UR21_MAX</td><td>Pst12 Pst23 Pst31</td><td>UD12 UD23 UD31</td><td>OD12 OD23 OD31</td></tr><tr><td>I I_MAX IMS</td><td colspan="6">¹⁾ Only if measurement of homopolar voltage has been activated</td></tr><tr><td>P Q S PF</td><td colspan="2">P_MAX Q_MAX S_MAX</td><td colspan="4"></td></tr><tr><td>P_TRIANGLE</td><td colspan="6"></td></tr><tr><td>PF_MIN</td><td colspan="2">Cφ_MIN</td><td colspan="4"></td></tr></table>	U12 U23 U31 F	U4C U4C_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31	I I_MAX IMS	¹⁾ Only if measurement of homopolar voltage has been activated						P Q S PF	P_MAX Q_MAX S_MAX						P_TRIANGLE							PF_MIN	Cφ_MIN					
U12 U23 U31 F	U4C U4C_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31																														
I I_MAX IMS	¹⁾ Only if measurement of homopolar voltage has been activated																																			
P Q S PF	P_MAX Q_MAX S_MAX																																			
P_TRIANGLE																																				
PF_MIN	Cφ_MIN																																			
 Energy Meter contents Standard meters	ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																																			
 Energy Meter contents User meters	ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																																			
 Energy Mean-values Power mean-values + trend	<table><tr><td>MT_P_I_IV</td><td>MT_P_II_III</td><td>MT_Q_I_II</td><td>MT_Q_III_IV</td><td>MT_S</td></tr></table>	MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																														
MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																																
 Energy Mean-values User mean-values + trend	<table><tr><td>M1 M2 M3 M4</td><td>TR_M1 TR_M2 TR_M3 TR_M4</td><td>M1_MM M2_MM M3_MM M4_MM</td></tr><tr><td>M5 M6 M7 M8</td><td>TR_M5 TR_M6 TR_M7 TR_M8</td><td>M5_MM M6_MM M7_MM M8_MM</td></tr><tr><td>M9 M10 M11 M12</td><td>TR_M9 TR_M10 TR_M11 TR_M12</td><td>M9_MM M10_MM M11_MM M12_MM</td></tr></table>	M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM	M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM	M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM																										
M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM																																		
M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM																																		
M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM																																		
 Energy Bimetal current	IB IB_MAX																																			

B4 Display matrices for 3-wire systems, unbalanced load

Display menu	Corresponding matrix																							
 Instantaneous values	<table><tr><td>U12 U23 U31 F</td><td>U4C U4C_MAX ¹⁾</td><td>U12_MM U23_MM U31_MM F_MM</td><td>UR1 UR2 UR2R1 UR21_MAX</td><td>Pst12 Pst23 Pst31</td><td>UD12 UD23 UD31</td><td>OD12 OD23 OD31</td></tr><tr><td>I1 I2 I3 IPE</td><td>I1_MAX I2_MAX I3_MAX IPE_MAX</td><td>IR1 IR2 IR2R1 IR21_MAX</td><td colspan="4" rowspan="4">²⁾ Only if measurement of homopolar voltage has been activated</td></tr><tr><td>P Q S PF</td><td>P_MAX Q_MAX S_MAX</td><td></td></tr><tr><td>P_TRIANGLE</td><td></td><td></td></tr><tr><td>PF_MIN</td><td>Cφ_MIN</td><td></td></tr></table>	U12 U23 U31 F	U4C U4C_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31	I1 I2 I3 IPE	I1_MAX I2_MAX I3_MAX IPE_MAX	IR1 IR2 IR2R1 IR21_MAX	²⁾ Only if measurement of homopolar voltage has been activated				P Q S PF	P_MAX Q_MAX S_MAX		P_TRIANGLE			PF_MIN	Cφ_MIN	
U12 U23 U31 F	U4C U4C_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31																		
I1 I2 I3 IPE	I1_MAX I2_MAX I3_MAX IPE_MAX	IR1 IR2 IR2R1 IR21_MAX	²⁾ Only if measurement of homopolar voltage has been activated																					
P Q S PF	P_MAX Q_MAX S_MAX																							
P_TRIANGLE																								
PF_MIN	Cφ_MIN																							
 Energy Meter contents Standard meters	ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																							
 Energy Meter contents User meters	ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																							
 Energy Mean-values Power mean-values + trend	<table><tr><td>MT_P_I_IV</td><td>MT_P_II_III</td><td>MT_Q_I_II</td><td>MT_Q_III_IV</td><td>MT_S</td></tr></table>	MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																		
MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																				
 Energy Mean-values User mean-values + trend	<table><tr><td>M1 M2 M3 M4</td><td>TR_M1 TR_M2 TR_M3 TR_M4</td><td>M1_MM M2_MM M3_MM M4_MM</td></tr><tr><td>M5 M6 M7 M8</td><td>TR_M5 TR_M6 TR_M7 TR_M8</td><td>M5_MM M6_MM M7_MM M8_MM</td></tr><tr><td>M9 M10 M11 M12</td><td>TR_M9 TR_M10 TR_M11 TR_M12</td><td>M9_MM M10_MM M11_MM M12_MM</td></tr></table>	M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM	M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM	M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM														
M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM																						
M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM																						
M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM																						
 Energy Bimetal current	<table><tr><td>IB1 IB2 IB3</td><td>IB1_MAX IB2_MAX IB3_MAX</td></tr></table>	IB1 IB2 IB3	IB1_MAX IB2_MAX IB3_MAX																					
IB1 IB2 IB3	IB1_MAX IB2_MAX IB3_MAX																							

B5 Display matrices for 3-wire systems, unbalanced load, Aron

Display menu	Corresponding matrix																				
 Instantaneous values	<table><tr><td>U12 U23 U31 F</td><td>U4C U4C_MAX ¹⁾</td><td>U12_MM U23_MM U31_MM F_MM</td><td>UR1 UR2 UR2R1 UR21_MAX</td><td>Pst12 Pst23 Pst31</td><td>UD12 UD23 UD31</td><td>OD12 OD23 OD31</td></tr><tr><td>I1 I2 I3 IMS</td><td>I1_MAX I2_MAX I3_MAX</td><td colspan="5" rowspan="4">³⁾ Only if measurement of homopolar voltage has been activated</td></tr><tr><td>P Q S PF</td><td>P_MAX Q_MAX S_MAX</td></tr><tr><td>P_TRIANGLE</td><td></td></tr><tr><td>PF_MIN</td><td>Cφ_MIN</td></tr></table>	U12 U23 U31 F	U4C U4C_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31	I1 I2 I3 IMS	I1_MAX I2_MAX I3_MAX	³⁾ Only if measurement of homopolar voltage has been activated					P Q S PF	P_MAX Q_MAX S_MAX	P_TRIANGLE		PF_MIN	Cφ_MIN
U12 U23 U31 F	U4C U4C_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31															
I1 I2 I3 IMS	I1_MAX I2_MAX I3_MAX	³⁾ Only if measurement of homopolar voltage has been activated																			
P Q S PF	P_MAX Q_MAX S_MAX																				
P_TRIANGLE																					
PF_MIN	Cφ_MIN																				
 Energy Meter contents Standard meters	<table><tr><td>ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT</td></tr></table>	ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																			
ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																					
 Energy Meter contents User meters	<table><tr><td>ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS</td></tr></table>	ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																			
ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																					
 Energy Mean-values Power mean-values + trend	<table><tr><td>MT_P_I_IV</td><td>MT_P_II_III</td><td>MT_Q_I_II</td><td>MT_Q_III_IV</td><td>MT_S</td></tr></table>	MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S															
MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																	
 Energy Mean-values User mean-values + trend	<table><tr><td>M1 M2 M3 M4</td><td>TR_M1 TR_M2 TR_M3 TR_M4</td><td>M1_MM M2_MM M3_MM M4_MM</td></tr><tr><td>M5 M6 M7 M8</td><td>TR_M5 TR_M6 TR_M7 TR_M8</td><td>M5_MM M6_MM M7_MM M8_MM</td></tr><tr><td>M9 M10 M11 M12</td><td>TR_M9 TR_M10 TR_M11 TR_M12</td><td>M9_MM M10_MM M11_MM M12_MM</td></tr></table>	M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM	M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM	M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM											
M1 M2 M3 M4	TR_M1 TR_M2 TR_M3 TR_M4	M1_MM M2_MM M3_MM M4_MM																			
M5 M6 M7 M8	TR_M5 TR_M6 TR_M7 TR_M8	M5_MM M6_MM M7_MM M8_MM																			
M9 M10 M11 M12	TR_M9 TR_M10 TR_M11 TR_M12	M9_MM M10_MM M11_MM M12_MM																			
 Energy Bimetal current	<table><tr><td>IB1 IB2 IB3</td><td>IB1_MAX IB2_MAX IB3_MAX</td></tr></table>	IB1 IB2 IB3	IB1_MAX IB2_MAX IB3_MAX																		
IB1 IB2 IB3	IB1_MAX IB2_MAX IB3_MAX																				

B6 Display matrices for 4-wire systems, unbalanced load

Display menu	Corresponding matrix																																																																																																																																												
 Instantaneous values	<table><tr><td>U1N</td><td>U12</td><td>U1N_MM</td><td>U12_MM</td><td>UR1</td><td>Pst1N</td><td>UD1N</td><td>UD12</td><td>OD1N</td><td>OD12</td></tr><tr><td>U2N</td><td>U23</td><td>U2N_MM</td><td>U23_MM</td><td>UR2</td><td>Pst2N</td><td>UD2N</td><td>UD23</td><td>OD2N</td><td>OD23</td></tr><tr><td>U3N</td><td>U31</td><td>U3N_MM</td><td>U31_MM</td><td>U0</td><td>Pst3N</td><td>UD3N</td><td>UD31</td><td>OD3N</td><td>OD31</td></tr><tr><td>UNE</td><td>F</td><td>F_MM</td><td>UR21_MAX</td><td>UNB_UR2_UR1</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>I1</td><td>IN</td><td>I1_MAX</td><td>IN_MAX</td><td>IR1</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>I2</td><td>IPE</td><td>I2_MAX</td><td>IPE_MAX</td><td>IR2</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>I3</td><td>IMS</td><td>I3_MAX</td><td>IR21_MAX</td><td>IO</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>F</td><td></td><td></td><td></td><td>UNB_IR2_IR1</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>P</td><td>P1</td><td>Q1</td><td>S1</td><td>P1_MAX</td><td>Q1_MAX</td><td>S1_MAX</td><td></td><td></td><td></td></tr><tr><td>Q</td><td>P2</td><td>Q2</td><td>S2</td><td>P2_MAX</td><td>Q2_MAX</td><td>S2_MAX</td><td></td><td></td><td></td></tr><tr><td>S</td><td>P3</td><td>Q3</td><td>S3</td><td>P3_MAX</td><td>Q3_MAX</td><td>S3_MAX</td><td></td><td></td><td></td></tr><tr><td>PF</td><td>P</td><td>Q</td><td>S</td><td>P_MAX</td><td>Q_MAX</td><td>S_MAX</td><td></td><td></td><td></td></tr><tr><td colspan="2">P_TRIANGLE</td><td colspan="2">P1_TRIANGLE</td><td colspan="2">P2_TRIANGLE</td><td colspan="4">P3_TRIANGLE</td></tr><tr><td colspan="2">PF_MIN</td><td colspan="2">Cφ_MIN</td><td colspan="6"></td></tr></table>	U1N	U12	U1N_MM	U12_MM	UR1	Pst1N	UD1N	UD12	OD1N	OD12	U2N	U23	U2N_MM	U23_MM	UR2	Pst2N	UD2N	UD23	OD2N	OD23	U3N	U31	U3N_MM	U31_MM	U0	Pst3N	UD3N	UD31	OD3N	OD31	UNE	F	F_MM	UR21_MAX	UNB_UR2_UR1						I1	IN	I1_MAX	IN_MAX	IR1						I2	IPE	I2_MAX	IPE_MAX	IR2						I3	IMS	I3_MAX	IR21_MAX	IO						F				UNB_IR2_IR1						P	P1	Q1	S1	P1_MAX	Q1_MAX	S1_MAX				Q	P2	Q2	S2	P2_MAX	Q2_MAX	S2_MAX				S	P3	Q3	S3	P3_MAX	Q3_MAX	S3_MAX				PF	P	Q	S	P_MAX	Q_MAX	S_MAX				P_TRIANGLE		P1_TRIANGLE		P2_TRIANGLE		P3_TRIANGLE				PF_MIN		Cφ_MIN							
U1N	U12	U1N_MM	U12_MM	UR1	Pst1N	UD1N	UD12	OD1N	OD12																																																																																																																																				
U2N	U23	U2N_MM	U23_MM	UR2	Pst2N	UD2N	UD23	OD2N	OD23																																																																																																																																				
U3N	U31	U3N_MM	U31_MM	U0	Pst3N	UD3N	UD31	OD3N	OD31																																																																																																																																				
UNE	F	F_MM	UR21_MAX	UNB_UR2_UR1																																																																																																																																									
I1	IN	I1_MAX	IN_MAX	IR1																																																																																																																																									
I2	IPE	I2_MAX	IPE_MAX	IR2																																																																																																																																									
I3	IMS	I3_MAX	IR21_MAX	IO																																																																																																																																									
F				UNB_IR2_IR1																																																																																																																																									
P	P1	Q1	S1	P1_MAX	Q1_MAX	S1_MAX																																																																																																																																							
Q	P2	Q2	S2	P2_MAX	Q2_MAX	S2_MAX																																																																																																																																							
S	P3	Q3	S3	P3_MAX	Q3_MAX	S3_MAX																																																																																																																																							
PF	P	Q	S	P_MAX	Q_MAX	S_MAX																																																																																																																																							
P_TRIANGLE		P1_TRIANGLE		P2_TRIANGLE		P3_TRIANGLE																																																																																																																																							
PF_MIN		Cφ_MIN																																																																																																																																											
 Energy Meter contents Standard meters	ΣP_I_IV_HT ΣP_I_IV_NT ΣP_II_III_NT ΣP_II_III_HT ΣQ_I_II_HT ΣQ_I_II_NT ΣQ_III_IV_HT ΣQ_I_II_NT																																																																																																																																												
 Energy Meter contents User meters	ΣMETER1 ΣMETER2 ΣMETER3 ΣMETER4 ΣMETER5 ΣMETER6 ΣMETER7 ΣQ_I ΣQ_II ΣQ_III ΣQ_IV ΣS																																																																																																																																												
 Energy Mean-values Power mean-values + trend	<table><tr><td>MT_P_I_IV</td><td>MT_P_II_III</td><td>MT_Q_I_II</td><td>MT_Q_III_IV</td><td>MT_S</td></tr></table>	MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																																																																																																																																							
MT_P_I_IV	MT_P_II_III	MT_Q_I_II	MT_Q_III_IV	MT_S																																																																																																																																									
 Energy Mean-values User mean-values + trend	<table><tr><td>M1</td><td>TR_M1</td><td>M1_MM</td></tr><tr><td>M2</td><td>TR_M2</td><td>M2_MM</td></tr><tr><td>M3</td><td>TR_M3</td><td>M3_MM</td></tr><tr><td>M4</td><td>TR_M4</td><td>M4_MM</td></tr><tr><td>M5</td><td>TR_M5</td><td>M5_MM</td></tr><tr><td>M6</td><td>TR_M6</td><td>M6_MM</td></tr><tr><td>M7</td><td>TR_M7</td><td>M7_MM</td></tr><tr><td>M8</td><td>TR_M8</td><td>M8_MM</td></tr><tr><td>M9</td><td>TR_M9</td><td>M9_MM</td></tr><tr><td>M10</td><td>TR_M10</td><td>M10_MM</td></tr><tr><td>M11</td><td>TR_M11</td><td>M11_MM</td></tr><tr><td>M12</td><td>TR_M12</td><td>M12_MM</td></tr></table>	M1	TR_M1	M1_MM	M2	TR_M2	M2_MM	M3	TR_M3	M3_MM	M4	TR_M4	M4_MM	M5	TR_M5	M5_MM	M6	TR_M6	M6_MM	M7	TR_M7	M7_MM	M8	TR_M8	M8_MM	M9	TR_M9	M9_MM	M10	TR_M10	M10_MM	M11	TR_M11	M11_MM	M12	TR_M12	M12_MM																																																																																																								
M1	TR_M1	M1_MM																																																																																																																																											
M2	TR_M2	M2_MM																																																																																																																																											
M3	TR_M3	M3_MM																																																																																																																																											
M4	TR_M4	M4_MM																																																																																																																																											
M5	TR_M5	M5_MM																																																																																																																																											
M6	TR_M6	M6_MM																																																																																																																																											
M7	TR_M7	M7_MM																																																																																																																																											
M8	TR_M8	M8_MM																																																																																																																																											
M9	TR_M9	M9_MM																																																																																																																																											
M10	TR_M10	M10_MM																																																																																																																																											
M11	TR_M11	M11_MM																																																																																																																																											
M12	TR_M12	M12_MM																																																																																																																																											
 Energy Bimetal current	<table><tr><td>IB1</td><td>IB1_MAX</td></tr><tr><td>IB2</td><td>IB2_MAX</td></tr><tr><td>IB3</td><td>IB3_MAX</td></tr></table>	IB1	IB1_MAX	IB2	IB2_MAX	IB3	IB3_MAX																																																																																																																																						
IB1	IB1_MAX																																																																																																																																												
IB2	IB2_MAX																																																																																																																																												
IB3	IB3_MAX																																																																																																																																												

C Logic functions

The principal function of the logical gates is given in the following table, for simplicity shown for gates with two inputs only.

function	symbol	older symbols		truth table	plain text
		ANSI 91-1984	DIN 40700 (alt)		
AND				A B Y	Function is true if all input conditions are fulfilled
				0 0 0	
				0 1 0	
				1 0 0	
				1 1 1	
NAND				A B Y	Function is true if at least one of the input conditions is not fulfilled
				0 0 1	
				0 1 1	
				1 0 1	
				1 1 0	
OR				A B Y	Function is true if at least one of the input conditions is fulfilled
				0 0 0	
				0 1 1	
				1 0 1	
				1 1 1	
NOR				A B Y	Function is true if none of the input conditions is fulfilled
				0 0 1	
				0 1 0	
				1 0 0	
				1 1 0	

Using DIRECT or INVERT the input is directly connected to the output of a monitoring function, without need for a logical combination. For these functions only one input is used.

DIRECT		A Y	The monitoring function is reduced to one input only. The state of the output corresponds to the input.
		0 0	
		1 1	
INVERT		A Y	The monitoring function is reduced to one input only. The state of the output corresponds to the inverted input.
		0 1	
		1 0	

D FCC statement

The following statement applies to the products covered in this manual, unless otherwise specified herein. The statement for other products will appear in the accompanying documentation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules and meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003 for digital apparatus. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/T.V. technician for help.

Camille Bauer AG is not responsible for any radio television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Camille Bauer AG. The correction of interference caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

INDEX

A		Basic measurements81
Alarming.....	52	Bimetal current87
C		harmonic analysis.....85
Commissioning.....	24	Load factors.....83
Configuration		mean values and trend87
menu	44	meters88
Conformity report	64	system imbalance.....86
cosφ	82	zero displacement voltage.....84
Cyber Security decommissioning.....	73	Measurement displays42
Cyber Security notes.....	6	Measurements
Cyber Security policies.....	24	reset43
D		Mechanical mounting10
Device overview.....	7	Menu operation41
Dimensional drawing.....	80	Monitoring functions.....53
Display matrices.....	89	
E		N
Electrical connections		NTP29
Aron connection.....	17	
cross sections.....	12	O
digital input.....	20	Operating elements.....41
digital output.....	20	
inputs.....	12	P
Modbus interface.....	21	PQ event recordings59
power supply.....	12	PQ monitoring48
split phase.....	19	PQ statistic.....62
Elektrische Anschlüsse		PQDIF.....66
Analogausgang.....	20	PQ-Easy Report.....64
Ethernet installation.....	27	
F		R
FCC statement.....	102	Reactive power83
Firewall.....	30	Resetting measurements43
G		Roman numbers.....42
GPS.....	22	
H		S
HTTPS.....	37	Safety notes6
I		Scope of supply.....5
I, II, III, IV.....	42	Security system.....32
IEC61850.....	31	Service and maintenance.....73
Installation check.....	25	Simulation31
IRIG-B.....	23	Summary alarm.....54
L		Symbols43
Logic components		Symmetrical components.....86
AND.....	101	SYSLOG40
DIRECT.....	101	
INVERT.....	101	T
NAND.....	101	Technical data.....74
NOR.....	101	Time synchronization
OR.....	101	GPS.....22
Logic functions.....	101	IRIG-B.....23
M		NTP.....29
Measured quantities.....	81	
		U
		UPS (Uninterruptible power supply).....21
		W
		Whitelist.....37
		Z
		Zero suppression76