

Device handbook

LINAX PQ1000

LINAX PQ3000

LINAX PQ5000

Operating Instructions LINAX PQx000 (2025-05)



GMC INSTRUMENTS

Camille Bauer Metrawatt AG
Aargauerstrasse 7
CH-5610 Wohlen / Switzerland
Phone: +41 56 618 21 11
Telefax: +41 56 618 35 35
E-Mail: info@cbmag.com
<https://www.camillebauer.com>

 **CAMILLE BAUER**
GMC-INSTRUMENTS GROUP

Legal information

Warning notices

In this document warning notices are used, which you have to observe to ensure personal safety and to prevent damage to property. Depending on the degree of danger the following symbols are used:



If the warning notice is not followed death or severe personal injury **will** result.



If the warning notice is not followed damage to property or severe personal injury **may** result.



If the warning notice is not followed the device **may** be damaged or **may** not fulfill the expected functionality.



If the cyber security policies are not followed data **may** be disclosed to unauthorized users, manipulated or restricted in its availability by cyber security threats.

Qualified personnel

The product described in this document may be handled by personnel only, which is qualified for the respective task. Qualified personnel have the training and experience to identify risks and potential hazards when working with the product. Qualified personnel are also able to understand and follow the given safety and warning notices.

Intended use

The product described in this document may be used only for the application specified. The maximum electrical supply data and ambient conditions specified in the technical data section must be adhered. For the perfect and safe operation of the device proper transport and storage as well as professional assembly, installation, handling and maintenance are required.

Disclaimer of liability

The content of this document has been reviewed to ensure correctness. Nevertheless, it may contain errors or inconsistencies and we cannot guarantee completeness and correctness. This is especially true for different language versions of this document. This document is regularly reviewed and updated. Necessary corrections will be included in subsequent version and are available via our webpage <http://www.camillebauer.com>.

Feedback

If you detect errors in this document or if there is necessary information missing, please inform us via e-mail to: customer-support@camillebauer.com

Contents

1. Introduction	5
1.1 Purpose of this document	5
1.2 Scope of supply	5
1.3 Further documents	5
2. Safety and Cyber Security notes	6
2.1 Safety notes	6
2.2 Cyber Security notes	6
3. Device overview	7
3.1 Brief description	7
3.2 Overview of devices	8
3.3 Available measurement data	9
4. Mechanical mounting	10
4.1 Panel cutout PQ1000 / PQ3000	10
4.2 Panel mounting PQ1000 / PQ3000	10
4.3 Hat rail mounting PQ1000 / PQ5000	11
5. Electrical connections	13
5.1 General safety notes	13
5.2 Terminal assignments of the I/O extensions	15
5.2.1 LINAX PQ3000	15
5.2.2 LINAX PQ5000	15
5.3 Possible cross sections and tightening torques	16
5.4 Inputs	17
5.5 Rogowski current inputs	24
5.6 Power supply	24
5.7 Relays	25
5.8 Digital inputs	25
5.9 Digital outputs	27
5.10 Analog outputs	28
5.11 Fault current detection	29
5.12 Temperature inputs	31
5.13 Modbus interface RS485	31
5.14 Uninterruptible power supply (UPS)	32
5.15 GPS time synchronization	33
5.16 IRIG-B time synchronization	35
6. Commissioning	36
6.1 Cyber Security policies	37
6.2 Parametrization of the device functionality	38
6.3 Operating LED	39
6.4 Installation check	39
6.5 Ethernet installation	41
6.5.1 Settings	41
6.5.2 Connection of the standard interface	44
6.5.3 Connection of the IEC61850 interface	44
6.5.4 Connection of the PROFINET interface	44
6.5.5 MAC addresses	45
6.5.6 Resetting the communication settings	46
6.6 Communication tests	46
6.7 IEC 61850 interface	47
6.8 PROFINET IO interface	47
6.8.1 General stations description file (GSD)	47
6.8.2 Parameterization of the device	48
6.8.3 Validity of measurements	50
6.8.4 PROFINET state	50
6.9 Simulation of analog / digital outputs	51
6.10 Security system	51
6.10.1 RBAC management	51
6.10.2 User log in / out via website	55
6.10.3 User log in / out via local display	56
6.10.4 Whitelisting clients	57
6.10.5 Secure communication using https	57
6.10.6 Audit log (SYSLOG)	60

7. Operating the device	61
7.1 Operating elements	61
7.2 Selecting the information to display	61
7.3 Measurement displays and used symbols	62
7.4 Resetting measurement data	64
7.5 Configuration	64
7.5.1 Local configuration at the device	64
7.5.2 Configuration via web browser	66
7.6 PQ monitoring	68
7.6.1 PQ events	68
7.6.2 PQ statistic	70
7.6.3 Provision of PQ data	71
7.7 Alarming	72
7.7.1 Limit values on base quantities	72
7.7.2 Monitoring fault-currents	73
7.7.3 Temperature monitoring	74
7.7.4 Monitoring functions	75
7.7.5 Summary alarm	76
7.8 Data recording	77
7.8.1 Periodic data	77
7.8.2 User-defined events	81
7.8.3 PQ events	81
7.8.4 PQ statistic	85
7.8.5 Micro SD card (PQ3000 only)	89
7.9 Measurement information in file format	90
7.9.1 Predefined tasks	90
7.9.2 Creating periodic file data	92
7.9.3 Accessing file information via webpage	93
7.9.4 Download of PQIS files	94
7.9.5 Periodical sending to a SFTP Server	95
7.9.6 Evaluation of the PQDIF files	96
7.10 Display timeouts	96
8. Service, maintenance and disposal	97
8.1 Calibration and new adjustment	97
8.2 Cleaning	97
8.3 Batteries	97
8.4 Cyber Security Decommissioning	97
8.5 Disposal	97
9. Technical data	98
10. Dimensional drawings	106
Annex	109
A Description of measured quantities	109
A1 Basic measurements	109
A2 Harmonic analysis	113
A3 System imbalance	114
A4 Mean values and trend	115
A5 Meters	116
B Display matrices	117
B0 Used abbreviations for the measurements	117
B1 Display matrices for single phase system	123
B2 Display matrices for split-phase (two-phase) systems	124
B3 Display matrices for 3-wire system, balanced load	125
B4 Display matrices for 3-wire systems, unbalanced load	126
B5 Display matrices for 3-wire systems, unbalanced load, Aron	127
B6 Display matrices for 4-wire systems, unbalanced load	128
B7 Common display matrices	129
C Logic functions	130
D FCC statement	131
INDEX	132

1. Introduction

1.1 Purpose of this document

This document describes the universal measurement devices for heavy-current quantities LINAX PQ1000, PQ3000 and PQ5000. It is intended to be used by:

- Installation personnel and commissioning engineers
- Service and maintenance personnel
- Planners



Device with option PME central unit

The functionality, the installation and the commissioning of the PME system are described in the *system handbook option PME central unit*. This manual can be accessed via the product page of the base unit at <https://camillebauer.com> or downloaded from the website of the base unit via the menu Service | Device Information | Download manual.

Scope

This handbook is valid for all hardware versions of the devices. Some of the functions described in this document are available only, if the necessary optional components are included in the device.

Required knowledge

A general knowledge in the field of electrical engineering is required. For assembly and installation of the device knowledge of applicable national safety regulations and installation standard is required.

1.2 Scope of supply

- Measurement device
- Safety instructions (multiple languages)
- Mounting set: 2 mounting clamps (PQ1000 for panel mounting and PQ3000 only)
- Battery pack (optional, for PQ3000 and PQ5000 with UPS only)

1.3 Further documents

The following documents are provided electronically via

<https://www.camillebauer.com/pq1000-en> or

<https://www.camillebauer.com/pq3000-en> or

<https://www.camillebauer.com/pq5000-en>:

- Safety instructions
- Data sheet LINAX
- Modbus interface LINAX PQx000: Register description of Modbus RTU/TCP communication
- Modbus interface option PME central unit
- IEC61850 interface SINEAX AMx000/DM5000, LINAX PQx000, CENTRAX CUX000
- Camille Bauer certificate for encrypted HTTPS communication

2. Safety and Cyber Security notes

2.1 Safety notes



Device may only be disposed in a professional manner!

The installation and commissioning should only be carried out by trained personnel.

Check the following points before commissioning:

- that the maximum values for all the connections are not exceeded, see "Technical data" section,
- that the connection wires are not damaged, and that they are not live during wiring,
- that the power flow direction and the phase rotation are correct.

The instrument must be taken out of service if safe operation is no longer possible (e.g. visible damage). In this case, all the connections must be switched off. The instrument must be returned to the factory or to an authorized service dealer.

It is forbidden to open the housing and to make modifications to the instrument. The instrument is not equipped with an integrated circuit breaker. During installation check that a labeled switch is installed and that it can easily be reached by the operators.

Unauthorized repair or alteration of the unit invalidates the warranty.

2.2 Cyber Security notes



This device can record data (measurement data, events, logging of operating procedures, etc.). This data can represent an asset that is worthy of protection and must be protected against disclosure and modification, and its availability must be guaranteed. In order to achieve the greatest possible security with regard to cyber security threats, the following must be observed:

Security-relevant settings must be made during commissioning. See the policies in [chapter 6.1 Cyber Security policies](#)

The device software must be kept up to date during operation. Software updates are published on the manufacturer's website.

When decommissioning the device, security-relevant measures must be performed. See [chapter 8.4 Cyber security decommissioning](#).

3. Device overview

3.1 Brief description

The devices of the LINAX PQ series are comprehensive instruments for the universal measurement and monitoring in power systems. They provide a wide range of functions, which may be extended using optional components. The nameplate on the device gives further details about the present version. A connection to the process environment may be established by means of communication interfaces, via digital I/O's, analog outputs or relays. The parameterization of the device is possible directly at the device or via web browser.


The products of the LINAX PQ1000, PQ3000 and PQ5000 series are independently certified measurement devices of class A or S according to IEC 61000-4-30 Ed. 3. They provide reliable and comparable information for regulatory authorities, negotiations with energy suppliers or internal quality control.

Using additional, optional components the opportunities of the device may be extended. You may choose from I/O extensions, communication interfaces and uninterruptible power supply. The nameplate on the device gives further details about the present version.

Continuous monitoring analyses breakdowns immediately and eliminates their causes in a sustainable manner. In addition, long-term acquisition permits the early recognition of changes in order to improve supply security and thus system availability.

The flexible approach without any software excels both in autarchy and flexible software integration options. It is based on standardized interfaces, generates compliance reports directly via the device website and excels with a comprehensive cyber security concept.

3.2 Overview of devices

			
	PQ1000	PQ3000	PQ5000
Voltage inputs	4	5	5
Input channels current	3	4	4
Function class acc. IEC 61000-4-30	Class S	Class A	Class A
Device type acc. IEC 62586-1	PQI-S FI1	PQI-A FI1	PQI-A FI1
PQ COMPLIANCE MONITORING			
Power frequency	▪	▪	▪
Voltage / current variations	▪	▪	▪
Unbalance voltage / current	▪	▪	▪
THDS of voltages	▪	▪	▪
Harmonics voltage / current	▪	▪	▪
Flicker Pst / Plt	—	▪	▪
Mains signalling voltages	—	▪	▪
Interharmonics voltage / current	—	▪	▪
PQ EVENT RECORDING			
Voltage dip	▪	▪	▪
Voltage interruption	▪	▪	▪
Voltage swell	▪	▪	▪
Rapid voltage changes (RVC)	—	▪	▪
Homopolar voltage (unbalance)	▪	▪	▪
Current swell	▪	▪	▪
Frequency anomaly	▪	▪	▪
Ripple control sequences	—	▪	▪
State change of digital inputs	—	—	—
MEASUREMENT UNCERTAINTY			(for version with CT inputs)
Voltage, current	±0,2%	±0,1%	±0,1%
Active, reactive, apparent power	±0,5%	±0,2%	±0,2%
Active energy	Class 0.2S (/5A)	Class 0.2S	Class 0.2S
COMMUNICATION			
Ethernet: Modbus/TCP, Webserver,	(Standard)	(Standard)	(Standard)
IEC 61850	(Option)	(Option)	(Option)
PROFINET IO	(Option)	(Option)	(Option)
RS485: Modbus/RTU	(Standard)	(Standard)	(Standard)
Standard I/Os	1 Dig. OUT ; 1 Dig. IN/OUT	1 Dig. IN ; 2 Dig. OUT	1 Dig. IN ; 2 Dig. OUT
Extension modules (optional)	See order codes	See order codes	See order codes
POWER SUPPLY			
Consumption	100-230V AC/DC or 24-48V DC ≤18 VA, ≤8 W	110-230V AC/130-230V DC or 110-200V AC/DC or 24-48V DC ≤30 VA, ≤13 W	100-230V AC/DC or 24-48V DC ≤27 VA, ≤12 W
DESIGN			
Colour display	TFT 3,5" (320x240px)	TFT 5,0" (800x480px)	Option: TFT 3,5" (320x240px)
Dimensions	96 x 96 x 85 mm	144 x 144 x 65,2 mm	160 x 110 x 70 mm

3.3 Available measurement data

MEASURED VALUE GROUP	APPLICATION
INSTANTANEOUS VALUES • U, I, IMS, P, Q, S, PF, LF, QF ... • Angle between voltage phasors • Min/max of instantaneous values with time stamp	» Transparent monitoring of present system state » Fault detection, connection check, sense of rotation check » Determination of grid variable variance with time reference
EXTENDED REACTIVE POWER ANALYSIS • Total reactive power, fundamental frequency, harmonics • $\cos\phi$, $\tan\phi$ of fundamental frequency with min values in all quadrants	» Reactive power compensation » Verification of specified power factor
HARMONICS ANALYSIS (ACCORDING TO IEC 61000-4-7) • Total harmonics content THD U/I and TDD I • Individual harmonics / interharmonics U/I	» Evaluation of the thermic load of equipment » Analysis of system perturbation and consumer structure
IMBALANCE ANALYSIS • Symmetrical components (positive, negative, zero sequence system) • Imbalance (derived from symmetrical components) • Deviation from U/I mean value	» Equipment overload protection » Failure/earth fault detection
ENERGY BALANCE ANALYSIS • Meter for acquisition/supply of active/reactive energy, high/low-rate tariff, meter with selectable base variable • Power mean values active/reactive power, demand and supply, freely definable mean values (e.g. phase power, voltage, current and much more) • Mean value trends	» Preparation of (internal) energy billing » Determination of energy consumption versus time (load profile) for energy management or energy efficiency verification » Energy consumption trend analysis for load management
OPERATING HOURS • 3 operating hour counters with programmable running condition • Operating hours of the device	» Monitoring of service and maintenance intervals

Measurement data is provided via the following menus of the web-interface and, if available, the local display:

- Instantaneous values:** Present TRMS values and associated min/max values
- Energy:** Power mean-values with trend and history as well as energy meters. Mean-value progressions (load profiles) and periodic meter readings are also available.
- Harmonics:** Total harmonic distortion THD/TDD, individual harmonics and their maximum values, phase angle of the harmonics
- Phasor diagram:** Overview of all current and voltage phasors and phase sequence check
- Waveform** of current and voltage inputs
- Events:** Chronological lists of PQ events and self-defined alarms / events. State list of monitored alarms.
- PQ statistic:** Data of the statistical power quality analysis including a facility for PQ report creation

4. Mechanical mounting



Please ensure that the [operating temperature limits](#) are not exceeded when determining the place of mounting (place of measurement).




By installing, the device becomes part of an electrical power installation that must be designed, operated and maintained in accordance with country-specific regulations so that the installation is safe and provides prevention against fire and explosion as far as possible.



It is the task of this installation to ensure that dangerous connections of the device cannot be touched during operation and that the spread of flames, heat and smoke from the interior is prevented. This may be done by providing an enclosure (e.g. case, cabinet) or using a room accessible to qualified personal only and compliant with local fire safety standards.


4.1 Panel cutout PQ1000 / PQ3000



Dimensional drawing: [See section 10](#)

4.2 Panel mounting PQ1000 / PQ3000

The device is suitable for panel widths up to 8mm (PQ3000) resp. 10mm (PQ1000), shown below for a PQ3000.




- Slide the device into the cutout from the outside. Orientation as shown.
- From the side slide in the mounting clamps into the intended openings and pull them back about 2 mm
- Tighten the fixation screws until the device is tightly fixed with the panel

Demounting of the device


The demounting of the device may be performed only if all connected wires are out of service. Remove all plug-in terminals and all connections of the current and voltage inputs. Pay attention to the fact, that current transformers must be shortened before removing the current connections to the device. Then demount the device in the opposite order of mounting.

4.3 Hat rail mounting PQ1000 / PQ5000


The device can be clipped onto a top-hat rail according to EN 60715, orientation as shown below.





Dimensional drawing PQ1000:
[See section 10](#)




Dimensional drawing PQ5000:
[See section 10](#)



The **PQ1000 with display for hat-rail mounting** can also be mounted that the front of the device protrudes through a cut-out in the enclosure. So, the operating buttons and the display become accessible. With centric mounting using the below maximum cut-out a gap between enclosure and device results, which does not exceed 2.5mm on each side.



The **PQ5000 with display** can also be mounted that the front of the device protrudes through a cut-out in the enclosure. So, the operating buttons and the display become accessible. With centric mounting using the below maximum cut-out a gap between enclosure and device results, which does not exceed 2.5mm on each side.



5. Electrical connections




Ensure under all circumstances that the leads are free of potential when connecting them!

5.1 General safety notes



Please observe that the data on the type plate must be adhered to!


The national provisions have to be observed in the installation and material selection of electric lines, e.g. in Germany VDE 0100 "Erection of power installations with nominal voltages up to 1000 V"!



Nameplate of a PQ1000 with



- TFT display
- Ethernet interface
- Modbus/RTU interface
- 2 relay outputs

Hint: For the device version with display for hat-rail mounting the nameplate is divided into three plates.



Nameplate of a PQ3000 with

- Ethernet interface
- Modbus/RTU interface
- 2 relay outputs
- PME central unit



Nameplate of a PQ5000 with

- TFT display
- Ethernet interface
- Modbus/RTU interface
- 2 relay outputs
- 4 analog outputs
- UPS

Symbol	Meaning
	Device may only be disposed of in a professional manner!
	Double insulation, device of protection class 2
	CE conformity mark. The device fulfills the requirements of the applicable EU directives.
	Products with this mark comply with both the Canadian (CSA) and the American (UL) requirements.
	Caution! General hazard point. Read the operating instructions.
	General symbol: Power supply
	General symbol: Input
	General symbol: Output
CAT III	Measurement category CAT III

5.2 Terminal assignments of the I/O extensions

5.2.1 LINAX PQ3000

Function	Option 1	Option 2	Option 3
2 relay outputs	1.1: 51,52,53 1.2: 55,56,57	2.1: 61,62,63 2.2: 65,66,67	
2 analog outputs	1.1: 56(+), 57(-) 1.2: 55(+), 57(-)	2.1: 66(+), 67(-) 2.2: 65(+), 67(-)	3.1: 46(+), 47(-) 3.2: 45(+), 47(-)
4 analog outputs	1.1: 56(+), 57(-) 1.2: 55(+), 57(-) 1.3: 52(+), 53(-) 1.4: 51(+), 53(-)	2.1: 66(+), 67(-) 2.2: 65(+), 67(-) 2.3: 62(+), 63(-) 2.4: 61(+), 63(-)	3.1: 46(+), 47(-) 3.2: 45(+), 47(-) 3.3: 42(+), 43(-) 3.4: 41(+), 43(-)
4 digital inputs (active)	1.1: 51(-), 53(+) 1.2: 52(-), 53(+) 1.3: 55(-), 57(+) 1.4: 56(-), 57(+)	2.1: 61(-), 63(+) 2.2: 62(-), 63(+) 2.3: 65(-), 67(+) 2.4: 66(-), 67(+)	3.1: 41(-), 43(+) 3.2: 42(-), 43(+) 3.3: 45(-), 47(+) 3.4: 46(-), 47(+)
4 digital inputs (passive)	1.1: 51(+), 53(-) 1.2: 52(+), 53(-) 1.3: 55(+), 57(-) 1.4: 56(+), 57(-)	2.1: 61(+), 63(-) 2.2: 62(+), 63(-) 2.3: 65(+), 67(-) 2.4: 66(+), 67(-)	3.1: 41(+), 43(-) 3.2: 42(+), 43(-) 3.3: 45(+), 47(-) 3.4: 46(+), 47(-)
2 temperature inputs	1.1: 52,53 1.2: 56,57	2.1: 62,63 2.2: 66,67	3.1: 42,43 3.2: 46,47
IRIG-B (TTL)	55(-),56(Ω),57(+)	65(-),66(Ω),67(+)	

5.2.2 LINAX PQ5000

Function	Option 1	Option 2
2 relay outputs	1.1: X1.1 / X1.2 / X1.3 1.2: X2.1 / X2.2 / X2.3	2.1: X3.1 / X3.2 / X3.3 2.2: X4.1 / X4.2 / X4.3
2 analog outputs	1.1: X2.2(+) / X2.3(-) 1.2: X2.1(+) / X2.3(-)	2.1: X4.2(+) / X4.3(-) 2.2: X4.1(+) / X4.3(-)
4 analog outputs	1.1: X2.2(+) / X2.3(-) 1.2: X2.1(+) / X2.3(-) 1.3: X1.2(+) / X1.3(-) 1.4: X1.1(+) / X1.3(-)	2.1: X4.2(+) / X4.3(-) 2.2: X4.1(+) / X4.3(-) 2.3: X3.2(+) / X3.3(-) 2.4: X3.1(+) / X3.3(-)
4 digital inputs (active)	1.1: X1.1(-) / X1.3(+) 1.2: X1.2(-) / X1.3(+) 1.3: X2.1(-) / X2.3(+) 1.4: X2.2(-) / X2.3(+)	2.1: X3.1(-) / X3.3(+) 2.2: X3.2(-) / X3.3(+) 2.3: X4.1(-) / X4.3(+) 2.4: X4.2(-) / X4.3(+)
4 digital inputs (passive)	1.1: X1.1(+) / X1.3(-) 1.2: X1.2(+) / X1.3(-) 1.3: X2.1(+) / X2.3(-) 1.4: X2.2(+) / X2.3(-)	2.1: X3.1(+) / X3.3(-) 2.2: X3.2(+) / X3.3(-) 2.3: X4.1(+) / X4.3(-) 2.4: X4.2(+) / X4.3(-)
2 temperature inputs	1.1: X1.2 / X1.3 1.2: X2.2 / X2.3	2.1: X3.2 / X3.3 2.2: X4.2 / X4.3
IRIG-B (TTL)	X2.1(-), X2.2(Ω), X2.3(+)	X4.1(-), X4.2(Ω), X4.3(+)

5.3 Possible cross sections and tightening torques

Inputs L1(2), L2(5), L3(8), N(11), PE(16), I1(1-3), I2(4-6), I3(7-9), IN(10-12), power supply (13-14)	
Single wire	• 1 x 0,5...6.0mm² or 2 x 0,5...2.5mm² • 1 x 20 AWG...9 AWG or 2 x 20 AWG...14 AWG
Multiwire with end splices	• 1 x 0,5...4.0mm² or 2 x 0,5...2.5mm² • 1 x 20 AWG...11 AWG or 2 x 20 AWG...14 AWG
Tightening torque	• 0.5...0.6Nm • 4.42...5.31 lbf in
I/O's, relays, RS485 connector (A, B, C/X)	
Single wire	• 1 x 0.5 ... 2.5mm² or 2 x 0.5 ... 1.0mm² • 1 x 20 AWG...14 AWG or 2 x 20 AWG...17 AWG
Multiwire with end splices	• 1 x 0.5 ... 2.5mm² or 2 x 0.5 ... 1.5mm² • 1 x 20 AWG...14 AWG or 2 x 20 AWG...16 AWG
Tightening torque	• 0.5...0.6Nm • 4.42...5.31 lbf in



You may have to remove first the plug-in terminals to get access to the screw terminals of the current inputs.

5.4 Inputs



All **voltage measurement inputs** must originate at circuit breakers or fuses rated 5 Amps or less. This does not apply to the neutral connector. You have to provide a method for manually removing power from the device, such as a clearly labeled circuit breaker or a fused disconnect switch in accordance with IEC 60947-2 or IEC 60947-3.

When using **voltage transformers**, you have to ensure that their secondary connections never will be short-circuited.



No fuse may be connected upstream of the **current measurement inputs**!


When using **current transformers** their secondary connectors must be short-circuited during installation and before removing the device. Never open the secondary circuit under load.

Rogowski current inputs

For device versions with current measurement via Rogowski coils, current inputs are realized as voltage inputs. An example for the connection of Rogowski coils is shown in chapter 5.5.

Further hints

- The connection of the inputs depends on the configured system (connection type).
- PQ3000, PQ5000 only: In the connection diagrams on the next pages conventional voltage transformers are used. If a voltage transformer with **extra windings** for measuring the homopolar voltage is applied, connections should be as shown below.



In order for the homopolar voltage to be measured, the item „Measure homopolar voltage“ must be set to „Yes“ in the settings of the measurement. This item is only available for 3-wire system types.

Single-phase AC mains


PQ3000 / PQ5000

PQ1000


Direct connection




Maximum permissible rated voltage 300V to ground!




If current I_N or voltage U_{NE} does not need to be measured, connection of IN or PE can be omitted.




With current transformers




If current I_N does not need to be measured, the corresponding transformer can be omitted. If voltage U_{NE} does not need to be measured, connection of PE can be omitted.



With current and voltage transformers



If current I_N or voltage U_{NE} does not need to be measured, the corresponding transformers can be omitted.



Three wire system, balanced load, current measurement via L1


PQ3000 / PQ5000

PQ1000

Direct connection



Maximum permissible rated voltage 300V to ground (520V ph-ph)!



Three wire system, unbalanced load



PQ3000 / PQ5000

PQ1000



Direct connection





Maximum permissible rated voltage 300V to ground (520V ph-ph)!



With current transformers



With current and voltage transformers



Three wire system, unbalanced load, Aron connection



PQ3000 / PQ5000

PQ1000



Direct connection





Maximum permissible rated voltage 300V to ground (520V ph-ph)!



With current transformers



With current and voltage transformers




Four wire system, unbalanced load

PQ3000 / PQ5000

Direct connection




Maximum permissible rated voltage 300V to ground (520V ph-ph)!




If current I_N or voltage U_{NE} does not need to be measured, connection of IN or PE can be omitted.


PQ1000




With current transformers




If current I_N does not need to be measured, the corresponding transformer can be omitted. If voltage U_{NE} does not need to be measured, connection of PE can be omitted.



With current and voltage transformers



If current I_N does not need to be measured, the corresponding transformer can be omitted.




Split-phase ("two phase system"), unbalanced load

PQ3000 / PQ5000

Direct connection




Maximum permissible rated voltage 300V to ground (600V ph-ph)!




If current I_N or voltage U_{NE} does not need to be measured, connection of IN or PE can be omitted.


PQ1000




With current transformers



If current I_N does not need to be measured, the corresponding transformer can be omitted. If voltage U_{NE} does not need to be measured, connection of PE can be omitted.




With current and voltage transformers




If current I_N does not need to be measured, the corresponding transformer can be omitted.

In systems without a primary neutral conductor a voltage transformer with a secondary center tap can also be used.





5.5 Rogowski current inputs

The connection of the Rogowski coils is performed depending on the selected system type, as shown in chapter 5.4 above. However, instead of current transformers a Rogowski coils is placed around each current-carrying conductor. This is subsequently shown for the measurement in a 4-wire low-voltage system.



When connecting the coils, you must follow the safety notices given in the operating instructions of the Rogowski coil. The current direction shown on the coils must match the real current direction and has to be the same for all phases.



In order to suppress injected interferences the shielding (green) is connected always to the I terminal of the current inputs (terminals 3, 6, 9, 12).

5.6 Power supply



A marked and easily accessible current limiting switch in accordance with IEC 60947-2 has to be arranged in the vicinity of the device for turning off the power supply. Fusing should be 10 Amps or less and must be rated for the available voltage and fault current.


5.7 Relays




When the device is switched off the relay contacts are de-energized, but dangerous voltages may be present.

Relays are available for device versions with corresponding I/O extensions only.

PQ1000




PQ3000



Option y	x
1	5
2	6

PQ5000



5.8 Digital inputs

The device provides a standard passive digital input. In addition, depending on the device version, there may be 4-channel passive or active digital input modules available.

Usage of the standard digital input

- Status input
- Meter tariff switching

Usage of the inputs of the optional input modules



- Counting input for pulses of meters for any kind of energy (pulse width 70...250ms)
- Operating feedback of loads for operating time counters
- Trigger and release signal for monitoring functions

Passive inputs (external power supply with 12 / 24 VDC required)





The power supply shall not exceed 30V DC!

PQ1000





Option



Technical data



Input current	< 7,0 mA
Logical ZERO	- 3 up to + 5 V
Logical ONE	8 up to 30 V

PQ3000



Option y	x
1	5
2	6
3	4

PQ5000



Technical data

Input current	< 7,0 mA
Logical ZERO	- 3 up to + 5 V
Logical ONE	8 up to 30 V

Active inputs (no external power supply required)

Technical data (acc. EN62053-31, class B)

Open circuit voltage ≤ 15 V


Short circuit current < 15 mA

Current at $R_{ON}=800\Omega \geq 2 \text{ mA}$



PQ1000



Example with meter pulse and status inputs





PQ3000



Option y	x
1	5
2	6
3	4

PQ5000



Example with meter pulse and status inputs

5.9 Digital outputs

The device has two standard digital outputs for which an external 12 / 24 VDC power supply is required.




The power supply shall not exceed 30V DC!

Usage as digital output


- ▶ Alarm output
- ▶ State reporting
- ▶ Pulse output to an external counter (acc. EN62053-31)
- ▶ Remote controlled output

PQ1000




¹⁾ Recommended if input impedance of counter > 100 kΩ

PQ3000



¹⁾ Recommended if input impedance of counter > 100 kΩ

PQ5000




Driving a counter mechanism

The width of the energy pulses can be selected within a range of 30 up to 250ms, but have to be adapted to the external counter mechanism.

Electro mechanical meters typically need a pulse width of 50...100ms.

Electronic meters are partly capable to detect pulses in the kHz range. There are two types: NPN (active negative edge) and PNP (active positive edge). For this device a PNP is required. The pulse width has to be $\geq 30\text{ms}$ (acc. EN62053-31). The delay between two pulses has to be at least the pulse width. The smaller the pulse width, the higher the sensitivity to disturbances.




Driving a relay

Rated current	50 mA (60 mA max.)
Switching frequency (S0)	$\leq 20\text{ Hz}$
Leakage current	0.01 mA
Voltage drop	< 3 V


5.10 Analog outputs

Analog outputs are available for devices with corresponding I/O extensions only. See nameplate. Analog outputs may be remote controlled.

PQ1000




PQ3000



Option y	x
1	5
2	6
3	4

PQ5000



Connection to an analog input card of a PLC or a control system

The device is an isolated measurement device. The module outputs are galvanically connected, but the modules isolated from each other. To reduce the influence of disturbances shielded a twisted-pair cables should be used. The shield should be connected to earth on both opposite ends. If there are potential differences between the ends of the cable the shield should be earthed on one side only to prevent from equalizing currents.

Under all circumstances consider as well appropriate remarks in the instruction manual of the system to connect.

5.11 Fault current detection

Each fault current module provides **two channels** for monitoring differential or fault currents in earthed AC current systems. In any case, measurement has to be performed via suitable current transformers, a direct measurement is not possible. The module is not suited for monitoring operating currents of normally live conductors (L1, L2, L3, N).

Measurement ranges

Each channel provides two measurement ranges:

a) Measurement range 1A

- Application: Direct measurement of a fault or earth wire current
- Meas. transformer: Current transformer 1/1 up to 1000/1A; 0.2 up to 1.5VA;
Instrument security factor FS5

b) Measurement range 2mA

- Application: Residual current monitoring (RCM)
- Meas. transformer: Residual current transformer 500/1 up to 1000/1A
Rated burden 100 Ω / 0.025 VA up to 200 Ω / 0.06 VA



Use only transformers intended for this application, according to our current transformer catalog, or transformers that fulfill the above specification. Using transformers with divergent specifications may damage the measurement inputs.

Connection

PQ1000

$\ominus$ I >	2
(50/60 Hz)	
COM 2mA 1A	
27 26 25	

Option

$\ominus$ I >	1
(50/60 Hz)	
COM 2mA 1A	
23 22 21	

PQ3000

x1	x2	x3
1A	2mA	COM
$\ominus$ I >		
(50/60 Hz)	1	

Option y

x5	x6	x7
1A	2mA	COM
$\ominus$ I >		
(50/60 Hz)	2	

Option y	x
1	5
2	6
3	4

PQ5000

X1	Option 1	X2
$\ominus$ I >	(50/60 Hz)	
1A 2mA C		1A 2mA C
1 1 2 3		2 1 2 3

X3	Option 2	X4
$\ominus$ I >	(50/60 Hz)	
1A 2mA C		1A 2mA C
1 1 2 3		2 1 2 3



The current transformers including the conductor isolation must guarantee in total a reinforced or double insulation between the mains circuit connected on the primary side and the measuring inputs of the device.




Only one measurement range may be connected per measuring channel!



The COM connectors of both measurement channels are internally connected.




For 2mA inputs a connection monitoring (breakage) is implemented. An alarm state is signaled for the respective measurement channels if either the current transformer is disconnected or the connection to the transformer is interrupted.



Example: Fault current monitoring in a TNS system

Hints

- (1) If the current transformers for the fault current detection needs to be grounded on the secondary side this has to be done via the COM connector.
- (2) Note that all conductors have to pass through the opening of the residual current transformer in the same direction.
- (3) A possible fault current flows through the protective earth conductor (PE). It can only be detected if the PE conductor is *not* routed through the residual current transformer. If this cannot be avoided, e.g. due to using a multi-wire cable with all conductors, the PE conductor must be returned through the transformer.
- (4) The cable or individual conductors should be routed through the transformer as centered as possible in order to minimize measurement errors.
- (5) Neither the current transformers nor the measurement leads should be mounted or installed close to strong magnetic fields. Measurement lines should also not be laid in parallel to power lines.
- (6) *For measurement range 1A only:* The rated output of the transformer must be chosen that it is reached when the rated secondary current (1A) flows. Consider that the burden of the transformer is not only made up by the burden of the measurement input, but also by the resistance of the measurement lines and the self-consumption of the transformer (copper losses).
 - A rated output selected too low leads to saturation losses in the transformer. The secondary rated current can no longer be reached as the transformer reaches its limits before.
 - A rated output selected too high or an exceeding instrument security factor (>FS5) may cause damage to the measuring inputs in case of overload.
- (7) For the connection of the transformer to the fault detection module use ...
 - Conductor cross sections of 1.0 up to 2.5mm² (16-14 AWG)
 - Pairwise twisted conductors in case of short cable lengths
 - Shielded cables (shield grounded on one side only) in disturbed environment or in case of long cable lengths



5.12 Temperature inputs

Each temperature module provides **two channels** for temperature monitoring. They can be used in two ways:

a) Temperature measurement via Pt100 sensor


- Measurement range: -50 up to 250°C
- 2 configurable alarm limits
- Configurable alarm delay time for ON / OFF
- Short circuit and wire / sensor breakage monitoring

b) Temperature monitoring with PTC sensors


- Monitoring the PTC response temperature
- Short circuit monitoring
- Serial connection of up to 6 sensors or up to 2 triplet sensors

Connection


PQ1000




Option



PQ3000





Option y




Option y	x
1	5
2	6
3	4

PQ5000



5.13 Modbus interface RS485

Via the optional Modbus interface measurement data may be provided for a superior system. However, the Modbus interface cannot be used for device parameterization.



1) One ground connection only.
This is possibly made within the master (PC).

Rt: Termination resistors: 120 Ω each
for long cables (> approx. 10 m)

Rs: Bus supply resistors,
390 Ω each

The signal wires (A, B) have to be twisted. GND (X) can be connected via a wire or via the cable shield. In disturbed environments shielded cables must be used. Supply resistors (Rs) have to be present in bus master (PC) interface. Stubs should be avoided when connecting the devices. A pure line network is ideal. You may connect up to 32 Modbus devices to the bus.

Modbus RTU enabled	no ▼
Baud rate	115.2kBd ▼
Parity	none parity ▼
Stop bits	2 ▼
Device address	1

A proper operation requires that all devices connected to the bus have equal communication settings (baud rate, transmission format) and unique device addresses. Use the appropriate menu in the settings of communication.

If a Modbus/RTU interface is present but not required, communication may be disabled for security reasons.

The bus system is operated half duplex and may be extended to a maximum length of 1200 m without repeater.

5.14 Uninterruptible power supply (UPS)

Hint: This option is not available for the PQ1000.

The [battery pack](#) for the uninterruptible power supply is supplied separately. Please note that compared to the storage temperature range of the base unit the [storage temperature range](#) of the battery pack is restricted.

Ensure that devices with uninterruptible power supply are used in an environment in accordance with the [specification](#). Outside this operating temperature range, it is not ensured that the battery pack is recharged.

Due to aging the capacity of the battery decreases. To ensure a successful operation of the device during power interruptions the battery needs to be replaced every 3 up to 5 years.



Potential for Fire or Burning. Do not disassemble, crush, heat or burn the removed battery pack.

Replace battery pack with a [battery pack of the same type](#) only. Use of another battery may present a risk of fire or explosion.

5.15 GPS time synchronization

The optional GPS connection module serves for connecting a GPS receiver as a very accurate time synchronization source for the measurement device. The GPS receiver, available as an accessory, is used as outdoor antenna to process data from multiple GPS satellites simultaneously.

GPS receiver

Only use the receiver **Garmin GPS 16x-LVS** (article no. 181'131), offered as an accessory. This device is preconfigured by us and provides the required time information (sentences) without further configuration effort.

- Protection: IPx7 (waterproof)
- Operating temperature: -30...80°C
- Storage temperature: -40...80°C
- 1Hz pulse accuracy: 1µs
- Connector: RJ45



Choosing a mounting location


For a correct operation the GPS receiver requires data from at least 3 satellites at the same time. Therefore, position the receiver so that the clearest possible view of the sky and horizon in all direction is obtained. This can be on the roof of a building, at best without reception being restricted by other buildings or obstacles. Avoid mounting the receiver next to large areas of conductible material, as this may cause poor signal reception. It should be also not closer than 1 meter away from any other antenna.



If lightning protection is required, this must be provided by the user.

Mounting the GPS receiver

- The GPS receiver **Garmin GPS 16x-LVS** can be flush mounted by means of 3 M4 screws.
- 120° distribution over a circle of $\varnothing 71.6\text{mm}$
- Thread length max. 8mm. Using longer screws may damage the GPS receiver.



Connecting the GPS receiver



Never connect the RJ45 socket of the connecting cable directly to a network device such as a router or switch. These devices could be damaged.

The GPS receiver is plugged directly into the GPS connection module. The connection cable has a length of 5 m. It may be extended using an RJ45 coupling and an Ethernet cable. The connection cable should not be laid in parallel to live conductors. Twisting or sharp kinking of the cable should be avoided.

Commissioning

- In the settings menu change time synchronization to „NTP server / GPS / IRIG-B “
- Check the time synchronization status

> Service > Device information > Device state

Min/max values reset	Device version	IPv4 mask: 255.255.255.0 [dhcp]
Meter contents set/reset	Device license	IPv4 Gtw: 192.168.56.5 [dhcp]
Operating hours	Device state	IPv6 Gtw: -
Device information		Name servers -----
Factory reset		DNS 1: 192.168.56.44 [dhcp]
Firmware update		DNS 2: 192.168.56.144 [dhcp]
Communication Tests		Time sources -----
Device reboot		Source 1: pool.ntp.org [NTP1]
		Source 2: GPS / IRIG-B
		Source 3: Local clock
		Time synchronisation -----
		GPS/IRIG-B at stratum 1
		Time offset: -0.001735 ms
		Root dispersion: 1.150 ms
		GPS/IRIG-B status -----
		Synchronised to GPS Timeserver
		Number of satellites 5
		GPS quality: Estimated fix
		Modbus -----
		RTU: Running
		TCP: Stopped

- The time synchronization can be restarted by switching the time synchronization off and on again.
- Time synchronization via GPS / IRIG-B and NTP server may work in parallel. If both synchronization sources are available, the system uses the more accurate time source, which is normally GPS or IRIG-B.



When connecting a GPS receiver for the first time or when it has been out of operation for a long time, it may take up to 1 hour for finding enough satellites for GPS receiver operation and thus for a reliable time synchronization.

5.16 IRIG-B time synchronization

The optional IRIG-B connection module can use TTL signals of an IRIG-B time server as a very accurate time synchronization source for the measurement device. The supported protocols are B004, B005, B006 and B007.

PQ1000

IRIG-B TTL		
+	Ω	-
27	26	25

Option

PQ3000

x5	x6	x7
-	Ω	+
IRIG-B TTL		

Option y	x
1	5
2	6

PQ5000

X1	Option 1	X2
	IRIG-B TTL	
	- Ω +	
	1 2 3	

or

X3	Option 2	X4
	IRIG-B TTL	
	- Ω +	
	1 2 3	



With a low-impedance IRIG-B source, a terminating resistor of 50 Ω can be connected to the last receiver by bridging the «-» and « Ω » terminals

Commissioning

- In the settings menu change time synchronization to „NTP server / GPS / IRIG-B “
- Check the time synchronization status

> Service > Device information > Device state

Min/max values reset	Device version	LINK: yes
Meter contents set/reset	Device license	Speed: 100Mb/s
Operating hours	Device state	IPv4 Addr: 192.168.1.101 [stat]
Device information		IPv4 BC: 192.168.1.255 [stat]
Factory reset		IPv4 Mask: 255.255.255.0 [stat]
Firmware update		IPv4 Gtw: 192.168.1.1 [stat]
Communication Tests		IPv6 Gtw: -
Device reboot		Name servers -----
		Time sources -----
		Source 1: pool.ntp.org [NTP1]
		Source 2: GPS / IRIG-B
		Source 3: Local clock
		Time synchronisation -----
		GPS/IRIG-B at stratum 1
		Time offset: -0.002543 ms
		Root dispersion: 1.210 ms
		GPS/IRIG-B status -----
		Synchronised to IRIG-B Timeserver
		Modbus -----
		RTU: Running
		TCP: Running


- The time synchronization can be restarted by switching the time synchronization off and on again.
- Time synchronization via GPS / IRIG-B and NTP server may work in parallel. If both synchronization sources are available, the system uses the more accurate time source, which is normally GPS or IRIG-B.

6. Commissioning




Before commissioning you have to check if the connection data of the device match the data of the plant (see nameplate).

If so, you can start to put the device into operation by switching on the power supply and the measurement inputs.




LINAX PQ1000

- Measurement input
 - Input voltage
 - Input current
 - System frequency
- 1 Serial number
- 2 Test and conformity marks
- 3 Assignment voltage inputs
- 4 Assignment current inputs
- 5 Assignment power supply
- 6 Load capacity relay outputs



LINAX PQ3000

- Measurement input
 - Input voltage
 - Input current
 - System frequency
- 1 Serial number
- 2 Test and conformity marks
- 3 Assignment voltage inputs
- 4 Assignment current inputs
- 5 Assignment power supply
- 6 Load capacity relay outputs



6.1 Cyber Security policies



Activation of firewall

To protect data (sub billing, energy efficiency data, power monitoring data, grid power quality data, syslog data, timestamps) from unauthorized access, the IP-based whitelist shall be activated immediately during the first commissioning of the device.



Configuration interface

To protect the device configuration from unauthorized manipulation, the role-based access control system shall be activated and configured to define the rights of the individual roles.



Passwords

To protect the device configuration from unauthorized manipulation, the users defined in the role-based access control system shall use strong passwords. The access credentials must be safely stored (e.g. do not affix any stickers with access data to the device).



UI access to measurement data

To protect the measured and/or recorded data from unauthorized disclosure, the role-based access control system shall be activated and configured to define the access rights of the individual roles.



SD-Card (PQ3000)

To protect data (sub billing, energy efficiency data, power monitoring data, grid power quality data, syslog data, timestamps) from unauthorized access, the access to the SD card has to be protected by limitation of physical access to authorized persons.



Modbus RTU interface

To protect data (sub billing, power monitoring data, grid power quality data) from unauthorized access, the Modbus RTU interface shall be deactivated if the interface is not used.



Modbus TCP interface

To protect data (sub billing, power monitoring data, grid power quality data) from unauthorized access, the Modbus TCP interface shall be deactivated if the interface is not used.

**IEC 61850 interface**

To protect the data (sub billing, power monitoring data, grid power quality data) from unauthorized access, do not connect the IEC 61850 interface if it is not used.

**PROFINET interface**

To protect data (sub billing, power monitoring data, grid power quality data) from unauthorized access, do not connect the Profinet interface if it is not used.

**Scheduled export**

To protect data from unauthorized access, the export interface of the device shall be deactivated if the interface is not used.

**NTP interface**

The NTP protocol does not offer any protection mechanisms against manipulation of data, e.g. by a “man in the middle” scenario. Therefore, if NTP synchronization is not used in the application, the time synchronization shall be disabled to protect the device against manipulation of time and timestamping information.

**Syslog interface**

The syslog protocol does not offer any protection mechanisms against manipulation of data, e.g. by a “man in the middle” scenario. Therefore, to protect the syslog data from unauthorized access, the syslog interface of the device shall be deactivated if the interface is not used.

**External I/O data**

External I/O data that is collected or emitted by the device is not subject by the device's protection mechanisms against disclosure, manipulation or loss of availability. It is the responsibility of the product user to take appropriate protective measures (e.g. physical access restriction).

6.2 Parametrization of the device functionality

A full parameterization of all functions of the device is possible directly at the device or via web browser. This assumes that user has the required access rights.


For security reasons, the security features “Users and Permissions” (RBAC) and “Web security” (HTTPS) may be activated. In this case, before the device webpage can be displayed using https, you have to [install a root certificate](#), which is provided via our homepage. Once the certificate is downloaded to the local computer the certificate can be installed manually. Just double-click on the file, and install the certificate as a trusted root certification authority.

See: [Configuration \(7.5\)](#)

6.3 Operating LED



PQ5000



PQ1000

The operating LED (only P5000 and PQ1000 without display) shows the present device state.


Procedure	LED display
Bootling of device	- Flashes green (1 Hz) - If successful: Change to static green display
Firmware update	- Change to update mode: Static red - During update: Flashes red (1 Hz) - If successful or cancelled: Bootling of device
Factory reset or reset of communication settings	- During reset: Flashes red (1 Hz) - Then (for a factory reset): Bootling of device

6.4 Installation check

The correct connection of the current and voltage inputs can be checked in two ways.

- a) **Sense of rotation check:** Using the sequence of the current and voltage phasors the sense of rotation is determined and compared to the configured one. The phase rotation indicator is arranged in the menu "Phasor diagram".

Test requirement: Magnitude of all connected voltages at least 5% of nominal, magnitude of all connected currents at least 0.2% of nominal.








Possible results

-  Correct sense of rotation
-  Wrong sense of rotation
-  Missing phase or magnitude too small

- b) **Phasor verification:** The phasor diagram shows a technical visualization of the current and voltage phasors, using a counter-clockwise rotation, independent of the real sense of rotation.



The diagram is always built basing on the voltage of the reference channel (direction 3 o'clock)

 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.60</td><td>230.64</td><td>230.54</td><td>V</td></tr><tr><td>0.00</td><td>-119.97</td><td>120.03</td><td>*</td></tr><tr><td>85.97</td><td>86.03</td><td>85.86</td><td>A</td></tr><tr><td>-22.9</td><td>-21.7</td><td>-20.0</td><td>*</td></tr><tr><td>0.921</td><td>0.929</td><td>0.940</td><td>PF</td></tr></table>	L1	L2	L3		230.60	230.64	230.54	V	0.00	-119.97	120.03	*	85.97	86.03	85.86	A	-22.9	-21.7	-20.0	*	0.921	0.929	0.940	PF	Correct installation (expectation) - Voltage sequence in clock-wise order L1 → L2 → L3 ($0^\circ \rightarrow -120^\circ \rightarrow 120^\circ$) - Current sequence in clock-wise order L1 → L2 → L3 - Similar angle between voltage and current phasors in all phases (approx. -20°)
L1	L2	L3																								
230.60	230.64	230.54	V																							
0.00	-119.97	120.03	*																							
85.97	86.03	85.86	A																							
-22.9	-21.7	-20.0	*																							
0.921	0.929	0.940	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.58</td><td>230.63</td><td>230.53</td><td>V</td></tr><tr><td>0.00</td><td>-119.97</td><td>120.03</td><td>*</td></tr><tr><td>85.96</td><td>86.04</td><td>85.87</td><td>A</td></tr><tr><td>-22.9</td><td>158.4</td><td>-20.0</td><td>*</td></tr><tr><td>0.921</td><td>-0.930</td><td>0.940</td><td>PF</td></tr></table>	L1	L2	L3		230.58	230.63	230.53	V	0.00	-119.97	120.03	*	85.96	86.04	85.87	A	-22.9	158.4	-20.0	*	0.921	-0.930	0.940	PF	What's wrong? - Voltage sequence: L1 → L2 → L3 - Current sequence: L1 → L3 → L2; Current L2 is out of the expected sequence - Angle U-I: Angle between U_{L2} and I_{L2} is approx. 180° wrong Required correction Reversing the polarity of current I_2
L1	L2	L3																								
230.58	230.63	230.53	V																							
0.00	-119.97	120.03	*																							
85.96	86.04	85.87	A																							
-22.9	158.4	-20.0	*																							
0.921	-0.930	0.940	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.59</td><td>230.49</td><td>230.70</td><td>V</td></tr><tr><td>0.00</td><td>120.04</td><td>-119.99</td><td>*</td></tr><tr><td>85.97</td><td>86.02</td><td>85.86</td><td>A</td></tr><tr><td>-22.9</td><td>98.3</td><td>-140.0</td><td>*</td></tr><tr><td>0.921</td><td>-0.145</td><td>-0.766</td><td>PF</td></tr></table>	L1	L2	L3		230.59	230.49	230.70	V	0.00	120.04	-119.99	*	85.97	86.02	85.86	A	-22.9	98.3	-140.0	*	0.921	-0.145	-0.766	PF	What's wrong? - Voltage sequence: L1 → L3 → L2; L3 and L2 seems to be interchanged - Current sequence: L1 → L2 → L3 - Angle U-I: Angles between U_{L2} / I_{L2} and U_{L3} / I_{L3} do not correspond to the expectations Required correction Exchanging the connections of the voltages L2 and L3
L1	L2	L3																								
230.59	230.49	230.70	V																							
0.00	120.04	-119.99	*																							
85.97	86.02	85.86	A																							
-22.9	98.3	-140.0	*																							
0.921	-0.145	-0.766	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.58</td><td>230.49</td><td>230.68</td><td>V</td></tr><tr><td>0.00</td><td>120.04</td><td>-119.99</td><td>*</td></tr><tr><td>85.97</td><td>86.04</td><td>85.86</td><td>A</td></tr><tr><td>-22.9</td><td>-81.6</td><td>-140.0</td><td>*</td></tr><tr><td>0.921</td><td>0.145</td><td>-0.766</td><td>PF</td></tr></table>	L1	L2	L3		230.58	230.49	230.68	V	0.00	120.04	-119.99	*	85.97	86.04	85.86	A	-22.9	-81.6	-140.0	*	0.921	0.145	-0.766	PF	What's wrong? - Voltage sequence: L1 → L3 → L2; L3 and L2 seems to be exchanged - Current sequence: L1 → L3 → L2; Current L2 is out of the expected sequence - Angle U-I: Angles between U_{L2} / I_{L2} and U_{L3} / I_{L3} do not correspond to the expectations Required correction Exchanging the connections of the voltages L2 and L3 and reversing the polarity of the current input I_2
L1	L2	L3																								
230.58	230.49	230.68	V																							
0.00	120.04	-119.99	*																							
85.97	86.04	85.86	A																							
-22.9	-81.6	-140.0	*																							
0.921	0.145	-0.766	PF																							
 50V/div 20A/div	<table><tr><th>L1</th><th>L2</th><th>L3</th><th></th></tr><tr><td>230.45</td><td>230.48</td><td>230.58</td><td>V</td></tr><tr><td>0.00</td><td>-120.02</td><td>119.98</td><td>*</td></tr><tr><td>85.96</td><td>86.00</td><td>85.86</td><td>A</td></tr><tr><td>-143.0</td><td>-141.6</td><td>-140.0</td><td>*</td></tr><tr><td>-0.798</td><td>-0.784</td><td>-0.766</td><td>PF</td></tr></table>	L1	L2	L3		230.45	230.48	230.58	V	0.00	-120.02	119.98	*	85.96	86.00	85.86	A	-143.0	-141.6	-140.0	*	-0.798	-0.784	-0.766	PF	What's wrong? - Voltage sequence: L1 → L2 → L3 - Current sequence: L3 → L1 → L2 - Angle U-I: The U-I angles do not correspond to the expectation, but are similar Required correction Cyclical exchange of the voltage connections: $L1 \rightarrow L3$, $L2 \rightarrow L1$, $L3 \rightarrow L2$. As an alternative the sequence of all currents may be changed as well (more effort required).
L1	L2	L3																								
230.45	230.48	230.58	V																							
0.00	-120.02	119.98	*																							
85.96	86.00	85.86	A																							
-143.0	-141.6	-140.0	*																							
-0.798	-0.784	-0.766	PF																							

6.5 Ethernet installation

6.5.1 Settings

Before devices can be connected to an existing Ethernet network, you have to ensure that they will not disturb the normal network service. The rule is:



None of the devices to connect is allowed to have the same IPv4/v6 address than another device already installed

The device supports both IPv4 and IPv6 communication. IPv4 communication is activated by default; IPv6 can be activated additionally via configuration.

IPv4 communication

Depending on the device version, there may be multiple Ethernet interfaces with different default IPv4 addresses.

Interface	Application	Default IPv4	Settings via menu
Standard	Configuration / Modbus TCP	192.168.1.101	Settings Communication Ethernet
IEC 61850	IEC61850 communication	192.168.1.111	Settings IEC61850 Ethernet
PROFINET	PROFINET communication	0.0.0.0	(exclusively via control system)

IPv6 communication

Depending on the device version, there may be multiple Ethernet interfaces with different default IPv6 addresses, once the IPv6 communication is activated.

Interface	Application	Default IPv6	Settings via menu
Standard	Configuration / Modbus TCP	fd2d:bb44:97f1:3976::1	Settings Communication Ethernet
IEC 61850	IEC61850 communication	fd2d:bb44:97f1:3976::B	Settings IEC61850 Ethernet
PROFINET	PROFINET communication	0::0	(exclusively via control system)

Network settings (Communication | Ethernet)

The following settings have to be arranged with the network administrator:

• IPv4/6: Mode	Defines how the IP address of the device is assigned. The assignment can be statically, via DHCP or SLAAC (IPv6 only).
• IPv4/6: IP address	Must be unique , i.e. may be assigned in the network only once
• IPv4: Subnet mask	Defines how many devices are directly addressable in the IPv4 network. This setting is equal for all the devices. Examples
• IPv4/6: Gateway address	Is used to resolve addresses during communication between different networks. It should contain a valid address within the directly addressable network
• IPv4/6: DNS-Server x	Is used to resolve a domain name into an address, if e.g. a name (pool.ntp.org) is used for the NTP server. Further information
• IPv6: Prefix length	Is comparable to the subnet mask in IPv4 networks; it is the number of the leftmost bits of the site prefix which need to be identical for direct communication.
• Hostname	Individual designation for each device. Via the hostname the device can be uniquely identified in the network. Therefore, for each device a unique name should be assigned.
• NTP-Server x	NTP servers are used as base for time synchronization
• Modbus TCP enabled	If Modbus/TCP communication is not required it may be disabled for security reasons.
• Modbus/TCP port	Selection of the TCP port to be used for Modbus/TCP communication. Standard setting is 502. See also TCP ports .

IPv4: Mode	Static ▼
IPv4: IP address	192.168.62.25
Subnet mask	255.255.248.0
IPv4: Gateway address	192.168.56.5
IPv4: DNS server 1	192.168.56.55
IPv4: DNS server 2	192.168.56.155
IPv6: Mode	Static ▼
IPv6: IP address	fd2d:bb44:97f1:3976::3
IPv6: Prefix length	64
IPv6: Gateway address	fd2d:bb44:97f1:3976::5:1
IPv6: DNS server 1	
IPv6: DNS server 2	
Host name	PQ5000Exxxxx
Clock synchronization	NTP server / GPS ▼
NTP server 1	pool.ntp.org
NTP server 2	
Modbus TCP enabled	yes ▼
Modbus TCP port	502

Network settings of Standard interface

IP address	192.168.62.103
Subnet mask	255.255.248.0
Gateway address	192.168.56.5
DNS server 1	192.168.56.55
DNS server 2	192.168.56.155
Host name	PQ5000-IEC61850-RR
Clock synchronization	NTP server ▼
NTP server 1	pool.ntp.org
NTP server 2	

Network settings of IEC61850 interface

IPv4: Subnet mask

For a direct communication between device and PC both devices need to be in the same network when the subnet mask is applied:

Example 1	decimal	binary
IP address	192.168. 1.101	11000000 10101000 00000001 01100101
Subnet mask	255.255.255.224	11111111 11111111 11111111 11100000
	variable range	xxxxxx
First address	192.168. 1. 96	11000000 10101000 00000001 01100000
Last address	192.168. 1.127	11000000 10101000 00000001 01111111

► The device 192.168.1.101 can access directly the devices 192.168.1.96 ... 192.168.1.127


Example 2	decimal	binary
IP address	192.168. 57. 64	11000000 10101000 00111001 01000000
Subnet mask	255.255.252. 0	11111111 11111111 11111100 00000000
	variable range	xx xxxxxxxx
First address	192.168. 56. 0	11000000 10101000 00111000 00000000
Last address	192.168. 59.255	11000000 10101000 00111011 11111111

► The device 192.168.57.64 can access directly the devices 192.168.56.0 ... 192.168.59.255

IPv4: Mode >> DHCP

If a DHCP server is available, alternatively the mode „**DHCP**“ or „**DHCP, addresses only**“ can be selected for the Standard interface. The device then gets all necessary information from the DHCP server. The difference between the two modes is that for “DHCP” also the DNS server address is obtained.

The settings obtained from the DHCP server can be retrieved locally via the service menu.



Depending on the settings of the DHCP server the provided IP address can change on each reboot of the device. Thus, it's recommended to use the DHCP mode during commissioning only.

The option DHCP is not available for devices without display.

Time synchronization via NTP protocol

For the *time synchronization* of devices via Ethernet *NTP* (Network Time Protocol) is the standard. Corresponding time servers are used in computer networks, but are also available for free via Internet. Using NTP it's possible to hold all devices on a common time base.

Two different NTP servers may be defined. If the first server is not available the second server is used for trying to synchronize the time.

If a public NTP server is used, e.g. “pool.ntp.org”, a name resolution is required. This normally happens via a **DNS server**. So, the IP address of the DNS server must be set in the communication settings of the Ethernet interface to make a communication with the NTP server, and thus time synchronization, possible. Your network administrator can provide you the necessary information.

The time synchronization of the Standard interface can be performed also by means of a [GPS receiver](#) or an [IRIG-B time server](#) with TTL signals.

TCP ports

The TCP communication is done via so-called ports. The number of the used port allows determining the type of communication. As a standard Modbus/TCP communication is performed via TCP port 502, NTP uses port 123. However, the port for the Modbus/TCP communication may be modified. You may provide a unique port to each of the devices, e.g. 503, 504, 505 etc., for an easier analysis of the communication traffic. Independent of these setting a communication via port 502 is always supported. The device allows at least 5 connections to different clients at the same time.

Firewall

Due to security reasons, nowadays each network is protected by means of a firewall. When configuring the firewall, you have to decide which communication is desired and which have to be blocked. The TCP port 502 for the Modbus/TCP communication normally is considered to be unsafe and is often disabled. This may lead to a situation where no communication between networks (e.g. via Internet) is possible.

6.5.2 Connection of the standard interface

The RJ45 connector serves for direct connecting an Ethernet cable.


- Interface: RJ45 socket, Ethernet 100BaseTX
- Mode: 10/100 MBit/s, full / half duplex, Auto-negotiation
- Protocols: http, https, Modbus/TCP, NTP

Functionality of the LED's


PQ1000



PQ3000



PQ5000



- LED right: Switched on as soon as a network connection exists (link)
- LED left: Flashes during communication with the device (activity)


6.5.3 Connection of the IEC61850 interface

The RJ45 sockets X1 and X2 serve for direct connecting Ethernet cables. Both ports are equivalent and internally connected via a switch.


- Interface: RJ45 sockets, Ethernet 100BaseTX
- Mode: 10/100 MBit/s, full / half duplex, auto-negotiation
- Protocols: IEC61850, NTP

Functionality of the LED's


PQ1000



PQ3000



PQ5000



- LED green: On if a network connection (link) exists, flashes during communication

6.5.4 Connection of the PROFINET interface


The RJ45 sockets X1 and X2 serve for direct connecting Ethernet cables. Both ports are equivalent and internally connected via a switch.

Note: The interface may only be connected to a local Profinet network, which is designed as SELV circuit according to IEC 60950-1.


- Interface: RJ45 sockets, Ethernet 100BaseTX
- Mode: 10/100 MBit/s, full / half duplex, auto-negotiation
- Protocols: PROFINET, LLDP, SNMP

Functionality of the LED's

PQ1000



PQ3000



PQ5000



LED	State	Meaning
X1 green X2 green	OFF	No network connection
	ON	Existing network connection
	Flashing	Active communication
Red left BF (Bus failure)	OFF	No error
	ON	No configuration, slow or no link
	Flashing (2 Hz)	No data exchange
Red right SF (System failure)	OFF	No error
	ON	Watchdog timeout, diagnosis active; System failure
	Flashing (1 Hz, 3s)	DCP signal service via bus initiated

6.5.5 MAC addresses

For uniquely identifying Ethernet connections in a network, a unique MAC address is assigned to each connection. Compared to the IP address, which may be modified by the user at any time, the MAC address is static.

Standard Ethernet interface

PQ1000

PQ1000 -1111 0D
Ord.: 000/123456/123/001
Man: 21 / 8
MAC: 00:12:34:26:07:3F

PQ3000

PQ 3000 -1112 131D
Ord.: 000/123456/123/001
Man: 15 / 33
MAC: 00:12:34:1D:00:97

PQ5000

PQ5000-1111 1130
MAC: 00:12:34:1F:00:64
Ord.: 000/123456/123
Man: 16 / 5

IEC61850 Ethernet interface

PQ1000

MAC: 00:12:34:21:00:7C
X2 IEC 61850 X1

PQ3000

X1 IEC 61850 X2
MAC: 00:12:34:21:00:7C

PQ5000

X1 IEC 61850 X2
MAC: 00:12:34:21:00:7C

PROFINET Ethernet interface

PQ1000

MAC: 00:12:34:22:00:0C
X2 PROFINET X1

PQ3000

X1 PROFINET X2
MAC: 00:12:34:22:00:0C

PQ5000

X1 PROFINET X2
MAC: 00:12:34:22:00:0C

Typically, for a PROFINET device [3 MAC addresses](#) are required:

- Chassis MAC: as given on the nameplate
- Port connector X1: Chassis MAC + 2
- Port connector X2: Chassis MAC + 1


6.5.6 Resetting the communication settings

If the communication settings of the Standard interface are no longer known, on devices with a display these settings may be locally displayed and modified. For devices without display this is not possible. The communication settings can then be reset to default settings via the reset button.



PQ5000

Press the sunk-in reset button (located below the operating LED) for at least 3s. During the reset the operating LED flashes red.



PQ1000

Press the sunk-in reset button (located on the left of the operating LED) for at least 3s. For that the nameplate needs to be penetrated. During the reset the operating LED flashes red.

6.6 Communication tests

Via the service menu on the device website you may check if the selected network structure is valid. The device must be able to reach the DNS server via gateway. The DNS server then allows resolving the URL of the NTP server to an IP address. The Standard Ethernet interface serves as interface for the communication tests.

- Ping: Connection test to any network device (initial: gateway address)
- DNS: Test, if the name resolution via DNS works (initial: URL of NTP server)
- NTP: Test, if the selected NTP-Server is in fact a time server (stratum x)
- SFTP: Test, if access to SFTP server works. A test file will be copied to the base directory of the server.

IPv4: Ping

192.168.56.5

Test

IPv6: Ping

fd2d:bb44:97f1:3976::5:1

Test

DNS

192.168.56.55

192.168.56.55

Test

NTP

pool.ntp.org

Test

SFTP server

tenserv.camillebauer.intra

22

data

sftpuser

....

Test

```
Testing NTP 'pool.ntp.org'
=====
server 176.10.99.200, stratum 2, offset -0.000689, delay 0.03264
server 162.159.200.123, stratum 3, offset 0.000510, delay 0.03139
server 84.16.67.12, stratum 1, offset -0.000664, delay 0.03560
server 5.148.175.134, stratum 2, offset -0.000103, delay 0.03174
23 Apr 14:29:06 ntpdate[5257]: adjust time server 84.16.67.12 offset -0.000664 sec
```

NTP server test

6.7 IEC 61850 interface

The features of the IEC61850 interface are described in a separate document:

>> IEC61850 interface SINEAX AMx000/DM5000, LINAX PQx000, CENTRAX CUx000

This document is available via:

- <https://www.camillebauer.com/pq1000-en> or
- <https://www.camillebauer.com/pq3000-en> or
- <https://www.camillebauer.com/pq5000-en>

6.8 PROFINET IO interface


The PROFINET interface provides a cyclical process image, which can be freely assembled by the user.

6.8.1 General stations description file (GSD)


The GSD file describes the functionality available via the PROFINET interface of the device. During system design by means of a configuration tool (e.g. TIA or Simatic Step 7 of Siemens) the GSD file serves to implement devices with a minimum effort.

The description language of the GSD file for PROFINET is GSDML (Generic Station Description Markup Language), thus a language independent XML format. Sources for the download of the GSDML file of the device are:


- <https://www.camillebauer.com/pq1000-en> or
<https://www.camillebauer.com/pq3000-en> or
<https://www.camillebauer.com/pq5000-en>
- USB stick with software and documentation, no.156'027 (optional)
- The website of the device itself:



Before a device can be used in a project, the associated GSD file must be imported in the configuration tool (e.g. TIA Portal).



6.8.2 Parameterization of the device




As soon as the GSD file has been imported, the device is available in the hardware catalog and can be integrated using drag&drop. There are three models available that represent the different designs of the whole device series. The selection shown above is for example suited for the devices AM2000, AM300 and PQ3000, which have the same design (panel 144x144mm) and support the same measured values.

Further steps during parameterization are:

- Assigning a unique device name via DCP protocol
- Assigning an IP address to the device, normally an automatic procedure
- Assembly of the cyclical process image (see below), maximum of 62 measurements
- Integration in the topology of the complete system

Because these steps are device independent and do rely on the used tool only, further details are not given here.



Assembly of the cyclical process image

In Slot 1 always the module 'System state' is present providing the following information:

Bit	Meaning
0	0: Measurement system stopped or not reachable 1: Measurement system running
1	0 ↔ 1: When the measurement system is running, the bit changes its state when the value of at least one of the modules changes
2...31	not used, currently set to 0

Hints

- A parameterization of the base functionality of the device (such as the measurement functionality) via PROFINET is not required
- A local modification of parameters (e.g. IP address, PROFINET device name) is not possible

6.8.3 Validity of measurements

The following measurements can be used in the process image:

- Instantaneous values of voltages, currents, active/reactive/apparent power, frequency, load factor
- THD voltages and currents, TDD currents
- Odd harmonics of voltages and currents up to the 25th
- Symmetrical components and unbalance factors of voltage/current
- Fundamental power, distortion reactive power, $\cos\varphi$, $\tan\varphi$
- Energy meters high and low tariff, pre- and user-defined base quantities
- Mean-values, predefined power quantities and user-defined base quantities

The provided measurements are the sum of all possible values, for all system configuration from single phase up to 4-wire unbalanced. The Modbus device description provides the information about the validity of the measurements with respect to the used system configuration. This description can be downloaded via one of the following sources:

- <https://www.camillebauer.com/pq1000-en> or
<https://www.camillebauer.com/pq3000-en> or
<https://www.camillebauer.com/pq5000-en>
- USB stick with software and documentation, no.156'027 (optional)

If invalid measurements are used in the process image, their values are always zero.

6.8.4 PROFINET state

- For devices with display the present PROFINET state is shown in the status bar:

	Data exchange with IO controller inactive
	Data exchange with IO controller active

- The PROFINET status is always visible in the status bar on the device website:

	Data exchange with IO controller inactive
	Data exchange with IO controller active


- PROFINET related information may be accessed via the menu *Service | PROFINET | PROFINET Status*:

<pre>IO controller ===== Connected: No Device name: IP address: IO device ===== Device name: am3000 Network settings ----- IP address: 192.168.1.201 Subnet mask: 255.255.255.0 Gateway addr.: 192.168.1.1 MAC addresses ----- Chassis: 00:12:34:22:00:09 Port X2: 00:12:34:22:00:0A Port X1: 00:12:34:22:00:0B</pre>	<pre>IO controller ===== Connected: Yes Device name: plcxb1d0ed IP address: 192.168.1.2 IO device ===== Device name: am3000 Network settings ----- IP address: 192.168.1.201 Subnet mask: 255.255.255.0 Gateway addr.: 192.168.1.1 MAC addresses ----- Chassis: 00:12:34:22:00:09 Port X2: 00:12:34:22:00:0A Port X1: 00:12:34:22:00:0B</pre>
<i>Data exchange with IO controller inactive</i>	<i>Data exchange with IO controller active</i>

6.9 Simulation of analog / digital outputs

To check if subsequent circuits will work properly with output values provided by the device, using the service menu **Simulation** all analog or digital / relay outputs may be simulated. This is done by either entering analog output values or selecting discrete states for the digital outputs / relays.

Simulation is possible via webpage and as well via the local display.



Simulation of digital outputs via device webpage

6.10 Security system

There are several security mechanisms implemented in the device which can be activated to provide a comprehensive access protection to all device data.

- The **role-based access control (RBAC)** system allows restricting the access to measured data, configuration settings and service functions to the rights granted to the present user. For access via website or local display this is done by reducing the available menus and / or providing only read access rights to specific services. For accessing data via external applications an API (Application Programming Interface) key is required, which needs to be implemented as a special user.
- **HTTPS** provides encrypted communication using TLS (Transport Layer Security)
- Via **client whitelist** access to the device can be restricted to specific clients with definable IP addresses
- **Communication blocking:** Communication services, such as Modbus/RTU, Modbus/TCP or SYSLOG are blocked by default and must be actively enabled via configuration. This way unauthorized access may be prevented and possible intruding points eliminated.
- **Security log:** The device stores all security related messages in a separate list accessible via the service menu. The content of this list can also be transferred to a central log-server using the **SYSLOG** protocol for security auditing.

If the device is equipped with a display, restrictions defined in the security system also take effect when operating the device via the local display. It is also possible to restrict users to local access only.

6.10.1 RBAC management

Each access to device data via website, local display or external software applications can be comprehensively protected using the role-based access control (RBAC) system. This way, access to measured value information, the change of configuration parameters or the resetting / deletion of measurement data can be individually adapted to the role of the active user.

Note: All settings of the security system are stored in the device in encrypted form only; login credentials are never transmitted in plain text.

A maximum of 8 users is supported

➤ **3 pre-defined standard users**

- *admin*: A user with administrator rights (Default setting password: „CBM_1234“)
- *localgui*: The standard user for the local display. Its permissions determine what can be displayed or changed via the built-in display without a user having to log in.
- *anonymous*: The standard user for access via device website. Its permissions determine what can be displayed or changed via the website without a user having to log in.

➤ **Up to 5 definable users or API keys**

Users or API keys may be created by each user with write access to the settings of the security system. In any case, each user with a web login can change the password of its own account.


Application programming interface (API) keys are used to allow applications to access device data via REST interface (communication via http/https protocol). Such keys are timely unlimited and have either read-only permissions, all permissions or all permissions except security.

The pre-defined administrator or any other user with full access rights to the settings of the security system can:


- Change its own credentials (user name and/or password)
- Change the credentials (user name and/or password) of any other user
- Freely define the permissions of the standard users *localgui* and *anonymous*; both users are standard users without login credentials
- Create new users up to a maximum of 5
- Restrict users to local operation only (no login via website)

Adding users / API keys

In addition to the 3 predefined users a maximum of 5 users or API keys may be created. To do so, use “Add user / API key” and select the type of user to be created.



Users: During password definition the requirements for a secure password are checked and the result is displayed. Each new user can be created based on the permission template of an already existing user, but all of these permissions may be changed later.





When defining / changing passwords the following restrictions must be considered:

- Password length 8 up to 32 characters
- At least three different types of characters must be used (uppercase, lowercase, numbers, special characters)



CAUTION: If login credentials (user name and / or password) of users with write access to the security system are changed, this information must be kept safe. For security reasons resetting the RBAC system can only be done at the factory, no backdoor is implemented.

API key: Along with the key name you have to define the permissions to be granted to the application using the key via REST interface. The resulting access rights cannot be changed afterwards.

Create API key

Key name: PLC_Access

Permission template: Read-only permission

Buttons: Save, Back

Dropdown options: Read-only permissions, All permissions except security, All permissions

Once the API key is created it can be displayed using  "Show API key"

API key

API key value: eyJhbGciOiJIUzI1NiIsInR5cCI6IkpXVCJ9.eyJhdWQiOiIiXyJg4IiwiaWF0IjoxNTc5MTU4OTc4LCJzZW50Ii0iJhbm9ueWlvdXMiLCJ0eG4iOiIiXOTIuMTY4LjU4LjExNCJ9.LiLjuJcs2bZAmYHlvdMXTAlr87gxUX-3kZ4cfz6jdMc;h57otulwFPxiOy3SGmmj5At1la0NjK-ID4JA

Button: Ok

When the application wants to communicate via REST interface with the device, it has to provide the API key and the session token via the cookie field in the request header, e.g.:

Cookie:

```
AccessToken=eyJhbGciOiJIUzI1NiIsInR5cCI6IkpXVCJ9.eyJhdWQiOiIiXyJg4IiwiaWF0IjoxNTc5MTU4OTc4LCJzZW50Ii0iJhbm9ueWlvdXMiLCJ0eG4iOiIiXOTIuMTY4LjU4LjExNCJ9.LiLjuJcs2bZAmYHlvdMXTAlr87gxUX-3kZ4cfz6jdMc;
sessionToken={5d1ca47c-8d38-4a08-85d5-feb941fa20}
```

Further information is provided in the document "http interface SINEAX PQx000"

Assignment of user rights

The assignment of the user rights granted for operation is done via the menu Settings | Security system | Users and permissions:

Users and Permissions enabled

Add user/ API key

	admin	localgui	anonymous	operator1	operator2	operator3	[API]Access token
Local account (no weblogin)	☐	☒	☐	☐	☐	☐	☐
Instantaneous values							
Energy							
Harmonics							
Phasor diagram							
Waveform							
Events							
PQ statistic							
Service							
Reset values							
Reset/Update device							
Audit Log							
Use IO simulation							
Settings							
Basic device settings							
Measurement							
Communication							
Security system							



Measurements or settings can be displayed



Measurements or settings cannot be displayed



Settings can be changed



Settings cannot be changed



Field not selectable




Change a user's login credentials

Overview of the access rights of each possible user

6.10.2 User log in / out via website

a) If “anonymous” has no granted permissions

Via website	Remarks
	1) Enter user name and password 2) Press <ENTER> or select “Login” If successful, depending on the permissions of the user logged in, the appropriate website is displayed

b) If “anonymous” has granted permissions



Via website	Remarks
	1) Click on the symbol  2) Enter user name and password. On first login use the default settings admin / CBM_1234. 3) Press <ENTER> or select “Login” If successful, depending on the permissions of the user logged in, the appropriate website is displayed

c) If another user is already logged in


Via website	Remarks
	Log out the current user by selecting “Logout” 1) Click on the symbol  2) Enter user name and password 3) Press <ENTER> or select “Login” If successful, depending on the permissions of the user logged in, the appropriate website is displayed

6.10.3 User log in / out via local display



a) If “localgui” has no granted permissions

Locally	Remarks
	No information is displayed on the screen. Press <ESC> to enter the login screen.
	1) Press <OK> to enter the user name 2) Proceed to password using ▼ 3) Press <OK> to enter the password 4) Proceed to Login and press <OK> If successful, depending on the permissions of the user logged in, the appropriate menu is displayed.

b) If localgui has granted permissions

Locally	Remarks
	Repeatedly press <ESC> until the login screen is displayed. 1) Press <OK> to enter the user name 2) Proceed to password using ▼ 3) Press <OK> to enter the password 4) Proceed to Login and press <OK> If successful, depending on the permissions of the user logged in, the appropriate menu is displayed

c) If another user is already logged in

Locally	Remarks
	Repeatedly press <ESC> until the login screen is displayed. Log out the current user by selecting “Logout” Depending on the permissions of localgui either a menu or the lock symbol is displayed
	Repeatedly press <ESC> until the login screen is displayed. 1) Press <OK> to enter the user name 2) Proceed to password using ▼ 3) Press <OK> to enter the password 4) Proceed to Login and press <OK> If successful, depending on the permissions of the user logged in, the appropriate menu is displayed.

6.10.4 Whitelisting clients

Whitelist	
On	
Client 1	192.168.58.3
Client 2	192.168.58.7
Client 3	192.168.59.3
Client 4	192.168.62.5
Client 5	
Client 6	
Client 7	
Client 8	
Client 9	
Client 10	

It is possible to define a list of IPv4 and/or IPv6 addresses of up to 10 clients allowed to have access to the device. All other clients will be blocked. Enable the whitelist via the *Settings* of the *Security system* in the item *Whitelist*.



If a DHCP server is used in the system, clients may get different IP addresses on each startup, losing this way access to the device.

If a device is no longer accessible you can reset its IP address (LAN), deactivating the whitelist at the same time.

6.10.5 Secure communication using https

HTTPS protocol provides encrypted communication using TLS (Transport Layer Security). Such as bidirectional encryption of communications between a client and server protects against eavesdropping and tampering of the communication, by creating a secure channel over an insecure network.

Before HTTPS communication can be used, a root certificate needs to be installed. The user can either use a Camille Bauer certificate (default setting) or its own customer certificate. This may be changed when defining the Settings of the Security system.

Camille Bauer certificate

The certificate can directly be downloaded from the device via **Certificates and keys**.

Name	Issuer	Not valid before	Not valid after
Camille Bauer SINEAX LINAX CENTRAX Root CA	Camille Bauer SINEAX LINAX CENTRAX Root CA	21.11.2024, 10:42:53	14.11.2054, 10:42:53

Details

Name: Camille Bauer SINEAX LINAX CENTRAX Root CA
Issuer: Camille Bauer SINEAX LINAX CENTRAX Root CA
Not valid before: 2024-11-21T09:42:53.000Z
Not valid after: 2054-11-14T09:42:53.000Z
Serial number: 18B5CEFD64D1386816617FE1F86B793CB318A210

Download


Ok

Alternatively, the certificate can also be obtained from the Camille Bauer website:

- <https://www.camillebauer.com/pq1000-en> or
- <https://www.camillebauer.com/pq3000-en> or
- <https://www.camillebauer.com/pq5000-en>.


The certificate must be installed before starting the browser.

Once the certificate is downloaded to the local computer the certificate can be installed manually. Just double-click on the file. **Install certificate**, then select **Place all certificates in the following store**, **Browse** and select **Trusted Root Certification Authorities**. **Finish** the Import Wizard.




The imported certificate is valid for all devices of the PQ, AM, DM and CU series.

Agree to install the certificate if the below security warning appears:




Customer certificate

Upload the customer server certificate and the private key via *Certificates and keys* under *Certificates for TLS*.



The uploaded certificate can then be selected when activating the HTTPS communication via *Settings* of the *Security System* in the menu *Web Security*.




You may use https communication also by ignoring any browser warning and establishing an **unsecure** connection to the device. However, for security reasons you should not work like that in the intended network environment.

6.10.6 Audit log (SYSLOG)

Security related events, such as ...

- a computer establishing a connection to the device
- a user logged in /out
- a failed login attempt
- each changing of the device configuration
- the view of the security log by a user
- etc.

are logged in a security log accessible via the service menu.




The screenshot shows a web interface for viewing security logs. At the top, there are pagination controls with buttons for previous/next page, page numbers 1, 2, 3, 4, and a '+5>>' button. To the right of these is a 'Results per page' dropdown set to 25 and a refresh icon. Below the pagination is a 'Filter' section with buttons for Emergency (red), Alert (red), Critical (red), Error (red), Warning (orange), Notice (blue), Info (grey), and Debug (pink). The main content is a table with the following columns: Time, PID, Priority, IP address, User name, and Message. The table contains 12 rows of log entries. The first 10 rows have a blue background, while the last 2 rows have a grey background. The messages include 'User reviewed latest security event log (allow)', 'User logged in successfully', 'Accepted password ssh2', 'User logged out successfully', 'The device was power off on Fri Jan 17 07:57:31 2020', and 'Firmware update was on Fri Jan 17 08:01:07 2020'.

Time	PID	Priority	IP address	User name	Message
17.01.2020, 09:35:59	cb-gui[2126]	Notice	192.168.57.65:54375	admin	User reviewed latest security event log (allow)
17.01.2020, 09:35:54	cb-gui[2126]	Notice	192.168.57.65:54375	admin	User logged in successfully
17.01.2020, 08:33:30	sshd[2436]	Info	192.168.58.58:11348	root	Accepted password ssh2
17.01.2020, 08:31:18	sshd[2420]	Info	192.168.58.58:11318	root	Accepted password ssh2
17.01.2020, 08:31:17	sshd[2416]	Info	192.168.58.58:11315	root	Accepted password ssh2
17.01.2020, 08:24:56	cb-gui[2126]	Info	192.168.57.65:53539	admin	User logged out successfully
17.01.2020, 08:04:45	cb-gui[2126]	Notice	192.168.57.65:53387	admin	User reviewed latest security event log (allow)
17.01.2020, 08:02:59	cb-pq3000[2120]	Notice			The device was power off on Fri Jan 17 07:57:31 2020
17.01.2020, 08:02:59	cb-pq3000[2120]	Notice			The device was power on Fri Jan 17 07:57:31 2020
17.01.2020, 08:02:59	cb-pq3000[2120]	Notice			Firmware update was on Fri Jan 17 08:01:07 2020

Example of a security log: The severity of each message is shown in a color code, which may also serve as filter criteria.

Each entry into this list may, if activated, also be transferred to a central log-server using the **SYSLOG** protocol for security auditing. This transfer may be performed based on UDP, TCP or TLS. The settings of the Syslog server are available via Settings | Communication | Syslog server:



The screenshot shows the Syslog server configuration settings. It includes three fields: 'Syslog protocol' with a dropdown menu set to 'TCP', 'Host' with a text input field containing 'tenserv.camillebauer.com', and 'Port' with a text input field containing '514'.

Syslog protocol	TCP
Host	tenserv.camillebauer.com
Port	514

7. Operating the device


7.1 Operating elements



PQ1000



PQ3000



PQ5000

The operation of devices with display is performed by means of 6 keys:

- 4 keys for **navigation** (◀, ▲, ▼, ▶) and for the selection of values
- OK for **selection** or confirmation
- ESC for **menu display**, terminate or cancel

The **function** of the operating keys change in some measurement displays, during parameterization and in service functions. For the PQ3000 the valid functionality of the keys is then shown in a help bar.

7.2 Selecting the information to display



PQ1000



PQ3000



PQ5000

For devices with display, information selection is performed via menu. Menu items may contain further sub-menus.

Displaying the menu

Press **ESC**. Each time the key is pressed a change to a higher menu level is performed, if present.

Displaying information






The menu item chosen using ▲, ▼ can be selected using **OK**. Repeat the procedure in possible submenus until the required information is displayed.

Return to measurement display

After 2 min. without interaction the menu is automatically closed and the last active measurement display is shown.

7.3 Measurement displays and used symbols


For displaying measurement information, the device uses both numerical and numerical-graphical measurement displays.

Examples	Measurement information
 Bimetal current 07.02.2018 15:27 79.90 A TRMS 98.00 A TRMS	2 measured quantities
 Power 21.07.2015 17:02 P 3.5431 kW Q 0.5423 kvar S 3.5867 kVA PF 0.988	4 measured quantities
 User mean-values 1-4 27.07.2015 11:27 U 1N 98.53 V U 1N 98.55 V U 2N 102.17 V U 2N 102.16 V U 3N 101.28 V U 3N 101.28 V I 1 109.56 A I 1 109.57 A	2x4 measured quantities
 Voltage min/max 21.07.2015 17:01 U 12 410.67 V U 1N 238.17 V U 23 411.28 V U 2N 237.30 V U 31 411.65 V U 3N 238.53 V F 50.007 Hz U neg/pos 21.25 %	2x4 measured quantities with min/max
 Odd harmonics U 06.05.2019 17:17 L1 THD 1.5 % L2 THD 1.4 % L3 THD 1.5 %	Graphical measurement display Further examples

Incoming / outgoing / inductive / capacitive

The device provides information for all four quadrants. Quadrants are normally identified using the roman numbers I, II, III and IV, as shown in the adjacent graphic. Depending on whether the system is viewed from the producer or consumer side, the interpretation of the quadrants is changing: The energy built from the active power in the quadrants I+IV can either be seen as delivered or consumed active energy.

By avoiding terms like incoming / outgoing energy and inductive or capacitive load when displaying data, an independent interpretation of the 4-quadrant information becomes possible. Instead the quadrant numbers I, II, III or IV, a combination of them or an appropriate graphical representation is used. You can select your own point of view by selecting the reference arrow system (load or generator) in the settings of the measurement.




Used symbols


For defining a measurement uniquely, a short description (e.g. U_{IN}) and a unit (e.g. V) are often not sufficient. Some measurements need further information, which is given by one of the following symbols or a combination of these symbols:

	Mean-value	ΣHT	Meter (high tariff)
	Mean-value trend	ΣLT	Meter (low tariff)
	Bimetal function (current)		Maximum value
	Energy quadrants I+IV		Minimum value
	Energy quadrants II+III	TRMS	True root-mean-square value
	Energy quadrants I+II	RMS	Root-mean square value (e.g. fundamental or harmonic content only)
	Energy quadrants III+IV	(H1)	Fundamental component only
I,II,III,IV	Quadrants	$\emptyset$	Average (of RMS values)


Examples



PQ3000: Meters with tariff and quadrant information



PQ1000/5000: User mean values, last value



PQ1000/5000: User mean values, trend

7.4 Resetting measurement data

- **Minimum and maximum** may be reset during operation. The reset may be performed in groups using the service menu.

Group	Values to be reset
1	Min/max values of voltages, currents and frequency
2	Min/max values of power quantities (P,Q,Q(H1),D,S); min. load factors
3	Min/max values of power mean-values, bimetal slave pointers and free selectable mean-values
4	Maximum values of harmonic analysis: THD U/I, TDD I, individual harmonics U/I
5	All imbalance maximum values of voltage and current

- **Meter contents** may be individually set or reset during operation using the service menu
- **Recorded logger data** can be individually reset via the service menu. This makes sense whenever the configuration of the quantities to record has been changed.

7.5 Configuration

7.5.1 Local configuration at the device

With the exception of the security system and the settings of the optional PME system a full parameterization of the device can be performed via the menu "Settings".

Modifications will not take effect before the user accepts the query "Store configuration changes" when leaving the settings menu. Changings in the "Country and clock" menu have immediate effect (e.g. a different operating language is used), but nevertheless must be stored.

- **Country and clock:** display language, date format, time zone, clock synchronization, time/date
- **Display:** Refresh rate, brightness, screen saver
- **Communication:** Settings of the [Ethernet](#) interface and Modbus communication. In addition, a [SFTP server](#) may be defined, to push user definable data files to.
- **Measurement:** System type, sense of rotation, nominal values of U / I / f, sampling, reference arrow system etc.

Hints

- *U / I transformer: The primary to secondary ratio is used only for converting the measured secondary to primary values, so e.g. 100 / 5 is equivalent to 20 / 1. The values do not have any influence on the display format of the measurements.*
- *Nominal voltage: Is used as the 100% reference for monitoring power quality events and corresponds to the declared input voltage U_{din} in accordance with IEC 61000-4-30*
- *Nominal current: Used for scaling the harmonic content [TDD](#) of the currents*
- *Maximum primary values U/I: These values are used only for fixing the display format of the measurements. This way the resolution of the displayed values can be optimized, because there is no dependency to installed transformers.*
- *Synchronous sampling: yes=sampling is adjusted to the measured system frequency to have a constant number of samplings per cycle; no=constant sampling based on the selected system frequency*
- *Reference channel: The measurement of the system frequency is done via the selected voltage or current input*
- **Power quality:** Definition of parameters for monitoring PQ. User-specific limits for the evaluation of the PQ statistic can also be set.
- **Mean-values | standard quantities:** Interval time and synchronization source for the predefined power mean values
- **Mean-values | user defined quantities:** Selection of up to 12 quantities for determining their mean-values and selection of their common interval and synchronization source
- **Bimetal current:** Selection of the response time for determining [bimetal currents](#)
- **Meters | Standard meters:** Tariff switching ON/OFF, [meter resolution](#)

- **Meters | User defined meters:** Base quantities (Px,Qx,Q(H1)x,Sx,Ix), Tariff switching ON/OFF, [meter resolution](#)
- **Meters | Meter logger:** Selection of the reading interval
- **Limit values:** Selection of up to 12 quantities to monitor, [limit values](#) for ON/OFF, event text ¹⁾
- **Digital inputs:** Debounce time (minimum pulse width), pulse rate and polarity of the [digital inputs](#)
- **Fault current:** Configuration of the fault current channels, especially alarm and pre-warning limits, transformer ratios as well as response and dropout delay
- **Temperature:** Configuration of the temperature monitoring channels, especially event text, alarm limits, response and dropout delay, lead resistance
- **Monitoring functions:** Definition of up to 8 [monitoring functions](#) with up to three inputs each, delay times for ON / OFF and event text ¹⁾
- **Summary alarm:** Selection of the monitoring functions to be used for triggering the [summary alarm](#) and selection of a possible source for resetting
- **Operating hours:** Selection of the running condition for up to 3 operating hour counters
- **Digital outputs | Digital output:** State, pulse or remote controlled [digital output](#) with source, pulse width, polarity, number of pulses per unit
- **Digital outputs | Relay:** State or remote controlled relay output with source
- **Analog outputs:** Type of output, source, transfer characteristic, upper/lower range limit
- **Security system:** Definition of the [security system](#) (RBAC, https, whitelist). Locally RBAC can only be enabled or disabled, credentials and access rights must be setup via website.
- **Demo mode:** Activation of a presentation mode; measurement data will be simulated. Demo mode is automatically stopped when rebooting the device.
- **Device tag:** Definition of different texts ¹⁾ mainly used for report generation, such as device tag, document title, device location and others.
- **Data export scheduler:** Via [website](#) you can setup tasks to be performed regularly. Each time such a task is running, it creates a data file to be transferred to a SFTP server and/or to be stored locally on the device. Via local configuration tasks can be enabled or disabled only.

¹⁾ In user-defined event and description texts all Unicode characters (UTF8) are allowed with the exception of the following:

- ASCII control characters (0x00 - 0x1F)
- The quotation mark " (0x22)
- The character & (0x26)
- The apostrophe ' (0x27)
- The asterisk * (0x2A)
- The slash / (0x2F)
- The colon : (0x3A)
- The «less than» character < (0x3C)
- The «bigger than» character > (0x3E)
- The question mark ? (0x3F)
- The backslash \ (0x5C)
- The vertical line | (0x7C)

At the device itself only «normal» characters of the ASCII character set can be input. Entering language specific character or texts is possible via the website of the device only.

7.5.2 Configuration via web browser



It's recommended to use either Google Chrome or Firefox as browser.




Internet Explorer works with limitations only (partly missing texts, firmware update not possible)

For configuring via web-browser you have to display the device website using:

- IPv4 communication: `http://IPv4_addr`, e.g. `http://192.168.1.101`
- IPv6 communication: `http://[IPv6_addr]`, e.g. `http://[fd2d:bb44:97f1:3976::1]`

This request works only if device and PC are in the same network segment. Depending on the device version, there may be multiple network devices with different [default IP addresses](#).

If the [secure communication via https](#) is activated and the root certificate installed, you have to use https instead of http for displaying the website



Device website using Google Chrome

192.168.1.101/webgui/index.html#

The locker symbol shows that a secure connection is established (if https is used)




There are three information here:

- The SD-card is present and stores data
- A network connection is established
- No user with credentials has logged in so far. Information granted to the default user '[anonymous](#)' is displayed.



Via WEB-GUI you can make the same settings as via the [local GUI](#) using the Settings menu. In addition, it is possible to setup the [security system](#) and the [Data export scheduler](#) and to enter user-defined event or description texts in UTF8 format.

Possibly modifications need to be saved in the device, before all parameters have been set. In such a case the following message appears:



If this request is not confirmed, unsaved modifications of the present device configuration may get lost.

Loading / saving configuration files

The user can save the present device configuration on a storage media and reload it from there. The storage or load procedure varies depending on the browser used.




The settings of the security system are not part of the configuration file. There is no way to transfer security settings from one device to another.



Loading a configuration file from a storage media

The configuration data of the selected file will be directly loaded into the device. The values in the WEB-GUI will be updated accordingly. Normally devices differ in the settings of network and Modbus parameters and device name. Thus, when loading the file, you can choose, whether the appropriate settings of the device should be retained or overwritten by the values in the file to be uploaded.



Storing the current parameter settings of the WEB-GUI into the device



Saving the device configuration to a storage media

Attention: Modifications in the WEB-GUI, which haven't been stored in the device, will not be written to the storage media.

7.6 PQ monitoring

Power quality monitoring provides both a statistical evaluation, allowing an assessment of compliance with standards (e.g. EN 50160) or supply contracts, as well as records of events in the grid (e.g. power voltage dips). This facilitates the analysis of causes and effects. Compliance reports may also be created directly via the website of the device.

7.6.1 PQ events

The device monitors all voltage events in accordance with IEC 61000-4-30. The default values of the trigger thresholds correspond to the common values of the EN 50160 for a public low-voltage distribution system, but can be changed by the user to individual needs.

In addition to the requirements of IEC 61000-4-30 the device can monitor current swells and frequency anomalies.

Monitored events	Threshold	Hysteresis	Reference value
Voltage dip	90%	2%	Nominal voltage
Voltage interruption	10%	2%	
Voltage swell	110%	2%	
Rapid voltage change ²⁾	6%	50% ¹⁾	
Homopolar voltage	50%	2%	
Current swell	120%	2%	Nominal current
Frequency anomaly	lower: 99% upper: 101%	0.5%	Nominal frequency

¹⁾ Related to the respective threshold

²⁾ Not available for PQ1000



The device does not verify the user-defined event parameters. If these values are not plausible, events may be not recognized correctly or misclassified. In particular, the trigger threshold for RVC events should not be greater than half of the difference of the threshold values of voltage swell and voltage dip.

Recordings

If any of the above events occurs, the device records both the half-cycle RMS values and the samples of all voltage and current channels. The event recording times can be configured using the menu *Settings* | *Power quality* | *Event recording*:

RMS(1/2): Pretrigger recording	s	1.000
RMS(1/2): Event recording (max.)	s	180.000
Samples: Pretrigger recording	s	1.000
Samples: Event recording	s	4.000

Possible recording times

≤1.0s

≤180.0s

≤1.0s

≤5.0s

Note: The event recording time "RMS(1/2): After triggering" is a maximum recording time. It is reduced to the real event duration + 1s, if the event duration is shorter than the configured time.

Recorded PQ events can be [visualized](#) either via the local display or the webpage of the device.

Mains signalling voltage

The device (except PQ1000) monitors mains signalling voltages, which are transmitted in the supply system for control purposes, and records them as events. Typically, these are ripple control signals. The user can define the frequency of the signalling voltage, the threshold and hysteresis (related to the nominal voltage) as well as the recording duration in multiples of the measurement interval of 10/12 cycles. The recording duration must not exceed 120s. The ripple control frequency is typically below 3 kHz and can be requested from the local energy provider.

Reference channel		U1
Ripple control frequency	Hz	375
Trigger threshold	%	2
Trigger hysteresis	%	1
Rec. duration (10/12 cycles)	#	50

7.6.2 PQ statistic

Power quality (PQ) is assessed by a comparison between the PQ parameters measured by the device and the limits of a contract agreed upon. The assessment period is usually at least one week to take into account possible variations between weekdays and weekends.

Via its website the device can perform an assessment of the measured PQ parameters in accordance with the following standards:

- EN 50160 (2010), low voltage, interconnected systems
- EN 50160 (2010), low voltage, island systems
- EN 50160 (2010), medium voltage, interconnected systems
- EN 50160 (2010), medium voltage, island systems
- EN 50160 (2010), high voltage, interconnected systems
- EN 50160 (2010), high voltage, island systems
- IEC 61000-2-2 (2002), public low voltage systems
- IEC 61000-2-4 (2002), industrial and non-public systems up to 35 kV, class 1
- IEC 61000-2-4 (2002), industrial and non-public systems up to 35 kV, class 2
- IEC 61000-2-4 (2002), industrial and non-public systems up to 35 kV, class 3
- IEC 61000-2-12 (2003), public medium voltage systems
- IEEE 519
- GB/T
- User specific limit sets

The assessment of the PQ statistic is shown in the chapter [Data recording | PQ statistic](#), including the creation of compliance reports.

Recorded PQ parameter groups

Measurement	Averaging time	Applied limits
Power frequency	10 s	<i>The applied limits and time conditions of the preset standards can be seen via the device website.</i> <i>They can be displayed via the following menu:</i> <i>Settings</i> <i> Power Quality</i> <i> Custom threshold limits</i> <i> (Standard)</i>  <i>Within the same menu user data sets with specific limits and evaluation criteria can be defined</i>  <i>User specific data sets can also be deleted again.</i>
Voltage magnitude	10 min.	
Flicker P _{st} ¹⁾	10 min.	
Flicker P _{lt} ¹⁾	2 h	
Mains signalling voltage ¹⁾	3 s	
Supply voltage unbalance	10 min.	
THDS of voltages	10 min.	
Voltage harmonics	10 min.	
Voltage interharmonics ¹⁾	10 min.	
Current magnitude	10 min.	
Current unbalance	10 min.	
Current harmonics	10 min.	
Current interharmonics ¹⁾	10 min.	

¹⁾ Not available for PQ1000

7.6.3 Provision of PQ data

The device can create PQ related data, such as PQ events or PQ statistic, using the standard format PQDIF (**P**ower **Q**uality **D**ata **I**nterchange **F**ormat). The automatic or event-driven generation of such files can be defined via the [Data export scheduler](#) in the Settings menu. By default, daily PQDIF will be created periodically after midnight for the past day and provided in a hierarchical time structure (year, month, day) for [download](#).

PQDIF files may also be generated manually via web interface. This may be done either for the present day (including data since midnight) or contiguous, selectable time ranges of up to 7 days. The file(s) is added in the time structure of the end day. Days with existing files are marked with a red dot.

> Service > Local data storage > Generate PQDIF

Simulation

Min/max values reset

Meter contents set/reset

Logger values reset

Operating hours

Device information

Local data storage

Factory reset

Audit Log

Firmware update

Communication Tests

Device reboot

Generate PQDIF

Download data

< March 2021

Mo	Tu	We	Th	Fr	Sa	Su
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	1	2	3	4
5	6	7	8	9	10	11

Generate PQDIF

Start PQ data generation

> Found 10 events on Wed Mar 24 2021

> Event 'Voltage dip' at 2021-03-24T13:45:23.549+01:00

> Event 'Voltage dip' at 2021-03-24T13:48:16.953+01:00

> Event 'Voltage dip' at 2021-03-24T13:48:53.748+01:00

> Event 'Voltage dip' at 2021-03-24T13:50:05.536+01:00

> Event 'Voltage dip' at 2021-03-24T13:51:05.008+01:00

> Event 'Voltage dip' at 2021-03-24T13:51:44.569+01:00

> Event 'Voltage dip' at 2021-03-24T13:54:33.099+01:00

> Event 'Voltage dip' at 2021-03-24T14:01:54.240+01:00


> Event 'Voltage dip' at 2021-03-24T14:07:14.922+01:00

> Event 'Voltage dip' at 2021-03-24T14:08:48.014+01:00

> PQ data stored in file 'PQ1000-1216324003_20210324.pqd'

> PQ data generation done


If for the selected time range PQDIF files are already stored in the device the below warning will be displayed.



7.7 Alarming

The device supports an alarming concept independent of power quality events. Depending on the user requirements, simple or more advanced monitoring tasks may be realized. The most important objects are limit values on base quantities, the monitoring of fault-current, monitoring functions and the summary alarm.

7.7.1 Limit values on base quantities




Using limit values either the exceeding of a given value (upper limit) or the fall below a given value (lower limit) is monitored.

Limits values are defined by means of two parameters: Limit for ON / OFF. The hysteresis corresponds to the difference between these two values.


Both state transitions OFF→ON and ON→OFF can be recorded as event or alarm in the appropriate lists.

Upper limit: $\text{Limit for ON} \geq \text{Limit for OFF}$



- The limit value becomes active (1) as soon as the limit for ON state is exceeded. It remains active until the associated measured quantity falls below the limit for OFF state again.
- The limit value is inactive (0) if either the limit for ON is not yet reached or if, following the activation of the limit value, the associated measured quantity falls below the limit for OFF state again.

Lower limit: $\text{Limit for ON} < \text{Limit for OFF}$



- The limit value becomes active (1) as soon as the associated measured quantity falls below the limit for ON state. It remains active until the associated measured quantity exceeds the limit for OFF state again.
- The limit value is inactive (0) if either the associated measured quantity is higher than the limit for ON state or if, following the activation of the limit value, it exceeds the limit for OFF state again.



If the limit for ON state and the limit for OFF state are configured to the same value, the limit value will be treated as an upper limit value without hysteresis.

Limit value states can:


- ... directly be used as source for a digital output
- ... be used as logic input for a monitoring function
- ... be recorded as event or alarm in the appropriate lists on each changing

7.7.2 Monitoring fault-currents

Each (optional) fault current module provides **two channels** for monitoring residual or fault current. For each of the channels an alarm and a pre-warning limit can be defined, which can be used as follows:

- ... Activating a [summary alarm](#) when the alarm limit is violated or a breakage occurs (2mA input only)
- ... as logic input for [monitoring functions](#)
- ... as source for digital outputs
- ... Entry into the alarm list, if the state of the alarm limits monitoring changes or when a breakage occurs (2mA input only)
- ... Entry into the event list, if the state of the pre-warning limits monitoring changes
- ... the value of the individual fault currents can also be output via the analog outputs

The present values of the monitored fault currents are visible via the menu of the instantaneous values:



Meaning of the used symbols

	Current value normal
	Pre-warning limit violated
	Alarm limit violated
	Alarm: Configured limit for ON
	Alarm: Configured limit for OFF
	Pre-warning: Configured limit for ON
	Pre-warning: Configured limit for OFF
	Breakage of measurement line detected

7.7.3 Temperature monitoring

Each (optional) temperature module provides **two channels** for temperature monitoring.

Used for Pt100 measurement


- Up to 2 limit values
- Short circuit and wire / sensor breakage monitoring

Used for PTC monitoring

- Monitoring the PTC response temperature
- Short circuit monitoring

Usage of the determined states

- ... Activating a [summary alarm](#) when an alarm limit is violated (Pt100) or the response temperature is reached (PTC), a short-circuit or a wire / sensor breakage (Pt100) occurs
- ... as logic input for [monitoring functions](#)
- ... as source for digital outputs
- ... Entry into the alarm list when any state change occurs
- ... the present temperature for Pt100 measurement can also be output via analog outputs



State of temperature monitoring in the instantaneous values menu, PTC on the left, Pt100 on the right

Meaning of the used symbols

	Measurement in the normal range
	Alarm limit 1 violated
	Alarm limit 1 violated
	Alarm 2: Configured limit for ON
	Alarm 2: Configured limit for OFF
	Alarm 1: Configured limit for ON
	Alarm 1: Configured limit for OFF
	Wire / sensor breakage detected
	Short-circuit detected


7.7.4 Monitoring functions

By means of monitoring functions the user can define an extended condition monitoring, e.g. for triggering an over-current alarm, if one of the phase currents exceeds a certain limit value.

The states of all monitoring functions

...will be shown in the alarm list ("Events" via main menu)

...build a summary alarm state



Logic inputs

Up to three states of limit values, fault-current or temperature monitoring, logic inputs or other monitoring functions. Unused inputs will automatically be initialized in a way that they do not influence the output.

Logic function

For the logical combination of the inputs the function AND, NAND, OR, NOR, DIRECT and INVERT are available. These logical functions are described in [Appendix C](#).

Delay time on

The time a condition must be present until it is forwarded

Delay time off

Time to be waited until a condition, which is no longer present, will be released again

Description

This text will be used for visualization in the alarm list

List entry

- *Alarm / event*: Each state transition will be recorded in the appropriate list
- *none*: No recording of state transitions


Possible follow-up actions

- Driving a logic output. The assignment of the monitoring function to a digital output / relay is done via the settings of the corresponding output.
- Visualization of the present state in the alarm list
- Combining the states of all monitoring functions to create a summary alarm
- Recording of state transitions as alarm or event in the appropriate lists

7.7.5 Summary alarm

The summary alarm combines the states of all [monitoring functions](#) MFx to a superior alarm-state of the overall unit. For each monitoring function you may select if it is used for building the summary alarm state. If at least one of the used functions is in the alarm state, the summary alarm is also in the alarm state.

If an optional failure-current monitoring is present, the detection of an alarm state or a breakage of the measurement line (2mA inputs only) activates directly the summary alarm.



Alarm display ((🔔))

The symbol arranged in the status bar signals if there are active alarms or not.

Acknowledgment: By acknowledging the summary alarm, the user confirms that he has recognized that an alarm state occurred. The acknowledgment is done automatically as soon as the user selects the alarm list to be displayed locally or via web browser or if the alarm state no longer exists. By acknowledging, only the flashing of the alarm symbol stops, the symbol itself remains statically displayed until none of the monitoring functions is in the alarm state.

Logic output

The summary alarm can drive an output. The assignment of a digital output / relay to the summary alarm is done via the settings of the corresponding output.

Reset: The state of the summary alarm - and therefore of the used output - can be reset, even if there is still an alarm active. So, for example a horn activated via summary alarm can be deactivated. A reset may be performed via display, via web browser, a digital input or the Modbus interface. The logic output becomes active again as soon as another monitoring function goes to the alarm state or if the same alarm becomes active again.

Alarm state display



The digital or relay output assigned to the summary alarm can be reset by means of the <OK> key. So, the active alarming will be stopped. But the alarm state of the summary alarm remains active until the alarm state no longer exists.

7.8 Data recording

The device stores long-term recordings of measurement progressions, events and PQ statistics. Some of these recordings provide predefined contents; some is based on user-defined contents.

In addition, file-based information may be periodically created using the [data export scheduler](#). This data may be saved internally and / or send securely to a SFTP server.

In general, recordings are done in endless mode. The oldest data will be deleted, as soon as the associated memory is used for more than 80%.

Group	Data type	Request	
Periodic data	- Mean-values versus time, predefined (5) and user-specific (12) quantities - Periodic meter readings, predefined (4) and user-specific (12) quantities	 Energy	- Mean value logger - Meter logger
Events	In form of a logbook with time information: - Event list: Every state transition of monitoring functions or limit values, classified as event and each violation of the pre-warning level of the (optional) fault current channels - Alarm list: Every state transition of monitoring functions or limit values, classified as alarm and each violation of the alarm limits of the (optional) fault current channels - Temperature alarm list: Each violation of the limit values of the (optional) temperature channels	 Events	Event and alarm list
PQ events	The occurrence of PQ events will be registered in the PQ event list. By selecting the entries for voltage events: - the course of the RMS values of all U/I - the wave shape of all U/I during the disturbance will be displayed	 Events	PQ events and Mains Signalling
Security events	Security log (SYSLOG)	 Service	Log of the security system
PQ statistic	For a selectable weekly interval, the evaluation of the PQ statistic is displayed, depending on the selected standard. In addition, daily trends of the monitored PQ variables can be displayed. By means of PQ-Easy Report, compliance reports can be created directly via website.		

7.8.1 Periodic data

Configuration of the periodic data recording

Via the settings menu the user can individually configure:


- The averaging interval of the standard mean-values P(I+IV), P(II+III), Q(I+II), Q (III+IV), S
- The averaging interval of up to 12 user-defined mean-values
- The reading interval of standard meters P(I+IV), P(II+III), Q(I+II), Q (III+IV)
- The reading interval of up to 12 user-defined meters

The recording of all mean-values and meters is started automatically on device start. The recording of the mean-values is done when the appropriate averaging interval expires.

Displaying the chronology of the mean values

The chronology of the mean values is available via the menu **Energy** and is divided in two groups:

- Pre-defined power mean values
- User-defined mean values




Selection of the mean values group



The selection of the mean-value quantity to display can be performed by choosing the corresponding register. Three different kind of displays are supported:

- Daily profile: Hourly mean-values will be shown, independently of the real averaging time
- Weekly profile
- Table: Listing of all acquired mean-values in the sequence of the real averaging interval

The graphical representation allows comparing directly the values of the previous day or week.



Alternatively, a line display can be selected, in which the display of min/max values can then also be activated in order to be able to see the fluctuation range of the measured values.

In this type of display, you can zoom into time ranges. The individual measured values are then visible as points. With the help of a "fly-over" display, detailed data can then be visualized:

- Time Interval
- Mean-value during the interval
- Min. RMS value within the interval
- Max. RMS value within the interval



Mean values in table format


#	time	mean	min(interval)	max(interval)
1	21.07.2023, 08:40:00,000	75.92 kW	56.36 kW	96.66 kW
2	21.07.2023, 08:35:00,000	83.00 kW	61.37 kW	114.90 kW
3	21.07.2023, 08:30:00,000	87.30 kW	78.11 kW	112.71 kW
4	21.07.2023, 08:25:00,000	90.52 kW	81.03 kW	112.20 kW
5	21.07.2023, 08:20:00,000	74.91 kW	42.62 kW	113.34 kW
6	21.07.2023, 08:15:00,000	50.99 kW	43.67 kW	78.99 kW
7	21.07.2023, 08:10:00,000	45.68 kW	41.04 kW	74.81 kW
8	21.07.2023, 08:05:00,000	46.27 kW	40.95 kW	75.15 kW
9	21.07.2023, 08:00:00,000	45.43 kW	40.93 kW	72.98 kW
10	21.07.2023, 07:55:00,000	46.15 kW	41.73 kW	75.16 kW
11	21.07.2023, 07:50:00,000	48.87 kW	44.78 kW	54.65 kW
12	21.07.2023, 07:45:00,000	49.95 kW	41.47 kW	74.79 kW
13	21.07.2023, 07:40:00,000	44.44 kW	37.41 kW	73.41 kW
14	21.07.2023, 07:35:00,000	47.50 kW	37.47 kW	68.90 kW

Displaying the chronology of meter contents

The chronology of meters is available via the menu **Energy** and is divided in two groups:

- Pre-defined meters
- User-defined meters

From the difference of two successive meter readings the energy consumption for the dedicated time range can be determined.



Selection of the meter logger group

> Energy > Meter logger > Std. meter log.

P (I+IV) P (II+III) Q (I+II) Q (III+IV)

Navigation: < 1 2 3 4 5 > +5>> Results per page 25


#	time	P ΣLT (I+IV)	P ΣHT (I+IV)
26	25.06.2023, 00:00:00,000	0 Wh	848242311 Wh
27	24.06.2023, 00:00:00,000	0 Wh	847797510 Wh
28	23.06.2023, 00:00:00,000	0 Wh	846779668 Wh
29	22.06.2023, 00:00:00,000	0 Wh	845737977 Wh
30	21.06.2023, 00:00:00,000	0 Wh	844716848 Wh
31	20.06.2023, 00:00:00,000	0 Wh	843700736 Wh
32	19.06.2023, 00:00:00,000	0 Wh	842899736 Wh
33	18.06.2023, 00:00:00,000	0 Wh	842491928 Wh
34	17.06.2023, 00:00:00,000	0 Wh	842065784 Wh
35	16.06.2023, 00:00:00,000	0 Wh	841237689 Wh
36	15.06.2023, 00:00:00,000	0 Wh	840200917 Wh
37	14.06.2023, 00:00:00,000	0 Wh	839292180 Wh
38	13.06.2023, 00:00:00,000	0 Wh	838391104 Wh

Meter content readings in table form

Displaying data locally

The selection works in principle in the same way as with the WEB-GUI. There are the following differences:

- The individual measured quantities are arranged in a display matrix and can be selected via navigation.
- The number of displayable meter readings is limited to 25
- The time range of the mean values is limited to the present day or the present week. There is no possibility for navigation.



Mean-values of the present day

Zeit	P ΣLT (I+IV) [Wh]	P ΣHT (I+IV) [Wh]
00:00:00,000 11.07.2023	0	861228877
00:00:00,000 10.07.2023	0	860475776
00:00:00,000 09.07.2023	0	860160500
00:00:00,000 08.07.2023	0	859764499
00:00:00,000 07.07.2023	0	858885213

Meter readings

Manual data export as CSV file

Via  the time range of the data to export can be selected. A CSV (Comma separated value) file will be generated. For creation the [CSV settings](#) of the data exporter are applied. This can be imported as a text file to Excel.

The same file contains data for all quantities of the respective group.

7.8.2 User-defined events



Configuration of events

For all [monitoring functions](#) and [limit values](#) for which state transitions need to be recorded, the parameter “list entry” must be set to either events or alarms.

Events of the (optional) fault-current and temperature channels are automatically entered into the appropriate lists. The limit values to be monitored can be defined via the items Temperature and Fault current in the settings menu.

Displaying of event entries

Event lists are a kind of logbook. Every state transition of monitored events is recorded in the appropriate list with the time of its occurrence.



Example of an event list

Displaying data locally

The selection works in principle in the same way as with the WEB-GUI. There is the following difference:

- The number of displayable events is limited to 25

7.8.3 PQ events


Configuration of the events to record

[See 7.6](#)

Display of PQ event recordings (locally)

Recorded events are available in the form of a logbook, mains signalling events are stored in a separated list. Each detected event is entered into the PQ event list with the time of its occurrence, the remaining voltage and the duration of the event. By selecting a list entry, the graphical display of the measured values during this event is entered. The following presentations are available:

- Half cycle RMS curves of all voltages, all currents, all voltages and currents
- Wave shapes of all voltages, all currents, all voltages and currents



Display matrix on the local display using the example of PQ3000

Restriction of the quantities to display on the local display

The user can adapt the displayed information to its needs. Once the graphic is displayed, the setting window for the selection of the quantities to display is entered by pressing <OK>.

Voltage display

U1N	☒
U2N	☒
U3N	☒
UNE	☐

Current display

I1	☒
I2	☒
I3	☒
IN	☐

Mixed display

U1N	☒
U2N	☒
U3N	☒
UNE	☐
I1	☒
I2	☒
I3	☒
IN	☐


Display of PQ events (WEB-GUI)

As with the local GUI, recorded events are available in the form of a logbook. Events may be filtered by event type and event date.

By selecting a list entry, the graphical display of the measured values during this event is entered.

time	Duration [s]	Event type	Trigger channel	Details
20.07.2021 09:50:42,952	250.356	Voltage dip	U2, U3	Residual voltage: 120.007 V Depth: 109.993 V
16.07.2021 09:28:38,590	1.600	Voltage interruption	U1, U2, U3	Residual voltage: 0.0351982 V Depth: 229.965 V
16.07.2021 09:28:38,570	1.640	Voltage dip	U1, U2, U3	Residual voltage: 0.0351982 V Depth: 229.965 V
16.07.2021 09:24:11,238	237.822	Voltage dip	U1	Residual voltage: 159.69 V Depth: 70.3095 V
14.07.2021				Residual voltage: 99.8595 V

List of PQ events



Graphical display of a PQ event


By selecting a time range via left mouse key, the graphical event display may be zoomed.




Zoomed PQ event

7.8.4 PQ statistic

From the PQ statistic it is very easy to see whether the limits of the [monitored criteria](#) are respected or not. Each criterion is represented by a bar, which itself may be composed of multiple color components:




Example for monitoring voltage variations:




- Limit to be respected is marked with a red line (95% of the time range)
- U1N: Requirement fulfilled, because green bar > 95%
- U2N: Requirement not fulfilled, because green bar < 95%
- U3N: Requirement fulfilled, because green bar > 95%

Display of PQ statistic (WEB-GUI)

Selection via the menu PQ statistic




The PQ statistic is shown for a time range of one week. The end of the time range can be selected. The time range always starts and ends at 00:00h. In the overview you can directly select the standard to be used for assessment.




Display of PQ statistic (locally)

Selection via Main menu | PQ statistic



The PQ statistic is always displayed for the past seven days. Another time range cannot be selected.

The standard to be used for the assessment of the statistic can be changed by selecting the entry “Standard”.



Display of PQ statistic details


For the recorded PQ quantities details can be displayed on a daily basis. On the local display this feature is limited to the past day.

...	Frequency	Daily statistic U	Harmonics U	Daily statistic I	Harmonics I
	Distribution	Voltage	Harmonics U1x	Current	Harmonics I1
	Daily statistic	Imbalance U	Harmonics U2x	Imbalance I	Harmonics I2
		THD U	Harmonics U3x	TDD I	Harmonics I3


Local display options PQ1000

...	Frequency	Daily statistic U	Harmonics U	Interharmonics U	Daily statistic I	Harmonics I	Interharmonics I
	Distribution	Voltage	Harmonics U1x	Interharmonics U1x	Current	Harmonics I1	Interharmonics I1
	Daily statistic	Flicker Pst	Harmonics U2x	Interharmonics U2x	Imbalance I	Harmonics I2	Interharmonics I2
		Flicker Plt	Harmonics U3x	Interharmonics U3x	TDD I	Harmonics I3	Interharmonics I3
		Imbalance U					
		THD U					

Local display options PQ3000 / PQ5000





Statistical distribution of 10-s frequency values




Course of 10-min voltage values with min/max

Creating a compliance report via the device website – PQ-Easy Report


Via  a compliance report in PDF format can be created.

1. Select assessment period: At least 1 week
2. Select standard which compliance needs to be proven
3. Select content of report (3 levels)
4. Enter a comment, which needs to be shown on the first page of the report
5. Start report generation...




During report generation a progress bar is shown at the upper side of the screen. The duration of the report generation depends on the selected content, the assessment period and the number of recorded PQ events.



The generated report can be downloaded.

Depending on the browser and its settings, you can either choose where to save the file or the report will be saved in the default download directory.


a) Overview



b) Details




c) Events



7.8.5 Micro SD card (PQ3000 only)

Devices with data logger are supplied with a micro SD-Card, which provides long recording times.



Activity

The red LED located next to the SD card signals the logger activity. When data is written to the SD card the LED becomes shortly dark.

Exchanging the card

For exchanging the SD card the removal key needs to be pressed. Once the LED becomes green the card is logged off and can be removed. To remove the card, press it slightly into the device to release the locking mechanism: The card is pushed out of the device.

If the SD card is not removed within 20s the exchanging procedure is cancelled and the card will be mounted to the system again.

Data cannot be temporarily stored in the device. If there is no SD card in the device no recordings can be done.



Data stored on the SD card can be accessed only as long as the card is in the device. Stored data may be read and analyzed via the webpage of the device or in reduced manner via display only. The content of the SD card cannot be read using a Windows PC.

Thus, before removing the SD card from the device, all data need to be read via Ethernet interface.

7.9 Measurement information in file format

Using the data export scheduler tasks can be managed to provide measurement information in file form. Files can be generated periodically or event-driven and stored locally in the device and/or sent to an SFTP server.

The creation, management and customization of tasks for providing files is done via the settings menu using the item *Data export | Data export scheduler*.

7.9.1 Predefined tasks

The data export scheduler contains three predefined tasks for providing measurement data in PQDIF or CSV file format. For better readability all tasks are activated in the below image, in the factory settings the task “Periodic PQIS” is deactivated.

Add task				
active	Name	Creation	File format	Action
☒	Periodic PQDIF	daily (last 24 hours)	[PQDIF] All values in three files	• store on local Storage
☒	PQ Events	immediately	[PQDIF] events	• push to SFTP server
☒	Periodic PQIS	daily (last 24 hours)	[PQIS] All values in separate files	• store on local Storage

These tasks may be activated, deactivated and changed, but not deleted. Local storage and push to SFTP server are possible actions to be defined. If a task needs to be modified, this can easily be done by selecting the appropriate line.

Periodic PQDIF

This task is executed periodically shortly after midnight and saves the file (s) in a hierarchical time structure (year, month, day). The task can be adjusted by selecting the entry. You can choose whether the information should be contained in one file or in up to three files (statistics, histograms, events). The time period can be either one day or seven days, and generation can be daily or weekly. The factory setting is the daily generation of up to 3 files, each for the previous day.

✕

Edit task

Name

Periodic PQDIF

File

PQDIF

Everything in one file

Creation

daily (last 7 days)

daily (last 24 hours)

daily (last 7 days)

weekly (last 7 days)

Action

store on local Storage


+

Ok

Cancel

PQ Events

If this task is activated, a PQDIF file with event data is created as soon as a PQ event has ended. Typically, this file is then sent to an SFTP server.



The screenshot shows a dialog box titled "Edit task" with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Name:** A text field containing "PQ Events".
- File format:** Two dropdown menus. The first is set to "PQDIF" and the second is set to "events".
- Creation:** A dropdown menu set to "immediately".
- active:** A green checkmark icon indicating the task is active.
- Action:** A dropdown menu with a minus sign icon, currently set to "push to SFTP server".
- subfolder:** A text field containing "MOB-HC_62.46/PQDIF/Events".
- Transmission window:** A dropdown menu set to "none".
- Bottom section:** A horizontal line separates this section from the one above. It contains a dropdown menu with a minus sign icon, currently set to "store temporarily on local Stor".
- Buttons:** "Ok" and "Cancel" buttons at the bottom right.

Periodic PQIS


If this task is activated, the device periodically creates, at the end of each day, CSV files with all information about the power quality, possibly occurred events during the day and the determined load profiles per Current Module. These files can be [downloaded](#) compressed in a ZIP file for a selectable time period. They are structured and formatted in a way that they can be read directly into the PQIS® software and evaluated there. The following files are generated:

- 10 minutes mean-values for PQ assessment
- 2 hours flicker values for PQ assessment
- Mean-values (configurable interval) of power quantities
- PQ event list
- Data for each PQ event:
 - Half-cycle values of voltages and currents
 - Waveform (samples) of voltages and currents
- Signalling voltage event list
- Half-cycle voltages for all signalling voltage events

7.9.2 Creating periodic file data

In addition to the predefined tasks, new tasks can be setup for creating CSV files with mean-values information at regular intervals. These files may then be stored locally and / or pushed to a SFTP server.

By selecting “Add task” new schedules can be set-up. An example is shown below:




The task “24h_PowerMeans” will generate daily CSV files containing standard mean-values for the past 24 hours.

The files will be both stored locally and pushed to the subfolder PowerMeans of a SFTP server. The [settings](#) of the SFTP server to be used can be defined via Communication | SFTP in the Settings menu.

The transmission window selected here causes a random transmission of the file to the SFTP server within one hour since creation. The transmission window may last up to 6 hours, but can also be deactivated in order to force an immediate transmission.

The task list then shows four active tasks. Predefined tasks are marked gray to highlight that they can be deactivated but not removed. On the other hand, at any time the newly created task “24h_PowerMeans” can be fully modified, deactivated or deleted.



active	Name	Creation	File format	Action
☒	Periodic PQDIF	daily (last 24 hours)	[PQDIF] All values in three files	• store on local Storage
☒	PQ Events	immediately	[PQDIF] events	• push to SFTP server
☒	Periodic PQIS	daily (last 24 hours)	[PQIS] All values in separate files	• store on local Storage
☒	24_h_PowerMeans	daily (last 24 hours)	[CSV] mean values	• store on local Storage • push to SFTP server

Via the settings of the local display only the activation / deactivation of the tasks is supported.

CSV settings

CSV files are intended for transmitting statistics of mean values. You may adjust the below parameters to adapt the file format and the content of the created files to your requirements.

Separator	Semicolon
Decimal separator	Dot
Time format	Local time +AB
include min/max values	Yes
Scaled to...	Nominal values
Digits after decimal point	3


- The **Separator** separates the individual entries on a text line for later display in table form.
- The **Decimal separator** defines how numbers or measured values are written to the file. The decimal separator must correspond to the country-specific number format of the operating system so that the CSV file can be opened directly in Excel without an import process. Common separators are periods (123.45) or commas (123,45).
- **Time format** defines the time format to be written. With the “local time + AB” time format, the double entries between 2 and 3 AM are supplemented with the letters A and B when switching back from daylight saving time.
- **Include min/max values** defines whether mean values with / without minimum and maximum values are written to the CSV file.
- **Scaled to** specifies whether the numerical value is based on the basic unit (e.g. 1087.65W) or on the units specified according to the nominal values (e.g. 1.0876kW), which are also used in the web interface.
- **Digits after decimal point** defines the number of digits after the decimal separator with which the numbers are written to the file.

7.9.3 Accessing file information via webpage


You can access files stored in the device using the service menu **Local data storage | Download data**. Depending on the tasks defined in the data export scheduler the available file structure may be different:

- **csv**: container for all CSV files to be locally stored
- **pqdif**: container for all PQDIF files to be locally stored

The structure is displayed in a new tab.




All files are stored in a hierarchical time structure (year, month, day). By selecting the desired date and double-clicking on the appropriate file, it can easily be downloaded.



7.9.4 Download of PQIS files


The files stored in the device can be downloaded and then transferred to the PQIS software.



By selecting a measurement campaign, all information for the entire measurement period can be downloaded to the local computer as a compressed ZIP file. The start and end times are automatically set, but can be changed. If desired, data files for mains signaling voltage events may be omitted, as they do not represent a power quality issue.

7.9.5 Periodical sending to a SFTP Server


If in the data export scheduler the sending to an SFTP server was selected as action, the appropriate files will be sent periodically to the SFTP server defined in the settings of the communication.



The screenshot shows a configuration window for an SFTP server. It contains the following fields and options:

- Host:** tenserv.camillebauer.intra
- Port:** 22
- Username:** sftpuser
- Password:**
- Base directory:** data
- Only connect to trusted host:** No (dropdown menu)
- Legacy host key algorithms:** None (dropdown menu with options: None, SSH-RSA, SSH-DSS, SSH-RSA, SSH-DSS)


For improving security, you may select that the device connects to trusted hosts only. When activating this setting the host must be present and sends a public key back to the device. If you accept this key the associated host will be added to the list of trusted servers.



In the presently used OpenSSH version **legacy algorithms** are not enabled by default, as these older algorithms have been found to be weak. But they can be enabled, if the used SFTP server does only support these algorithms. In the [Communication tests](#) in the service menu various settings can be tested to find the one supported by the SFTP server.

7.9.6 Evaluation of the PQDIF files

For the analysis of the data of the PQDIF files a free tool with limited functionality, such as the PQDiffactor from Electrotek Concepts (<http://www.pqview.com/pqdiffactor/>; registration required), or any other software (e.g. Dranview-7) supporting the PQDIF format can be used.



Representation of a voltage dip using PQDiffactor

7.10 Display timeouts

Devices with display are designed for displaying measurements. So, any other procedure will be terminated after a certain time without user interaction and the last active measurement image will be shown again.

Menu timeout

A menu timeout takes effect after 2 min. without changing the present menu selection. It doesn't matter if the currently displayed menu is the main menu or a sub-menu: The menu is closed and the last active measurement image is displayed again.

Configuration timeout

After 5 min. without interaction in a parameter selection or during entering a value in the settings menu, the active configuration step is closed and the associated parameter remains unchanged. The next step depends on what you have done before:

- If the user did not change configuration parameters before the aborted step, the main menu will be displayed and the device starts to monitor a possible menu timeout.
- If the user changed configuration parameters before the aborted step, the query "Store configuration changes?" is shown. If the user does not answer this query within 2 min. this dialogue is closed: The changed configuration will be stored and activated and then the last active measurement image is displayed again.

8. Service, maintenance and disposal

8.1 Calibration and new adjustment

Each device is adjusted and checked before delivery. The condition as supplied to the customer is measured and stored in electronic form.

The uncertainty of measurement devices may be altered during normal operation if, for example, the specified ambient conditions are not met. If desired, in our factory a calibration can be performed, including a new adjustment if necessary, to assure the accuracy of the device.

8.2 Cleaning

The display and the operating keys should be cleaned in regular intervals. Use a dry or slightly moist cloth for this.



Damage due to detergents

Detergents may not only affect the clearness of the display but also can damage the device. Therefore, do not use detergents.

8.3 Batteries

The device contains a battery for buffering the internal clock. It cannot be changed by the user. The replacement can be done at the factory only.

If the UPS option is implemented, the associated battery pack needs to be exchanged regularly. For more information see [chapter 5.14](#).

The radio modules of the PME option max contain batteries.

8.4 Cyber Security Decommissioning



Logger data on internal Memory

To protect the data (sub billing, power monitoring data, grid power quality data, syslog data, time stamps) from unauthorized access, the data must be erased before the device is decommissioned.

This can be done via the corresponding menu item in the Service menu.



SD-Card (PQ3000)

To protect the data (sub billing, power monitoring data, grid power quality data, syslog data, time stamps) from unauthorized access, the SD card must be deleted or destroyed using a suitable measure (e.g. data media shredder).

8.5 Disposal

The product must be disposed in compliance with local regulations. This particularly applies to the built-in batteries.

9. Technical data

Inputs

Nominal current: 1...5 A; max. 7.5 A (sinusoidal)
Measurement category: 300V CAT III
Consumption: $\leq I^2 \times 0.01 \Omega$ per phase
Overload capacity: 10 A continuous
 100 A, 5 x 1 s, interval 300 s

Current measurement via Rogowski coils
 Range: 0...3000A (max. 3800 A)

See operating instructions of Rogowski coil
 ACF3000 for further information

Nominal voltage: 57.7...400 V_{LN} (UL: 347V_{LN}), 100...693 V_{LL} (UL: 600V_{LL});
Measurement max.: PQ1000/3000: 480V_{LN}, 832V_{LL} (sinusoidal); PQ5000: 520V_{LN}, 900V_{LL} (sinusoidal)
Measurement category: 600V CAT III
Consumption: $\leq U^2 / 1.54 M\Omega$ per phase
Impedance: 1.54 M Ω per phase
Overload capacity: continuous: 480 V_{LN}, 832 V_{LL} (PQ1000/3000); 520 V_{LN}, 900 V_{LL} (PQ5000)
 10 x 1 s, interval 10s: 800 V_{LN}, 1386 V_{LL}

Systems: Single phase
 Split phase (2-phase system)
 3-wire, balanced load
 3-wire, unbalanced load
 3-wire, unbalanced load, Aron connection
 4-wire, unbalanced load

Nominal frequency: 42...50...58Hz or 50.5...60...69.5Hz, configurable

Sampling rate: 18 kHz

Internal data memory: 16 GB

Measurement uncertainty



Version with Rogowski current inputs

The additional uncertainty of the Rogowski coils ACF 3000 is not included in the following specifications: See operating instructions of Rogowski coil ACF3000

Reference conditions: Acc. IEC/EN 60688, ambient 15...30°C, sinusoidal input signals (form factor 1.1107), no fixed frequency for sampling, measurement time 200ms (10 / 12 cycles at 50 / 60Hz)

Quantity	PQ1000	PQ3000 / PQ5000
Voltage, current:	$\pm 0,2\%$ ^{1) 2)}	$\pm 0,1\%$ ^{1) 2)}
Neutral current:	$\pm 0,5\%$ ¹⁾	$\pm 0,2\%$ ¹⁾ (if calculated)
Power:	$\pm 0,5\%$ ^{1) 2)}	$\pm 0,2\%$ ^{1) 2)}
Power factor:	$\pm 0,2^\circ$	$\pm 0,2^\circ$
Frequency:	$\pm 0,01$ Hz	$\pm 0,01$ Hz
Imbalance U,I:	$\pm 0,5\%$	$\pm 0,5\%$
Harmonics:	$\pm 0,5\%$	$\pm 0,5\%$
THD U,I:	$\pm 0,5\%$	$\pm 0,5\%$
Active energy ³⁾ :	Class 0,2S (/5A)	Class 0,2S
Reactive energy ⁴⁾ :	Class 0,5S	Class 0,5S

Measurement with fixed system frequency:

General: $\pm$ Basic uncertainty x (F_{config} - F_{actual}) [Hz] x 10
Imbalance U: $\pm 2\%$ up to ± 0.5 Hz
Harmonics: $\pm 2\%$ up to ± 0.5 Hz
THD, TDD: $\pm 3.0\%$ up to ± 0.5 Hz

¹⁾ Related to the nominal value of the basic quantity

²⁾ Additional uncertainty if neutral wire not connected (3-wire connections)

• Voltage, power: 0.1% of measured value; load factor: 0.1°

• Energy: Voltage influence x 2, angle influence x 2

³⁾ Acc. IEC 62053-22: 2003 for

Accuracy Requirements	Subclause
<i>Meter constant</i>	8.4
<i>Starting current test</i>	8.3.3
<i>Limits of error due to variation of the current</i>	8.1
Limits of error due to influence quantities	Subclause
<i>5th harmonic of voltage and current</i>	8.2.1
<i>Interharmonics in the current circuit – burst fired waveform test</i>	8.2.1
<i>Odd harmonics in the current circuit</i>	8.2.1
<i>Reversed phase sequence</i>	8.2.1

4) Acc. IEC 62053-24: 2014 for

Accuracy Requirements	Subclause
<i>Meter constant</i>	8.5
<i>Starting current test</i>	8.4
<i>Limits of error due to variation of the current</i>	8.2
Limits of error due to influence quantities	Subclause
<i>5th harmonic of voltage and current</i>	8.3
<i>Interharmonics in the current circuit – burst fired waveform test</i>	8.3
<i>Odd harmonics in the current circuit</i>	8.3
<i>Reversed phase sequence</i>	8.3

Power Quality

Type of device: (IEC 62586-1) **PQI-x F11**: Power Quality Instrument – Class **A**; Fixed installation;
Indoor environment with uncontrolled temperature variations (1)
x=S (PQ1000), **x=A** (PQ3000, PQ5000)

Measurement cycle: 200 ms (50Hz: 10 cycles; 60Hz: 12 cycles)

Flagging concept: Multiphase approach in accordance with IEC 61000-4-30

Certification: According to IEC62586-2 (standard for verifying compliance with IEC 61000-4-30)

Certification body: Federal Institute of Metrology METAS, an independent and accredited laboratory

Conformity assessment against IEC 62586-2:2017

Clause	PQ parameter	Compliance 120 V- 60 Hz	Compliance 230 V – 50 Hz
6.1	Power frequency	Yes	Yes
6.2	Magnitude of the supply voltage	Yes	Yes
6.3	Flicker ¹⁾	Yes (class F1)	Yes (class F1)
6.4	Supply voltage interruptions, dips and swells	Yes	Yes
6.5	Supply voltage unbalance	Yes	Yes
6.6	Voltage harmonics	Yes	Yes
6.7	Voltage Interharmonics ¹⁾	Yes	Yes
6.8	Mains signalling voltage of the supply voltage ¹⁾	Yes	Yes
6.9	Measurement of underdeviation / overdeviation parameters ¹⁾	Yes	Yes
6.10	Flagging	Yes	Yes
6.11	Clock uncertainty testing	Yes	Yes
6.12	Variations due to external influence quantities	Yes	Yes
6.13	Rapid voltage changes (RVC) ¹⁾	Yes	Yes
6.14	Magnitude of current	Yes	Yes
6.15	Harmonic current	Yes	Yes
6.16	Interharmonic currents ¹⁾	Yes	Yes
6.17	Current imbalance	Yes	Yes

¹⁾ Not available for PQ1000

Zero suppression, range limitations

The measurement of specific quantities is related to a pre-condition which must be fulfilled, that the corresponding value can be determined and sent via interface or displayed. If this condition is not fulfilled, a default value is used for the measurement.

Quantity	Condition	Default
Voltage	$U_x < 1\% U_{xnom}$	0.00
Current	$I_x < 0,1\% I_{xnom}$	0.00
PF	$S_x < 1\% S_{xnom}$	1.00
QF, LF, $\tan\phi$	$S_x < 1\% S_{xnom}$	0.00
Frequency	voltage and/or current input too low ¹⁾	Nominal frequency
Voltage unbalance	$U_x < 5\% U_{xnom}$	0.00
Current unbalance	mean value of phase currents $< 5\% I_{xnom}$	0.00
Phase angle U	at least one voltage $U_x < 5\% U_{xnom}$	120°
Harmonics U, THD-U	fundamental $< 5\% U_{xnom}$	0.00

¹⁾ Specific levels depend on the device configuration

Power supply

via terminals 13-14

PQ3000 (see nameplate)	OVC ¹⁾	Consumption ²⁾	
V1: 110...230V AC 50/60Hz / 130...230V DC $\pm 15\%$	III (UL: II)	$\leq 30 \text{ VA}, \leq 13 \text{ W}$	
V2: 24...48V DC $\pm 15\%$	-	$\leq 13 \text{ W}$	
V3: 110...200V AC 50/60Hz / 110...200V DC $\pm 15\%$	III (UL: II)	$\leq 30 \text{ VA}, \leq 13 \text{ W}$	

PQ1000 / PQ5000 (see nameplate)	OVC ¹⁾	Consumption ²⁾	
		PQ1000	PQ5000
V1: 100...230V AC 50/60Hz / DC $\pm 15\%$	III	$\leq 18\text{VA}, \leq 8\text{W}$	$\leq 27\text{VA}, \leq 12\text{W}$
V2: 24...48V DC $\pm 15\%$	-	$\leq 8 \text{ W}$	$\leq 12 \text{ W}$

¹⁾ Overvoltage category (OVC); ²⁾ depends on the device hardware used

Available inputs / outputs and functional extensions

Basic unit	• 1 digital input • 2 digital outputs
Extensions	Optional modules • 2 relay outputs with changeover contacts • 2 bipolar analog outputs • 4 bipolar analog outputs • 4 passive digital inputs • 4 active digital inputs • GPS connection module • IRIG-B connection module (TTL) • 2 failure current channels (residual or earth current) • IEC61850 interface • PROFINET interface • 2 temperature inputs • PME central unit (for connecting PME radio modules)

- PQ1000: 1 extension may be present in the device
- PQ3000: Up to 3 extensions may be present in the device. Only one module can be equipped with analog outputs.
- PQ5000: Up to 2 extensions may be present in the device.

I/O interface

Analog outputs

	via plug-in terminals
Linearization:	Linear, kinked
Range:	$\pm 20 \text{ mA}$ (24 mA max.), bipolar
Uncertainty:	$\pm 0.2\%$ of 20 mA
Burden:	$\leq 500 \Omega$ (max. 10 V / 20 mA)
Burden influence:	$\leq 0.2\%$
Residual ripple:	$\leq 0.4\%$
Response time:	220...420 ms

Relays

	via plug-in terminals
Contact:	changeover contact
Load capacity:	250 V AC, 2 A, 500 VA 30 V DC, 2 A, 60 W

Passive digital inputs

	via plug-in terminals
Nominal voltage:	12 / 24 V DC (30 V max.)
Input current:	$< 7\text{mA}$
Logical ZERO:	- 3 up to + 5 V
Logical ONE:	8 up to 30 V
Minimum pulse width:	70...250ms

Active digital inputs

	via plug-in terminals
Open circuit voltage:	$\leq 15\text{V}$
Short circuit current:	$< 15\text{mA}$
Current at $R_{ON}=800\Omega$:	$\geq 2 \text{ mA}$
Minimum pulse width:	70...250ms

Digital outputs

	via plug-in terminals
Nominal voltage:	12 / 24 V DC (30 V max.)

Nominal current: 50 mA (60 mA max.)

Fault current detection via plug-in terminals

Number of channels 2; each channel provides two measurement ranges (2mA, 1A)

Zero suppression Measurement < 0.2% of measurement range

Measurement range 1A

Application: Direct measurement of a fault or earth wire current

Measurement transformer: Current transformer 1/1 up to 1000/1A

Instrument security factor FS5

Rated output 0.2 up to 1.5 VA

Measurement range: $I_{\text{Rated}} = 1.0\text{A}$ (max. 1.2A; crest factor 3)

Overload: 2A continuous; 20A, 5 x 1s, interval 300s

Self-consumption: $\leq I_2 \times 0.1 \Omega$

Monitoring: Alarm limit 0.03 ... 1000 A (2 up to 100% of primary measurement range)

Measurement range 2mA

Application: Residual current monitoring (RCM)

Measurement transformer: Residual current transformer 500/1 up to 1000/1A

Rated burden 100 Ω / 0.025 VA up to 200 Ω / 0.06 VA

Measurement range: $I_{\text{Rated}} = 2\text{mA}$ (max. 2.4mA; crest factor 3)

Overload: 40mA continuous; 200mA, 5 x 1s, interval 300s

Self-consumption: $\leq I_2 \times 64 \Omega$

Monitoring: Alarm limit 0.03 ... 1 A

Further settings

Alarm limit for OFF: $I_{\text{OFF}} = 90 \dots 75\%$ *)

Pre-warning limit: $I_{\text{WARN}} = 50\% \dots (I_{\text{OFF}} - 1\%)$ *)

Pre-warning OFF: $I_{\text{WARN}} - (10 \dots 25\%)$ *)

Response delay: 1...10s, separately for alarm and pre-warning

Dropout delay: 1...300s, separately for alarm and pre-warning

*) All percent values are related to the alarm limit (100%)

Temperature inputs via plug-in terminals

Number of channels: 2

Measurement current: <1.0mA

Connection: 2-wire

Input protection: Voltage limitation via protective diode

Used for Pt100 measurement

Measurement range: -50 up to 250°C / -58 up to 482°F

Uncertainty: $\pm 1.0 \%$ of measurement $\pm 1 \text{ K}$

Connection monitoring: Short-circuit (<20 Ω), wire / sensor breakage (>1000 Ω)

Alarm limits: 2

Response delay: 0...999 s, separately for each alarm limit

Dropout delay: 0...999 s, separately for each alarm limit

Used for PTC monitoring

Alarm active: >3.6 ... 4.0 k Ω

Alarm fallback: <1.5 ... 1.65 k Ω

Number of sensors: 1...6 single sensors (acc. DIN 44081) in series

1...2 triplet sensors (acc. DIN 44082) in series

Connection monitoring: Short-circuit (<15 Ω ON, >18 Ω OFF)

Application restriction: Ambient temperature of sensor $\geq -20^\circ\text{C}$

Response delay: 0...999 s

Dropout delay: 0...999 s

Interface

Ethernet via RJ45 socket

Protocol: Modbus/TCP, NTP, http, https, IPv4, IPv6
Physics: Ethernet 100BaseTX
Mode: 10/100 Mbit/s, full/half duplex, auto-negotiation

IEC61850 via RJ45 sockets, 2 equivalent ports
Protocol: IEC61850, NTP
Physics: Ethernet 100BaseTX
Mode: 10/100 Mbit/s, full/half duplex, auto-negotiation

PROFINET via RJ45 sockets, 2 equivalent ports
Conformance class: CC-B
Netload class: III
Protocol: PROFINET, LLDP, SNMP
Physics: Ethernet 100BaseTX
Mode: 10/100 Mbit/s, full/half duplex, auto-negotiation

Note: The interface may only be connected to a local Profinet network, which is designed as SELV circuit according to IEC 60950-1.

Modbus/RTU via plug-in terminal (A, B, C/X)
Protocol: Modbus/RTU
Physics: RS-485, max. 1200m (4000 ft)
Baud rate: 9'600, 19'200, 38'400, 57'600, 115'200 Baud
Number of participants: ≤ 32

Internal clock (RTC)

Uncertainty: ± 2 minutes / month (15 up to 30°C)
Synchronization: none, via Ethernet ([NTP protocol](#)), [GPS](#) or [IRIG-B](#) (TTL)
Running reserve: > 10 years

Uninterruptible power supply (UPS)

Type: VARTA Easy Pack EZPackL, UL listed MH16707
Nominal voltage: 3.7V
Capacity: 1150 mAh min., 4.5 Wh
Operating duration: 5 times 3 minutes
Life time: 3 up to 5 years, depending on operating and ambient conditions

Ambient conditions, general information

Operating temperature: • Device without UPS: –10 up to 15 up to 30 up to + 55°C
• Device with UPS: 0 up to 15 up to 30 up to + 35°C
(if used outside this operating temperature range, it is not ensured that the UPS battery pack is recharged).
Storage temperature: Base device: -25 up to +70°C;
Battery pack UPS: -20...60°C (<1 month); -20°...45°C (< 3 months);
-20...30°C (< 1 year)
Temperature influence: 0.5 x measurement uncertainty per 10 K
Long term drift: 0.5 x measurement uncertainty per year
Usage group: II (acc. EN 60 688)
Relative humidity: < 95% no condensation
Altitude: ≤ 2000 m max.
Device to be used indoor only!

Mechanical attributes

Housing material: Polycarbonate (Makrolon)
Flammability class: V-0 acc. UL94, non-dripping, free of halogen
Weight: 400 g (PQ1000), 800 g (PQ3000), 600g (PQ5000)
Dimensions: [Dimensional drawings](#)

Vibration withstand (test according to DIN EN 60 068-2-6)

Acceleration: • Device with display: ± 0.25 g (operating); 1.20 g (storage)

Frequency range: 10 ... 150 ... 10 Hz, rate of frequency sweep: 1 octave/minute
 Number of cycles: 10 in each of the 3 axes


Safety

The current inputs are galvanically isolated from each other

Protection class: II (protective insulation, voltage inputs via protective impedance)

Pollution degree: 2

Protection: Front: IP40, IP54 (PQ1000 / PQ3000 with sealing joint); Housing: IP30;
 Terminals: IP20



IP54 remark

Sealing joint must be applied on the entire circumference of the housing; tested for CE compliance only.

Rated voltage (versus earth):

PQ3000
 • Power supply V1: 110...230V AC / 130...230V DC
 • Power supply V2: 24...48V DC
 • Power supply V3: 110...200V AC / 110...200V DC
 PQ1000 / PQ5000
 • Power supply V1: 100...230V AC / DC
 • Power supply V2: 24...48V DC
 Relays: 250 V AC (OVC III)
 I/O's: 24 V DC

Test voltages:

Test time 60s, acc. IEC/EN 61010-1 (2011)

- power supply versus inputs U ¹⁾: 3600V AC
- power supply versus inputs I: 3000V AC
- power supply V1, V3 versus bus, I/O's: 3000V AC
- inputs U versus inputs I: 1800V AC
- inputs U versus bus, I/O's ¹⁾: 3600V AC
- inputs I versus bus, I/O's: 3000V AC
- inputs I versus inputs I: 1500V AC

¹⁾ During type test only, with all protective impedances removed



The device uses the principle of protective impedance for the voltage inputs to ensure protection against electric shock. All circuits of the device are tested during final inspection.

Prior to performing high voltage or isolation tests involving the voltage inputs, all output connections of the device, especially analog outputs, digital and relay outputs as well as Modbus and Ethernet interface, must be removed. A possible high-voltage test between input and output circuits must be limited to 500V DC, otherwise electronic components can be damaged.

Applied regulations, standards and directives

IEC/EN 61010-1	Safety regulations for electrical measuring, control and laboratory equipment
IEC/EN 61000-4-30 Ed.3	Power quality measurement methods
IEC/EN 61000-4-7	General guide on harmonics and interharmonics measurements
IEC/EN 61000-4-15	Flickermeter - Functional and design specifications
IEEE 1159.3	Recommended Practice for the Transfer of Power Quality Data
IEC 62586-1 Ed.2	Power quality measurement in power supply systems – Power quality instruments (PQI)
IEC 62586-2 Ed.2	Power quality measurement in power supply systems – Functional tests and uncertainty requirements
IEC TS 63383	Cybersecurity aspects of devices used for power metering and monitoring, power quality monitoring, data collection and analysis
EN50160	Voltage characteristics of electricity supplied by public distribution systems
IEC/EN 60688	Electrical measuring transducers for converting AC electrical variables into analog or digital signals
DIN 40 110	AC quantities
IEC/EN 60068-2-1/ -2/-3/-6/-27:	Ambient tests -1 Cold, -2 Dry heat, -3 Damp heat, -6 Vibration, -27 Shock
IEC/EN 60529	Protection type by case
IEC/EN 61000-6-4	Electromagnetic compatibility (EMC): Emission standard for industrial environments
IEC/EN 61000-6-5	Electromagnetic compatibility (EMC): Immunity for equipment used in power station and substation environment
IEC/EN 61131-2	Programmable controllers - equipment, requirements and tests (digital inputs/outputs 12/24V DC)
IEC 62053-22: 2003	Static meters for AC active energy (classes 0,1S, 0,2S and 0,5S)
IEC 62053-24: 2014	Static meters for reactive energy at fundamental frequency (classes 0,5S, 1S, 1, 2 and 3)
IEC 62053-31	Pulse output devices for electromechanical and electronic meters (S0 output)
UL94	Tests for flammability of plastic materials for parts in devices and appliances
2011/65/EU (RoHS)	EU directive on the restriction of the use of certain hazardous substances

Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

This device complies with part 15 of the FCC:


Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class A digital apparatus complies with Canadian ICES-0003.


10. Dimensional drawings

All dimensions in [mm]


LINAX PQ1000 with display




LINAX PQ1000 for hat-rail with display



LINAX PQ1000 for hat-rail without display



LINAX PQ3000



LINAX PQ5000



Annex

A Description of measured quantities

Used abbreviations

1L	Single phase system
2L	Split phase; system with 2 phases and center tap
3Lb	3-wire system with balanced load
3Lu	3-wire system with unbalanced load
3Lu.A	3-wire system with unbalanced load, Aron connection (only 2 currents connected)
4Lu	4-wire system with unbalanced load

A1 Basic measurements

The basic measured quantities are calculated each 200ms by determining an average over 10 cycles at 50Hz or 12 cycles at 60Hz. If a measurement is available depends on the selected system.

Depending on the measured quantity also minimum and maximum values are determined and non-volatile stored with timestamp. These values may be reset by the user via display, see [resetting of measurements](#).

Measurement	present	max	min	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Voltage U	•	•	•	✓	✓				
Voltage U _{1N}	•	•	•		✓				✓
Voltage U _{2N}	•	•	•		✓				✓
Voltage U _{3N}	•	•	•						✓
Voltage U ₁₂	•	•	•			✓	✓	✓	✓
Voltage U ₂₃	•	•	•			✓	✓	✓	✓
Voltage U ₃₁	•	•	•			✓	✓	✓	✓
Voltage U _{NE} ³⁾	•	•		✓	✓	✓	✓	✓	✓
Current I	•	•		✓		✓			
Current I1	•	•			✓		✓	✓	✓
Current I2	•	•			✓		✓	✓	✓
Current I3	•	•					✓	✓	✓
Neutral current I _N	•	•		✓	✓				✓
Earth current I _{PE} (calculated)	•	•							✓
Active power P	•	•		✓	✓	✓	✓	✓	✓
Active power P1	•	•			✓				✓
Active power P2	•	•			✓				✓
Active power P3	•	•							✓
Fundamental active power P(H1)	•	•		✓	✓	✓	✓	✓	✓
Fundamental active power P1(H1)	•	•			✓				✓
Fundamental active power P2(H1)	•	•			✓				✓
Fundamental active power P3(H1)	•	•							✓
Total reactive power Q	•	•		✓	✓	✓	✓	✓	✓
Total reactive power Q1	•	•			✓				✓
Total reactive power Q2	•	•			✓				✓
Total reactive power Q3	•	•							✓
Distortion reactive power D	•	•		✓	✓	✓	✓	✓	✓
Distortion reactive power D1	•	•			✓				✓
Distortion reactive power D2	•	•			✓				✓
Distortion reactive power D3	•	•							✓
Fundamental reactive power Q(H1)	•	•		✓	✓	✓	✓	✓	✓
Fundamental reactive power Q1(H1)	•	•			✓				✓
Fundamental reactive power Q2(H1)	•	•			✓				✓
Fundamental reactive power Q3(H1)	•	•							✓

Measurement	present	max	min	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Apparent power S	•	•		√	√	√	√	√	√
Apparent power S1	•	•			√				√
Apparent power S2	•	•			√				√
Apparent power S3	•	•							√
Fundamental apparent power S(H1)	•	•		√	√	√	√	√	√
Fundamental apparent power S1(H1)	•	•			√				√
Fundamental apparent power S2(H1)	•	•			√				√
Fundamental apparent power S3(H1)	•	•							√
Frequency F	•	•	•	√	√	√	√	√	√
Power factor PF	•			√	√	√	√	√	√
Power factor PF1	•				√				√
Power factor PF2	•				√				√
Power factor PF3	•								√
PF quadrant I			•	√	√	√	√	√	√
PF quadrant II			•	√	√	√	√	√	√
PF quadrant III			•	√	√	√	√	√	√
PF quadrant IV			•	√	√	√	√	√	√
Reactive power factor QF	•			√	√	√	√	√	√
Reactive power factor QF1	•				√				√
Reactive power factor QF2	•				√				√
Reactive power factor QF3	•								√
Load factor LF	•			√	√	√	√	√	√
Load factor LF1	•				√				√
Load factor LF2	•				√				√
Load factor LF3	•								√
cosφ (H1)	•			√	√	√	√	√	√
cosφ L1 (H1)	•				√				√
cosφ L2 (H1)	•				√				√
cosφ L3 (H1)	•								√
cosφ (H1) quadrant I			•	√	√	√	√	√	√
cosφ (H1) quadrant II			•	√	√	√	√	√	√
cosφ (H1) quadrant III			•	√	√	√	√	√	√
cosφ (H1) quadrant IV			•	√	√	√	√	√	√
tanφ (H1)	•			√	√	√	√	√	√
tanφ L1 (H1)	•				√				√
tanφ L2 (H1)	•				√				√
tanφ L3 (H1)	•								√
$U_{mean}=(U1N+U2N)/2$	•				√				
$U_{mean}=(U1N+U2N+U3N)/3$	•								√
$U_{mean}=(U12+U23+U31)/3$	•					√	√	√	
$I_{mean}=(I1+I2)/2$	•				√				
$I_{mean}=(I1+I2+I3)/3$	•						√		√
IMS, Average current with sign of P	•			√	√	√	√	√	√
Phase angle between U1 and U2	•					√	√	√	√
Phase angle between U2 and U3	•					√	√	√	√
Phase angle between U3 and U1	•					√	√	√	√
Angle between U and I	•			√		√	√	√	
Angle between U1 and I1	•				√				√
Angle between U2 and I2	•				√				√
Angle between U3 and I3	•								√
Maximum ΔU <> Um ¹⁾	•	•			√	√	√	√	√
Maximum ΔI <> Im ²⁾	•	•			√		√		√

¹⁾ maximum deviation from the mean value of all voltages ([see A3](#))

²⁾ maximum deviation from the mean value of all currents ([see A3](#))


³⁾ For 3-wire systems: Homopolar voltage, only if its measurement has been activated

• Available via communication interface only

Reactive power

Most of the loads consume a combination of ohmic and inductive current from the power system. Reactive power arises by means of the inductive load. But the number of non-linear loads, such as RPM regulated drives, rectifiers, thyristor-controlled systems or fluorescent lamps, is increasing. They cause non-sinusoidal AC currents, which may be represented as a sum of harmonics. Thus, the reactive power to transmit increases and leads to higher transmission losses and higher energy costs. This part of the reactive power is called distortion reactive power.

Normally reactive power is unwanted, because there is no usable active component in it. Because the transmission of reactive power over long distances is uneconomic, it makes sense to install compensation systems close to the consumers. So, transmission capacities may be used better and losses and voltage drops by means of harmonic currents can be avoided.



- P: Active power
- S: Apparent power including harmonic components
- S1: Fundamental apparent power
- Q: Total reactive power
- Q(H1): Fundamental reactive power
- D: Distortion reactive power

The reactive power may be divided in a fundamental and a distortion component. Only the fundamental reactive power may be compensated directly by means of the classical capacitive method. The distortion components have to be combated using inductors or active harmonic conditioners.

The **load factor PF** is the relation between active power P and apparent power S, including all possibly existing harmonic parts. This factor is often called $\cos\varphi$, which is only partly correct. The PF corresponds to the $\cos\varphi$ only, if there is no harmonic content present in the system. So, the $\cos\varphi$ represents the relation between the active power P and the fundamental apparent power S(H1).


The **$\tan\varphi$** is often used as a target quantity for the capacitive reactive power compensation. It corresponds to the relation of the fundamental reactive power Q(H1) and the active power P.

Power factors

The **power factor PF** gives the relation between active and apparent power. If there are no harmonics present in the system, it corresponds to the $\cos\varphi$ or displacement power factor. The PF has a range of $-1 \dots 0 \dots +1$, where the sign gives the direction of energy flow.

The **load factor LF** is a quantity derived from the PF, which allows making a statement about the load type. Only this way it's possible to measure a range like 0.5 capacitive ... 1 ... 0.5 inductive in a non-ambiguous way.

The **reactive power factor QF** gives the relation between reactive and apparent power.




Example from the perspective of an energy consumer

Zero displacement voltage U_{NE}

Starting from the generating system with star point E (which is normally earthed), the star point (N) on load side is shifted in case of unbalanced load. The zero displacement voltage between E and N may be determined by a vectorial addition of the voltage vectors of the three phases:


$$\underline{U}_{NE} = - (\underline{U}_{1N} + \underline{U}_{2N} + \underline{U}_{3N}) / 3$$

A displacement voltage may also occur due to harmonics of order 3, 9, 15, 21 etc., because the dedicated currents add in the neutral wire.



Earth fault monitoring in IT systems

Via the determination of the zero displacement voltage it's possible to detect a first earth fault in an unearthed IT system. To do so, the device is configured for measurement in a 4-wire system with unbalanced load and the neutral connector is connected to earth. In case of a single-phase earth fault there is a resulting zero displacement voltage of $U_{LL} / \sqrt{3}$. The alarming may be done e.g. by means of a relay output.



Because in case of a fault the voltage triangle formed by the three phases does not change, the voltage and current measurements as well as the system power values will still be measured and displayed correctly. Also, the meters carry on to work as expected.

The method is suited to detect a fault condition during normal operation. A declination of the isolation resistance may not be detected this way. This should be measured during a periodical control of the system using a mobile system.

Another possibility to analyze fault conditions in a grid offers the method of the [symmetrical components](#) as described in A3.

A2 Harmonic analysis

The harmonic analysis is performed according IEC 61000-4-7 over 10 cycles at 50Hz or 12 cycles at 60Hz. If a measured quantity is available depends on the selected system.

Measurement	prese	max	1L	2L	3Lb	3Lu	3Lu.A	4Lu
THD Voltage U1N/U	•	•	√	√				√
THD Voltage U2N	•	•		√				√
THD Voltage U3N	•	•						√
THD Voltage U12	•	•			√	√	√	
THD Voltage U23	•	•			√	√	√	
THD Voltage U31	•	•			√	√	√	
THD Current I1/I	•	•	√	√	√	√	√	√
THD Current I2	•	•		√		√	√	√
THD Current I3	•	•				√	√	√
TDD Current I1/I	•	•	√	√	√	√	√	√
TDD Current I2	•	•		√		√	√	√
TDD Current I3	•	•				√	√	√
Harmonic contents 2 nd ...50 th U1N/U	•	•	√	√				√
Harmonic contents 2 nd ...50 th U2N	•	•		√				√
Harmonic contents 2 nd ...50 th U3N	•	•						√
Harmonic contents 2 nd ...50 th U12	•	•			√	√	√	
Harmonic contents 2 nd ...50 th U23	•	•			√	√	√	
Harmonic contents 2 nd ...50 th U31	•	•			√	√	√	
Harmonic contents 2 nd ...50 th I1/I	•	•	√	√	√	√	√	√
Harmonic contents 2 nd ...50 th I2	•	•		√		√	√	√
Harmonic contents 2 nd ...50 th I3	•	•				√	√	√

• Available via communication interface only

Harmonic contents are available up to the 89th (50Hz) or 75th (60Hz) on the Modbus interface

Harmonics

Harmonics are multiples of the fundamental or system frequency. They arise if non-linear loads, such as RPM regulated drives, rectifiers, thyristor-controlled systems or fluorescent lamps are present in the power system. Thus, undesired side effects occur, such as additional thermal stress to operational resources or electrical mains, which lead to an advanced aging or even damage. Also, the reliability of sensitive loads can be affected and unexplainable disturbances may occur. In industrial networks the image of the harmonics gives good information about the kind of loads connected. See also:

► [Increase of reactive power due to harmonic currents](#)

TDD (Total Demand Distortion)

The complete harmonic content of the currents is calculated additionally as Total Demand Distortion, briefly TDD. This value is scaled to the rated current or rated power. Only this way it's possible to estimate the influence of the current harmonics on the connected equipment correctly.

Maximum values

The maximum values of the harmonic analysis arise from the monitoring of THD and TDD. The maximum values of individual harmonics are not monitored separately, but are stored if a maximum value of THD or TDD is detected. The image of the maximum harmonics therefore always corresponds to the dedicated THD or TDD.



The accuracy of the harmonic analysis strongly depends on the quality of the current and voltage transformers possibly used. In the harmonics range transformers normally change both, the amplitude and the phase of the signals to measure. It's valid: The higher the frequency of the harmonic, the higher its damping or phase shift.

A3 System imbalance

Measured quantity	present	max	min	1L	2L	3Lb	3Lu	3Lu.A	4Lu
UR1: Positive sequence [V]	•					√	√	√	√
UR2: Negative sequence [V]	•					√	√	√	√
U0: Zero sequence [V]	•								√
U: Imbalance UR2/UR1	•	•				√	√	√	√
U: Imbalance U0/UR1	•	•							√
IR1: Positive sequence [A]	•						√		√
IR2: Negative sequence [A]	•						√		√
I0: Zero sequence [A]	•								√
I: Imbalance IR2/IR1	•	•					√		√
I: Imbalance I0/IR1	•	•							√

• Available via communication interface only

Imbalance in three-phase systems may occur due to single-phase loads, but also due to failures, such as e.g. the blowing of a fuse, an earth fault, a phase failure or an isolation defect. Also, harmonics of the 3rd, 9th, 15th, 21st etc. order, which add in the neutral wire, may lead to imbalance. Operating resources dimensioned to rated values, such as three-phase generators, transformers or motors on load side, may be excessively stressed by imbalance. So, a shorter life cycle, a damage or failure due to thermal stress can result. Therefore, monitoring imbalance helps to reduce the costs for maintenance and extends the undisturbed operating time of the used resources.

Imbalance or unbalanced load relays use different measurement principles. One of them is the approach of the symmetrical components, the other one calculates the maximum deviation from the mean-value of the three phase values. The results of these methods are not equal and don't have the same intention. Both of these principles are implemented in the device.

Symmetrical components (acc. Fortescue)

The imbalance calculation method by means of the symmetrical components is ambitious and intensive to calculate. The results may be used for disturbance analysis and for protection purposes in three-phase systems. The real existing system is divided in symmetrical system parts: A positive sequence, a negative sequence and (for systems with neutral conductor) a zero sequence system. The approach is easiest to understand for rotating machines. The positive sequence represents a positive rotating field, the negative sequence a negative (braking) rotating field with opposite sense of direction. Therefore, the negative sequence prevents that the machine can generate the full turning moment. For e.g. generators the maximum permissible current imbalance is typically limited to a value of 8...12%.

Maximum deviation from the mean value

The calculation of the maximum deviation from the mean value of the phase currents or phase voltages gives the information if a grid or substation is imbalanced loaded. The results are independent of rated values and the present load situation. So, a more symmetrical system can be aspired, e.g. by changing loads from one phase to another.


Failure detection is possible as well. The capacitors used in compensation systems are wear parts, which fail quite often and then have to be replaced. When using three phase power capacitors all phases will be compensated equally which leads to almost identical currents flowing through the capacitors, if the system load is comparable. By monitoring the current imbalance it's then possible to estimate if a capacitor failure is present.

The maximum deviations are calculated in the same steps as the instantaneous values and therefore are arranged there ([see A1](#)).

A4 Mean values and trend

Measured quantity		Present	Trend	max	min	History
Active power I+IV	10s...60min. ¹⁾	•	•	•	•	5
Active power II+III	10s...60min. ¹⁾	•	•	•	•	5
Reactive power I+II	10s...60min. ¹⁾	•	•	•	•	5
Reactive power III+IV	10s...60min. ¹⁾	•	•	•	•	5
Apparent power	10s...60min. ¹⁾	•	•	•	•	5
Mean value quantity 1	10s...60min. ²⁾	•	•	•	•	1
....						
Mean value quantity 12	10s...60min. ²⁾	•	•	•	•	1

¹⁾ Interval time t1 ²⁾ Interval time t2



The device calculates automatically the mean values of all system power quantities. In addition up to 12 further mean value quantities can be freely selected.

Calculating the mean-values

The mean value calculation is performed via integration of the measured instantaneous values over a configurable averaging interval. The interval time may be selected in the range from 10 seconds up to one hour. Possible interim values are set the way that a multiple of it is equal to a minute or an hour. Mean values of power quantities (interval time t1) and free quantities (interval time t2) may have different averaging intervals.

Synchronization

For the synchronization of the averaging intervals the internal clock is used. To be able to compare the mean values of power quantities on generating and demand side it is therefore required to synchronize the clock via NTP or GPS.

Trend

The estimated final value (trend) of mean values is determined by weighted addition of measurements of the past and the present interval. It serves for early detection of a possible exceeding of a given maximum value. This can then be avoided, e.g. by switching off an active load.

History

For mean values of system powers the last 5 interval values may be displayed on the device or read via interface. For configurable quantities the value of the last interval is provided via communication interface.

Bimetal current


This measured quantity serves for measuring the long-term effect of the current, e.g. for monitoring the warming of a current-carrying line. To do so, an exponential function is used, similar to the charging curve of a capacitor. The response time of the bimetal function can be freely selected, but normally it corresponds to the interval for determining the power mean-values.

Measured quantity	Presen	max	min	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Bimetal current IB, 1...60min. ³⁾	•	•		√		√			
Bimetal current IB1, 1...60min. ³⁾	•	•			√		√	√	√
Bimetal current IB2, 1...60min. ³⁾	•	•			√		√	√	√
Bimetal current IB3, 1...60min. ³⁾	•	•					√	√	√

³⁾ Interval time t3

A5 Meters

Measured quantity	1L	2L	3Lb	3Lu	3Lu.A	4Lu
Active energy I+IV, high tariff	•	•	•	•	•	•
Active energy II+III, high tariff	•	•	•	•	•	•
Reactive energy I+II, high tariff	•	•	•	•	•	•
Reactive energy III+IV, high tariff	•	•	•	•	•	•
Active energy I+IV, low tariff	•	•	•	•	•	•
Active energy II+III, low tariff	•	•	•	•	•	•
Reactive energy I+II, low tariff	•	•	•	•	•	•
Reactive energy III+IV, low tariff	•	•	•	•	•	•
User configured meter 1	Only basic quantities can be selected which are supported in the present system.					
User configured meter 2						
User configured meter 3						
User configured meter 4						
User configured meter 5						
User configured meter 6						
User configured meter 7						
User configured meter 8						
User configured meter 9						
User configured meter 10						
User configured meter 11						
User configured meter 12						



Standard meters

The meters for active and reactive energy of the system are always active.

User configured meters

To each of these meters the user can freely assign a basic quantity.

Programmable meter resolution



For all meters the resolution (displayed unit) can be selected almost freely. This way, applications with short measurement times, e.g. energy consumption of a working day or shift, can be realized. The smaller the basic unit is selected, the faster the meter overflow is reached.

B Display matrices

B0 Used abbreviations for the measurements

Instantaneous values

Name	Measurement identification	Unit	Description
U	U TRMS	V	Voltage system
U1N	U 1N TRMS	V	Voltage between phase L1 and neutral
U2N	U 2N TRMS	V	Voltage between phase L2 and neutral
U3N	U 3N TRMS	V	Voltage between phase L3 and neutral
U12	U 12 TRMS	V	Voltage between phases L1 and L2
U23	U 23 TRMS	V	Voltage between phases L2 and L3
U31	U 31 TRMS	V	Voltage between phases L3 and L1
UNE	U NE TRMS	V	Zero displacement voltage 4-wire systems
I	I TRMS	A	Current system
I1	I 1 TRMS	A	Current phase L1
I2	I 2 TRMS	A	Current phase L2
I3	I 3 TRMS	A	Current phase L3
IN	I N TRMS	A	Neutral current
IPE	I PE TRMS		Earth current
P	P TRMS	W	Active power system (P=P1+P2+P3)
P1	P 1 TRMS	W	Active power phase L1
P2	P 2 TRMS	W	Active power phase L2
P3	P 3 TRMS	W	Active power phase L3
Q	Q TRMS	var	Reactive power system (Q=Q1+Q2+Q3)
Q1	Q 1 TRMS	var	Reactive power phase L1
Q2	Q 2 TRMS	var	Reactive power phase L2
Q3	Q 3 TRMS	var	Reactive power phase L3
S	S TRMS	VA	Apparent power system
S1	S 1 TRMS	VA	Apparent power phase L1
S2	S 2 TRMS	VA	Apparent power phase L2
S3	S 3 TRMS	VA	Apparent power phase L3
F	F TRMS	Hz	System frequency
PF	PF TRMS		Active power factor P/S
PF1	PF 1 TRMS		Active power factor P1/S1
PF2	PF 2 TRMS		Active power factor P2/S2
PF3	PF 3 TRMS		Active power factor P3/S3
QF	QF TRMS		Reactive power factor Q / S
QF1	QF 1 TRMS		Reactive power factor Q1 / S1
QF2	QF 2 TRMS		Reactive power factor Q2 / S2
QF3	QF 3 TRMS		Reactive power factor Q3 / S3
LF	LF TRMS		Load factor system
LF1	LF 1 TRMS		Load factor phase L1
LF2	LF 2 TRMS		Load factor phase L2
LF3	LF 3 TRMS		Load factor phase L3
UR1	U pos SEQ	V	Positive sequence voltage
UR2	U neg SEQ	V	Negative sequence voltage
U0	U zero SEQ	V	Zero sequence voltage
IR1	I pos SEQ	A	Positive sequence current
IR2	I neg SEQ	A	Negative sequence current
I0	I zero SEQ	A	Zero sequence current
UR2R1	U neg/pos UNB	%	Unbalance factor voltage UR2/UR1
IR2R1	I neg/pos UNB	%	Unbalance factor current IR2/IR1
U0R1	U zero/pos UNB	%	Unbalance factor voltage U0/UR1
I0R1	I zero/pos UNB	%	Unbalance factor current I0/IR1
IMS	I  TRMS	A	Average current with sign of P

Name	Measurement identification		Unit	Description
Pst1N	Pst 1N	10min		Short term flicker U1N, Averaging time 10min.
Pst2N	Pst 2N	10min		Short term flicker U2N, Averaging time 10min.
Pst3N	Pst 3N	10min		Short term flicker U3N, Averaging time 10min.
Pst12	Pst 12	10min		Short term flicker U12, Averaging time 10min.
Pst23	Pst 23	10min		Short term flicker U23, Averaging time 10min.
Pst31	Pst 31	10min		Short term flicker U31, Averaging time 10min.
UD	$U \leq$ 1N	TRMS	V	Underdeviation system voltage
UD1N	$U \leq$ 1N	TRMS	V	Underdeviation voltage U1N
UD2N	$U \leq$ 2N	TRMS	V	Underdeviation voltage U2N
UD3N	$U \leq$ 3N	TRMS	V	Underdeviation voltage U3N
UD12	$U \leq$ 12	TRMS	V	Underdeviation voltage U12
UD23	$U \leq$ 23	TRMS	V	Underdeviation voltage U23
UD31	$U \leq$ 31	TRMS	V	Underdeviation voltage U31
OD	$U \geq$ 1N	TRMS	V	Overdeviation system voltage
OD1N	$U \geq$ 1N	TRMS	V	Overdeviation voltage U1N
OD2N	$U \geq$ 2N	TRMS	V	Overdeviation voltage U2N
OD3N	$U \geq$ 3N	TRMS	V	Overdeviation voltage U3N
OD12	$U \geq$ 12	TRMS	V	Overdeviation voltage U12
OD23	$U \geq$ 23	TRMS	V	Overdeviation voltage U23
OD31	$U \geq$ 31	TRMS	V	Overdeviation voltage U31

Minimum and maximum of instantaneous values

Name	Measurement identification			Unit	Description
U_MM	U		TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U
U1N_MM	U	1N	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U1N
U2N_MM	U	2N	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U2N
U3N_MM	U	3N	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U3N
U12_MM	U	12	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U12
U23_MM	U	23	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U23
U31_MM	U	31	TRMS $\begin{smallmatrix} \blacktriangle TS \\ \blacktriangledown TS \end{smallmatrix}$	V	Minimum and maximum value of U31
UNE_MAX	U	NE	TRMS $\blacktriangle TS$	V	Maximum value of UNE
I_MAX	I		TRMS $\blacktriangle TS$	A	Maximum value of I
I1_MAX	I	1	TRMS $\blacktriangle TS$	A	Maximum value of I1
I2_MAX	I	2	TRMS $\blacktriangle TS$	A	Maximum value of I2
I3_MAX	I	3	TRMS $\blacktriangle TS$	A	Maximum value of I3
IN_MAX	I	N	TRMS $\blacktriangle TS$	A	Maximum value of IN
IPE_MAX	I	PE	TRMS $\blacktriangle TS$	A	Maximum value of IPE
P_MAX	P		TRMS $\blacktriangle TS$	W	Maximum value of P
P1_MAX	P	1	TRMS $\blacktriangle TS$	W	Maximum value of P1
P2_MAX	P	2	TRMS $\blacktriangle TS$	W	Maximum value of P2
P3_MAX	P	3	TRMS $\blacktriangle TS$	W	Maximum value of P3
Q_MAX	Q		TRMS $\blacktriangle TS$	var	Maximum value of Q
Q1_MAX	Q	1	TRMS $\blacktriangle TS$	var	Maximum value of Q1
Q2_MAX	Q	2	TRMS $\blacktriangle TS$	var	Maximum value of Q2
Q3_MAX	Q	3	TRMS $\blacktriangle TS$	var	Maximum value of Q3
S_MAX	S		TRMS $\blacktriangle TS$	VA	Maximum value of S
S1_MAX	S	1	TRMS $\blacktriangle TS$	VA	Maximum value of S1
S2_MAX	S	2	TRMS $\blacktriangle TS$	VA	Maximum value of S2
S3_MAX	S	3	TRMS $\blacktriangle TS$	VA	Maximum value of S3
F_MM	F		TRMS $\blacktriangle TS$	Hz	Minimum and maximum value of F
UR21_MAX	U	neg/pos	UNB $\blacktriangle TS$	%	Maximum value of UR2/UR1
IR21_MAX	I	neg/pos	UNB $\blacktriangle TS$	%	Maximum value of IR2/IR1
THD_U_MAX	U		THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U
THD_U1N_MAX	U	1N	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U1N
THD_U2N_MAX	U	2N	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U2N
THD_U3N_MAX	U	3N	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U3N
THD_U12_MAX	U	12	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U12
THD_U23_MAX	U	23	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U23
THD_U31_MAX	U	31	THD $\blacktriangle TS$	%	Max. Total Harmonic Distortion of U31
TDD_I_MAX	I		TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I
TDD_I1_MAX	I	1	TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I1
TDD_I2_MAX	I	2	TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I2
TDD_I3_MAX	I	3	TDD $\blacktriangle TS$	%	Max. Total Demand Distortion of I3

TS: Timestamp of occurrence, e.g. 2014/09/17 11:12:03

Mean-values, trend and bimetal current

Name	Measurement identification					Unit	Description
M1	(m)	(p)	(q)		(t2)	(mu)	Mean-value 1
M2	(m)	(p)	(q)		(t2)	(mu)	Mean-value 2
....	(m)	(p)	(q)		(t2)	(mu)	
M11	(m)	(p)	(q)		(t2)	(mu)	Mean-value 11
M12	(m)	(p)	(q)		(t2)	(mu)	Mean-value 12
TR_M1	(m)	(p)	(q)		(t2)	(mu)	Trend mean-value 1
TR_M2	(m)	(p)	(q)		(t2)	(mu)	Trend mean-value 2
....	(m)	(p)	(q)		(t2)	(mu)	
TR_M11	(m)	(p)	(q)		(t2)	(mu)	Trend mean-value 11
TR_M12	(m)	(p)	(q)		(t2)	(mu)	Trend mean-value 12
IB	IB				(t3)	A	Bimetal current, system
IB1	IB	1			(t3)	A	Bimetal current, phase L1
IB2	IB	2			(t3)	A	Bimetal current, phase L2
IB3	IB	3			(t3)	A	Bimetal current, phase L3

Minimum and maximum of mean-values and bimetal-current

Name	Measurement identification					Unit	Description
M1_MM	(m)	(p)	(q)		(t2)  TS  TS	..	Min/Max mean-value 1
M2_MM	(m)	(p)	(q)		(t2)  TS  TS	..	Min/Max mean-value 2
....	(m)	(p)	(q)		(t2)  TS  TS	..	
M11_MM	(m)	(p)	(q)		(t2)  TS  TS	..	Min/Max mean-value 11
M12_MM	(m)	(p)	(q)		(t2)  TS  TS	..	Min/Max mean-value 12
IB_MAX	IB				(t3)  TS	A	Maximum bimetal current, system
IB1_MAX	IB	1			(t3)  TS	A	Maximum Bimetal current, phase L1
IB2_MAX	IB	2			(t3)  TS	A	Maximum Bimetal current, phase L2
IB3_MAX	IB	3			(t3)  TS	A	Maximum Bimetal current, phase L3

Meters

Name	Measurement identification			Unit	Description
ΣP_I_IV_HT	P		ΣHT	Wh	Meter P I+IV, high tariff
ΣP_II_III_HT	P		ΣHT	Wh	Meter P II+III, high tariff
ΣQ_I_II_HT	Q		ΣHT	varh	Meter Q I+II, high tariff
ΣQ_III_IV_HT	Q		ΣHT	varh	Meter Q III+IV, high tariff
ΣP_I_IV_LT	P		ΣLT	Wh	Meter P I+IV, low tariff
ΣP_II_III_LT	P		ΣLT	Wh	Meter P II+III, low tariff
ΣQ_I_II_LT	Q		ΣLT	varh	Meter Q I+II, low tariff
ΣQ_III_IV_LT	Q		ΣLT	varh	Meter Q III+IV, low tariff
ΣMETER1	(m)	(p)	(qg) Σ(T)	(mu)	User meter 1, tariff HT or LT
ΣMETER2	(m)	(p)	(qg) Σ(T)	(mu)	User meter 2, tariff HT or LT
.....	(m)	(p)	(qg) Σ(T)	(mu)	
ΣMETER11	(m)	(p)	(qg) Σ(T)	(mu)	User meter 11, tariff HT or LT
ΣMETER12	(m)	(p)	(qg) Σ(T)	(mu)	User meter 12, tariff HT or LT

(m): Short description of basic quantity, e.g. „P“

(p): Phase reference of the selected quantity, e.g. „1“






(q): Quadrant information, e.g. „I+IV“



(qg): Graphical quadrant information, e.g. 

(T): Associated tariff, e.g. „HT“ or „LT“

(mu): Unit of basic quantity

Graphical measurement displays

Name	Presentation	Description
Px_TRIANGLE		Graphic of the power triangle consisting of: • Active, reactive and apparent power Px, Qx, Sx • Distortion reactive power Dx • Fundamental reactive power Qx(H1) • $\cos(\varphi)$ of fundamental • Active power factor PFx
PF_MIN		Graphic: Minimum active power factor PF in all 4 quadrants
Cφ_MIN	(as PF_MIN)	Graphic: Minimum $\cos(\varphi)$ in all 4 quadrants
I> m.1 / m.2		Graphic: Present measurements and states of fault-current monitoring <i>Data available only, if the device is equipped with at least one optional fault-current module.</i>
θ m.1 / m.2		Graphic: Present measurements and states of temperature monitoring <i>Data available only, if the device is equipped with at least one temperature module.</i>
MT_P_I_IV		Graphic mean-value P (I+IV) Trend, last 5 interval values, minimum and maximum
MT_P_II_III	(as MT_P_I_IV)	Graphic mean-value P (II+III) Trend, last 5 interval values, minimum and maximum
MT_Q_I_II	(as MT_P_I_IV)	Graphic mean-value Q (I+II) Trend, last 5 interval values, minimum and maximum
MT_Q_III_IV	(as MT_P_I_IV)	Graphic mean-value Q (III+IV) Trend, last 5 interval values, minimum and maximum
MT_S	(as MT_P_I_IV)	Graphic mean-value S: Trend, last 5 interval values, minimum and maximum

HO_IX		Graphic: Odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all currents
HO_UX	(as HO_IX)	Graphic: Odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all voltages
HE_IX	(as HO_IX)	Graphic: Even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all currents
HE_UX	(as HO_IX)	Graphic: Even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all voltages
HO_UX_MAX	(as HO_IX)	Graphic: Maximum values odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all voltages
HO_IX_MAX	(as HO_IX)	Graphic: Maximum values odd harmonics 3 rd up to 49 th + Total Harmonic Distortion of all currents
HE_UX_MAX	(as HO_IX)	Graphic: Maximum values even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all voltages
HE_IX_MAX	(as HO_IX)	Graphic: Maximum values even harmonics 2 nd up to 50 th + Total Harmonic Distortion of all currents
PHASOR		Graphic: All current and voltage phasors with present load situation

B1 Display matrices for single phase system



Instantaneous values

Device	Corresponding matrix			
PQ1000	U I P F	U_MM I_MAX P_MAX F_MM		
	P Q S PF	P_MAX Q_MAX S_MAX		
	P_TRIANGLE			
	PF_MIN	Cφ_MIN		
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2	
	ϑ 1.1 / 1.2	ϑ 2.1 / 2.2	ϑ 3.1 / 3.2	
PQ3000 PQ5000	U UNE F	U_MM UNE_MAX F_MM	Pst1N	UD OD
	I IN IMS	I_MAX IN_MAX		
	P Q S PF	P_MAX Q_MAX S_MAX		
	P_TRIANGLE			
	PF_MIN	Cφ_MIN		
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2	
	ϑ 1.1 / 1.2	ϑ 2.1 / 2.2	ϑ 3.1 / 3.2	

B2 Display matrices for split-phase (two-phase) systems



Instantaneous values

Device	Corresponding matrix				
PQ1000	U1N U2N U UNE	U1N_MM U2N_MM U_MM UNE_MAX			
	I1 I2 I1_MAX I2_MAX				
	P Q F PF	P1 P2 Q1 Q2	P_MAX Q_MAX S_MAX	P1_MAX P2_MAX Q1_MAX Q2_MAX	
	P_TRIANGLE	P1_TRIANGLE	P2_TRIANGLE		
	PF_MIN	Cφ_MIN			
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2		
	∅ 1.1 / 1.2	∅ 2.1 / 2.2	∅ 3.1 / 3.2		
PQ3000	U1N U2N U UNE	U1N_MM U2N_MM U_MM UNE_MAX	Pst1N Pst2N	UD12 UD1N UD2N	OD12 OD1N OD2N
	I1 I2 IN IPE	I1_MAX I2_MAX IN_MAX IPE_MAX			
	P Q F PF	P1 P2 Q1 Q2	P_MAX / P1_MAX Q_MAX / P2_MAX S_MAX / Q1_MAX F_MM / Q2_MAX		
	P_TRIANGLE	P1_TRIANGLE	P2_TRIANGLE		
	PF_MIN	Cφ_MIN			
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2		
	∅ 1.1 / 1.2	∅ 2.1 / 2.2	∅ 3.1 / 3.2		
PQ5000	U1N U2N U UNE	U1N_MM U2N_MM U_MM UNE_MAX	Pst1N Pst2N	UD12 UD1N UD2N	OD12 OD1N OD2N
	I1 I2 IN IPE	I1_MAX I2_MAX IN_MAX IPE_MAX			
	P Q F PF	P1 P2 Q1 Q2	P_MAX Q_MAX S_MAX		P1_MAX P2_MAX Q1_MAX Q2_MAX
	P_TRIANGLE	P1_TRIANGLE	P2_TRIANGLE		
	PF_MIN	Cφ_MIN			
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2		
	∅ 1.1 / 1.2	∅ 2.1 / 2.2	∅ 3.1 / 3.2		

B3 Display matrices for 3-wire system, balanced load

 Instantaneous values

Device	Corresponding matrix						
PQ1000	U12 U23 U31 F		U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX			
	I I_MAX IMS						
	P Q S PF		P_MAX Q_MAX S_MAX				
	P_TRIANGLE						
	PF_MIN		Cφ_MIN				
	> 1.1 / 1.2		> 2.1 / 2.2		> 3.1 / 3.2		
	∅ 1.1 / 1.2		∅ 2.1 / 2.2		∅ 3.1 / 3.2		
PQ3000 PQ5000	U12 U23 U31 F	UNE UNE_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31
	I I_MAX IMS		¹⁾ Only if measurement of homopolar voltage has been activated				
	P Q S PF		P_MAX Q_MAX S_MAX				
	P_TRIANGLE						
	PF_MIN		Cφ_MIN				
	> 1.1 / 1.2		> 2.1 / 2.2		> 3.1 / 3.2		
	∅ 1.1 / 1.2		∅ 2.1 / 2.2		∅ 3.1 / 3.2		

B4 Display matrices for 3-wire systems, unbalanced load

 Instantaneous values

Device	Corresponding matrix						
PQ1000	U12 U23 U31 F	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX				
	I1 I2 I3 IPE	I1_MAX I2_MAX I3_MAX IPE_MAX	IR1 IR2 IR2R1 IR21_MAX				
	P Q S PF	P_MAX Q_MAX S_MAX					
	P_TRIANGLE						
	PF_MIN	Cφ_MIN					
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2				
	∅ 1.1 / 1.2	∅ 2.1 / 2.2	∅ 3.1 / 3.2				
PQ3000 PQ5000	U12 U23 U31 F	UNE UNE_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31
	I1 I2 I3 IPE	I1_MAX I2_MAX I3_MAX IPE_MAX	IR1 IR2 IR2R1 IR21_MAX	¹⁾ Only if measurement of homopolar voltage has been activated			
	P Q S PF	P_MAX Q_MAX S_MAX					
	P_TRIANGLE						
	PF_MIN	Cφ_MIN					
	I> 1.1 / 1.2	I> 2.1 / 2.2	I> 3.1 / 3.2				
	∅ 1.1 / 1.2	∅ 2.1 / 2.2	∅ 3.1 / 3.2				

B5 Display matrices for 3-wire systems, unbalanced load, Aron

 Instantaneous values

Device	Corresponding matrix						
PQ1000	U12 U23 U31 F		U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX			
	I1 I2 I3 IMS		I1_MAX I2_MAX I3_MAX				
	P Q S PF		P_MAX Q_MAX S_MAX				
	P_TRIANGLE						
	PF_MIN		Cφ_MIN				
	I> 1.1 / 1.2		I> 2.1 / 2.2	I> 3.1 / 3.2			
	ϑ 1.1 / 1.2		ϑ 2.1 / 2.2	ϑ 3.1 / 3.2			
PQ3000 PQ5000	U12 U23 U31 F	UNE UNE_MAX ¹⁾	U12_MM U23_MM U31_MM F_MM	UR1 UR2 UR2R1 UR21_MAX	Pst12 Pst23 Pst31	UD12 UD23 UD31	OD12 OD23 OD31
	I1 I2 I3 IMS		I1_MAX I2_MAX I3_MAX	¹⁾ Only if measurement of homopolar voltage has been activated			
	P Q S PF		P_MAX Q_MAX S_MAX				
	P_TRIANGLE						
	PF_MIN		Cφ_MIN				
	I> 1.1 / 1.2		I> 2.1 / 2.2	I> 3.1 / 3.2			
	ϑ 1.1 / 1.2		ϑ 2.1 / 2.2	ϑ 3.1 / 3.2			

B6 Display matrices for 4-wire systems, unbalanced load

 Instantaneous values

Device	Corresponding matrix												
PQ1000	U1N U2N U3N UNE	U12 U23 U31 F	U1N_MM U2N_MM U3N_MM F_MM		U12_MM U23_MM U31_MM UR21_MAX		UR1 UR2 U0 UNB_UR2_UR1						
	I1 I2 I3 F	IN IPE IMS	I1_MAX I2_MAX I3_MAX IN_MAX		IR1 IR2 I0 UNB_IR2_IR1								
	P Q S PF	P1 P2 P3 P	Q1 Q2 Q3 Q	S1 S2 S3 S	P1_MAX P2_MAX P3_MAX P_MAX	Q1_MAX Q2_MAX Q3_MAX Q_MAX	S1_MAX S2_MAX S3_MAX S_MAX						
	P_TRIANGLE		P1_TRIANGLE		P2_TRIANGLE		P3_TRIANGLE						
	PF_MIN		Cφ_MIN										
	I> 1.1 / 1.2		I> 2.1 / 2.2		I> 3.1 / 3.2								
	ϑ 1.1 / 1.2		ϑ 2.1 / 2.2		ϑ 3.1 / 3.2								
PQ3000	U1N U2N U3N UNE	U12 U23 U31 F	U1N_MM / U12_MM U2N_MM / U23_MM U3N_MM / U31_MM F_MM / UR21_MAX			UR1 UR2 U0 UNB_UR2_UR1		Pst1N Pst2N Pst3N	UD1N UD2N UD3N	UD12 UD23 UD31	OD1N OD2N OD3N	OD12 OD23 OD31	
	I1 I2 I3 F	IN IPE IMS	I1_MAX / IN_MAX I2_MAX / IPE_MAX I3_MAX / IR21_MAX			IR1 IR2 I0 UNB_IR2_IR1							
	P Q S PF	P1 P2 P3 P	Q1 Q2 Q3 Q	S1 S2 S3 S	P1_MAX P2_MAX P3_MAX P_MAX	Q1_MAX Q2_MAX Q3_MAX Q_MAX	S1_MAX S2_MAX S3_MAX S_MAX						
	P_TRIANGLE		P1_TRIANGLE		P2_TRIANGLE		P3_TRIANGLE						
	PF_MIN		Cφ_MIN										
	I> 1.1 / 1.2		I> 2.1 / 2.2		I> 3.1 / 3.2								
	ϑ 1.1 / 1.2		ϑ 2.1 / 2.2		ϑ 3.1 / 3.2								
PQ5000	U1N U2N U3N UNE	U12 U23 U31 F	U1N_MM U2N_MM U3N_MM F_MM		U12_MM U23_MM U31_MM UR21_MAX		UR1 UR2 U0 UNB_UR2_UR1		Pst1N Pst2N Pst3N	UD1N UD2N UD3N	UD12 UD23 UD31	OD1N OD2N OD3N	OD12 OD23 OD31
	I1 I2 I3 F	IN IPE IMS	I1_MAX I2_MAX I3_MAX		IN_MAX IPE_MAX IR21_MAX		IR1 IR2 I0 UNB_IR2_IR1						
	P Q S PF	P1 P2 P3 P	Q1 Q2 Q3 Q	S1 S2 S3 S	P1_MAX P2_MAX P3_MAX P_MAX	Q1_MAX Q2_MAX Q3_MAX Q_MAX	S1_MAX S2_MAX S3_MAX S_MAX						
	P_TRIANGLE		P1_TRIANGLE		P2_TRIANGLE		P3_TRIANGLE						
	PF_MIN		Cφ_MIN										
	I> 1.1 / 1.2		I> 2.1 / 2.2		I> 3.1 / 3.2								
	ϑ 1.1 / 1.2		ϑ 2.1 / 2.2		ϑ 3.1 / 3.2								

B7 Common display matrices

Display menu	Corresponding matrix
 Energy Meter contents Standard meters	$\Sigma P_{I_IV_HT}$ $\Sigma P_{I_IV_NT}$ $\Sigma P_{II_III_NT}$ $\Sigma P_{II_III_HT}$ $\Sigma Q_{I_II_HT}$ $\Sigma Q_{I_II_NT}$ $\Sigma Q_{III_IV_HT}$ $\Sigma Q_{I_II_NT}$
 Energy Meter contents User meters	$\Sigma METER1$ $\Sigma METER2$ $\Sigma METER3$ $\Sigma METER4$ $\Sigma METER5$ $\Sigma METER6$ $\Sigma METER7$ $\Sigma METER8$ $\Sigma METER9$ $\Sigma METER10$ $\Sigma METER11$ $\Sigma METER12$
 Energy Mean-values Power mean-values + trend	$MT_{P_I_IV}$ $MT_{P_II_III}$ $MT_{Q_I_II}$ $MT_{Q_III_IV}$ MT_S
 Energy Mean-values User mean-values + trend	$M1 / TR_{M1}$ $M2 / TR_{M2}$ $M3 / TR_{M3}$ $M4 / TR_{M4}$ $M5 / TR_{M5}$ $M6 / TR_{M6}$ $M7 / TR_{M7}$ $M8 / TR_{M8}$ $M9 / TR_{M9}$ $M10 / TR_{M10}$ $M11 / TR_{M11}$ $M12 / TR_{M12}$ $M1_MM$ $M2_MM$ $M3_MM$ $M4_MM$ $M5_MM$ $M6_MM$ $M7_MM$ $M8_MM$ $M9_MM$ $M10_MM$ $M11_MM$ $M12_MM$ For PQ1000 and PQ5000 divided into 2 images each
 Energy Bimetal current	$IB1$ $IB2$ $IB3$ $IB1_MAX$ $IB2_MAX$ $IB3_MAX$

C Logic functions

The principal function of the logical gates is given in the following table, for simplicity shown for gates with two inputs only.

function	symbol	older symbols		truth table	plain text
		ANSI 91-1984	DIN 40700 (alt)		
AND				A B Y	Function is true if all input conditions are fulfilled
				0 0 0	
				0 1 0	
				1 0 0	
				1 1 1	
NAND				A B Y	Function is true if at least one of the input conditions is not fulfilled
				0 0 1	
				0 1 1	
				1 0 1	
				1 1 0	
OR				A B Y	Function is true if at least one of the input conditions is fulfilled
				0 0 0	
				0 1 1	
				1 0 1	
				1 1 1	
NOR				A B Y	Function is true if none of the input conditions is fulfilled
				0 0 1	
				0 1 0	
				1 0 0	
				1 1 0	

Using DIRECT or INVERT the input is directly connected to the output of a monitoring function, without need for a logical combination. For these functions only one input is used.

DIRECT		A Y	The monitoring function is reduced to one input only. The state of the output corresponds to the input.
		0 0	
		1 1	
INVERT		A Y	The monitoring function is reduced to one input only. The state of the output corresponds to the inverted input.
		0 1	
		1 0	

D FCC statement

The following statement applies to the products covered in this manual, unless otherwise specified herein. The statement for other products will appear in the accompanying documentation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules and meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003 for digital apparatus. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/T.V. technician for help.

Camille Bauer Metrawatt AG is not responsible for any radio television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Camille Bauer Metrawatt AG. The correction of interference caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

INDEX

A	
Alarming	72
C	
Commissioning	36
Compliance report	87
Configuration	
menu	64
cosφ	110
Cyber Security decommissioning	97
Cyber Security notes	6
Cyber Security policies	37
D	
Demounting	11
Device overview	7
Dimensional drawing	106
Display matrices	117
Driving a counter mechanism	27
E	
Electrical connections	
cross sections	16
digital input	25
digital output	27
I/O extensions	15
inputs	17
Modbus interface	31
power supply	24
relays	25
split phase	23
Elektrische Anschlüsse	
Analogausgang	28
Rogowski-Stromeingänge	24
Ethernet	
LEDs	44, 45
Ethernet installation	41
F	
Fault current	29
FCC statement	131
Firewall	44
G	
GPS	33
H	
HTTPS	57
I	
I, II, III, IV	63
IEC61850	47
Installation check	39
IRIG-B	35
L	
Logic components	
AND	130
DIRECT	130
INVERT	130
NAND	130
NOR	130
OR	130
Logic functions	130
M	
Measured quantities	109

Basic measurements	109
Bimetal current	115
earth fault monitoring	112
harmonic analysis	113
Load factors	111
mean values and trend	115
meters	116
system imbalance	114
zero displacement voltage	112
Measurement displays	62
Measurements	
reset	64
Mechanical mounting	10
Menu operation	61
N	
NTP	43
O	
Operating elements	61
P	
PQ event recordings	81
PQ monitoring	68
PQ statistic	85
PQDIF	90
Profinet IO	47
R	
RCM	29
Reactive power	111
Resetting measurements	64
Roman numbers	63
S	
Safety notes	6
Scope of supply	5
SD card	
Exchange	89
LED	89
SD-Card	89
Security system	51
Service and maintenance	97
Simulation	51
Summary alarm	76
Symbols	63
Symmetrical components	114
SYSLOG	60
T	
Technical data	98
temperature inputs	31
Time synchronization	
GPS	33
IRIG-B	35
NTP	43
U	
UPS (Uninterruptible power supply)	32
W	
Whitelist	57
Z	
Zero suppression	100